

## Lifetime Air 8711252503820

# Lifetime Air Mobile Air Conditioner User Manual

Model: 8711252503820

## INTRODUCTION

Thank you for choosing the Lifetime Air Mobile Air Conditioner. This 3-in-1 appliance functions as an air cooler, fan, and humidifier, designed to provide a comfortable indoor environment. This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before use and retain it for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using this appliance:

- Read all instructions before operating the appliance.
- Do not block air inlets or outlets. Ensure adequate space around the unit for proper airflow.
- Connect the appliance only to a properly grounded power outlet with the correct voltage (220-240V, 50-60Hz).
- Keep the appliance out of reach of children and pets.
- Always unplug the appliance from the power outlet before cleaning, maintenance, or when not in use for extended periods.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Do not operate the appliance with a damaged cord or plug, or if it has malfunctioned or been dropped or damaged in any manner.
- Use only manufacturer-recommended attachments.
- Do not use the appliance outdoors.
- Do not place the appliance near heat sources such as radiators, heat registers, stoves, or other heat-producing appliances.

## PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Lifetime Air Mobile Air Conditioner Unit
- 1 x Remote Control
- 2 x Cooling Elements (Ice Packs)
- 1 x User Manual
- 1 x Air Filter (pre-installed or separate)

## PRODUCT OVERVIEW

---

Familiarize yourself with the components of your Lifetime Air Mobile Air Conditioner.



**Figure 1:** Side view of the Lifetime Air Mobile Air Conditioner, showing its compact design and caster wheels for easy mobility.



**Figure 2:** Front view of the air conditioner, highlighting the air outlet louvers and the visible water level indicator on the side.



**Figure 3:** The remote control unit, featuring buttons for Power (On/Off), Speed, Mode, Timer, Swing, and Cool functions.



**Figure 4:** The two included cooling elements, designed to be frozen and placed in the water tank for enhanced cooling performance.



**Figure 5:** Close-up view of the removable 4-liter water tank, located at the bottom rear of the unit, used for humidification and cooling functions.





**Figure 6:** The air filter, which can be removed for cleaning or replacement, ensuring clean air circulation.



Follow these steps to set up your mobile air conditioner for first use:

1. **Unpacking:** Carefully remove the appliance and all accessories from the packaging. Retain the packaging for future storage or transport.
2. **Placement:** Place the air conditioner on a flat, stable surface. Ensure there is at least 20 cm of clear space around the unit for optimal airflow. The unit's caster wheels allow for easy repositioning.
3. **Prepare Cooling Elements (Optional for enhanced cooling):** Fill the two cooling elements with water (if not pre-filled) and place them in a freezer for at least 4 hours until completely frozen.
4. **Fill Water Tank:** Pull out the water tank from the rear of the unit (refer to Figure 5). Fill the tank with clean, cool water up to the "MAX" line. If using cooling elements, place them into the water tank after filling. Carefully slide the water tank back into its position until it clicks securely.
5. **Connect Power:** Plug the power cord into a standard electrical outlet (220-240V, 50-60Hz). The unit will emit a beep, and the LED display will light up briefly, indicating it is in standby mode.

## OPERATION

The Lifetime Air Mobile Air Conditioner can be operated using the control panel on the unit or the included remote control (refer to Figure 3).

### Control Panel and Remote Control Functions

- **Power Button ( ):** Press to turn the unit ON or OFF.
- **Speed Button (≡):** Press repeatedly to cycle through the three fan speeds: Low (5 m/s), Medium (5.8 m/s), and High (6.8 m/s). The current speed will be indicated on the LED display.
- **Mode Button (■):** Press to select the operating mode:
  - **Fan Mode:** Circulates air without cooling or humidifying.
  - **Humidifier Mode:** Releases moisture into the air from the water tank.
  - **Cooler Mode:** Activates the water pump to circulate water over the cooling pad, providing evaporative cooling. For enhanced cooling, ensure cooling elements are in the water tank.
- **Timer Button ( ):** Press to set the operating timer. Each press increases the timer by 0.5 hours, up to a maximum of 15.5 hours. The unit will automatically turn off once the set time expires.
- **Swing Button (↺):** Press to activate or deactivate the 60-degree oscillation function, which moves the louvers horizontally to distribute air more widely.
- **Cool Button (\*):** Activates or deactivates the cooling function. This function requires water in the tank and is enhanced by the use of frozen cooling elements.

**Note:** The unit operates at a maximum noise level of 55 dB, making it suitable for various environments, including bedrooms.

## MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your appliance. Always unplug the unit before performing any maintenance.

- **Cleaning the Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Cleaning the Water Tank:**
  - a. Remove the water tank from the unit.

- b. Empty any remaining water.
- c. Clean the tank with mild soap and water. Rinse thoroughly to remove any soap residue.
- d. Allow the tank to air dry completely before reinserting it into the unit. Clean the tank regularly to prevent mold and mildew growth.

• **Cleaning the Air Filter:**

- a. Locate the air filter at the back of the unit (refer to Figure 6).
- b. Gently pull out the filter.
- c. Rinse the filter under running water to remove dust and debris. For stubborn dirt, use a soft brush.
- d. Allow the filter to air dry completely before reinserting it. Do not use the unit without the filter.

- **Storage:** If storing the unit for an extended period, ensure the water tank is empty and clean, and the unit is dry. Store in a cool, dry place, preferably in its original packaging.

## TROUBLESHOOTING

Before contacting customer support, please refer to the following table for common issues and their solutions:

| Problem                           | Possible Cause   | Solution  |
|-----------------------------------|--|---|
| Unit does not turn on.            | No power supply.   | Check if the power cord is securely plugged into a working electrical outlet.   |
| No cool air / Weak cooling.       | Water tank is empty or low.<br>Cooling elements are not frozen.          | Fill the water tank with clean, cool water. Ensure cooling elements are frozen and placed in the tank.                  |
| Weak airflow.                     | Air filter is clogged with dust.   | Clean the air filter as described in the Maintenance section.   |
| Unit is noisy.                    | Unit is not on a flat surface.<br>Internal components may be obstructed. | Ensure the unit is placed on a stable, level surface. Check for any foreign objects inside the unit (after unplugging). |
| Oscillation function not working. | Swing function is deactivated.   | Press the Swing button on the control panel or remote control to activate oscillation.                                  |

## SPECIFICATIONS

| Feature                | Detail            |
|------------------------|-------------------|
| Brand                  | Lifetime Air      |
| Model Number           | 8711252503820     |
| Dimensions (L x W x H) | 22 x 24 x 53.5 cm |
| Weight                 | 3.6 kg            |
| Material               | Plastic           |
| Color                  | White             |



| Feature               | Detail  |
|-----------------------|---|
| Power                 | 80 Watts  |
| Voltage               | 220-240 Volts   |
| Airflow Capacity      | 412 m³ per hour   |
| Water Tank Capacity   | 4 Liters  |
| Wind Speed (3 levels) | 6.8 / 5.8 / 5 m/s   |
| Noise Level           | Max 55 dB   |
| Timer Function        | Up to 15.5 hours  |
| Oscillation Function  | 60-degree oscillating fan   |
| Controls              | LED display, Remote control   |
| Special Features      | 3-in-1 (Air Cooler, Fan, Humidifier), Quiet operation, Adjustable speed |





## WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your purchase or contact the retailer where you purchased the product. Warranty terms and conditions may vary by region and retailer.

If you encounter any issues that cannot be resolved using the troubleshooting guide, or require further assistance, please contact Lifetime Air customer support. Contact details are typically available on the product packaging or the manufacturer's official website.

## Related Documents - 8711252503820

|   |   |
|---|---|
|  | <p><a href="#">Lifetime Air 8000 BTU Air Conditioner Instruction Manual</a></p> <p>Comprehensive instruction manual for the Lifetime Air 8000 BTU air conditioner, covering safety instructions, product description, setup, operation, maintenance, and troubleshooting.</p> |
|  | <p><a href="#">Lifetime Air LQ-AC07S Air Cooler Instruction Manual</a></p> <p>Comprehensive instruction manual for the Lifetime Air LQ-AC07S air cooler, covering setup, operation, safety precautions, cleaning, and maintenance.</p>  |

|  |   |
|--|---|
|    | <p><a href="#">LIFETIME AIR Instruction Manual</a></p> <p>This document is an instruction manual for the LIFETIME AIR air conditioner, model JHS-A016-09KR2/A. It provides safety instructions, product description, operation guidelines, maintenance procedures, troubleshooting tips, and technical specifications.</p>  |
|   | <p><a href="#">Lifetime Air JHS-A016-09KR2/A Instruction Manual</a></p> <p>Comprehensive instruction manual for the Lifetime Air JHS-A016-09KR2/A air conditioner, covering safety, operation, installation, and maintenance.</p>   |
|   | <p><a href="#">GUNJI Evaporative Cooler User Manual - Features, Operation, and Maintenance</a></p> <p>Comprehensive user manual for GUNJI evaporative coolers, including models T-PAC24-0787-11GY and T-PAC24-0787-9GY. Learn about features like 12-hour auto shut-off, ice packs, 3-speed settings, smart remote control, and dual water tanks for efficient cooling.</p> |
|  | <p><a href="#">CONOPU OZJ21S07 Air Humidifier User Manual</a></p> <p>Comprehensive instructions for the CONOPU OZJ21S07 Air Humidifier, covering operation, cleaning, maintenance, and warranty. This ultrasonic humidifier features constant temperature, three modes, silent operation, multiple moisture settings, and timer functions.</p>                              |