

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Woputne](#) /

› [Woputne HL-TJ8010A Desk Clip-on Lamp Instruction Manual](#)

Woputne HL-TJ8010A

Woputne HL-TJ8010A Desk Clip-on Lamp Instruction Manual

Model: HL-TJ8010A

[Box](#) [Setup](#) [Operation](#) [Overview](#) [Safety Instructions](#) [What's in the](#)
[Features](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty &](#)
[Support](#)

1. PRODUCT OVERVIEW

The Woputne HL-TJ8010A Desk Clip-on Lamp is designed to provide versatile and adjustable lighting for various tasks and environments. Featuring a sturdy clamp, flexible gooseneck, multiple light modes, and dimmable brightness levels, it is ideal for reading, home office work, crafting, and more. This lamp is USB-powered and includes a 5V 2A adapter for convenient use.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before use.
- Do not expose the lamp to water or excessive moisture. This product is not waterproof.
- Use only with the provided 5V 2A adapter or a compatible USB power source.
- Avoid looking directly into the LED light source for extended periods to prevent eye strain.
- Ensure the clamp is securely fastened to a stable surface before adjusting the lamp.
- Keep out of reach of children.
- Do not attempt to disassemble or repair the lamp yourself. Contact customer support for assistance.
- Unplug the lamp from the power source when not in use or before cleaning.

3. WHAT'S IN THE BOX

Your Woputne HL-TJ8010A Desk Clip-on Lamp package includes:

- Woputne Desk Clip-on Lamp (2 pieces for 2-pack variant)

- 5V 2A USB Power Adapter (2 pieces for 2-pack variant)

4. SETUP GUIDE

1. Attach the Lamp:

Locate a suitable surface (desk, headboard, shelf) for clamping the lamp. The sturdy clamp can open up to 5cm (2 inches) wide. Ensure the surface is stable and the clamp is securely fastened to prevent accidental falls.



Detailed view of the lamp's clamp, demonstrating its secure attachment to a surface. The clamp features scratch-resistant foam for protection.

2. Connect Power:

Plug the USB cable from the lamp into the provided 5V 2A USB power adapter. Then, plug the adapter into a standard wall outlet. Alternatively, you can plug the USB cable directly into a compatible USB port on a computer or power bank.



The lamp's USB cable and the included 5V 2A power adapter. The USB cable is approximately 150cm long.

3. Position the Light:

Utilize the 360° flexible gooseneck to adjust the lamp head to your desired angle and position. The gooseneck is approximately 38cm long, allowing for extensive customization of light direction.

Your browser does not support the video tag.

Video demonstrating the flexibility of the gooseneck and how to position the lamp head. This video is provided by Woputne-US.

5. OPERATING INSTRUCTIONS


The Woputne Desk Clip-on Lamp features an inline control panel for easy adjustment of light settings.




Close-up of the control panel with buttons for power, mode, and brightness adjustment.

- **Power On/Off:** Press the power button (ⓘ) to turn the lamp on or off.
- **Change Light Mode:** Press the mode button (M) to cycle through the 3 available light colors:
 - Warm Light
 - Natural Light
 - White Light


3 COLORS LIGHTING MODE




Warm Light



Natural Light



White Light



Visual representation of the three distinct color temperatures offered by the lamp.


- **Adjust Brightness:** Use the '+' and '-' buttons to adjust the brightness level. There are 10 dimmable brightness levels, from 10% to 100%.

- **Auto Turn Off Function:** The reading light can be set to turn off automatically after 1 minute. This feature allows you to settle into bed under illumination before it switches off.
- **Memory Function:** The lamp remembers the last used brightness and mode settings until the power supply is disconnected.

6. KEY FEATURES

- **3 Light Colors & 10 Brightness Levels:** Offers cool light, warm light, and natural light with 10 adjustable brightness levels (10% to 100%) for various activities like painting, reading, or studying.
- **Sturdy Clip & 360° Flexible Gooseneck:** The robust clamp securely attaches to surfaces up to 5cm thick. The 360° flexible gooseneck (approx. 38cm long) allows for precise light positioning.
- **Auto Turn Off & Memory Function:** Includes a 1-minute auto-off timer and remembers the last brightness and mode settings.
- **Compact & Versatile Design:** Small, round lamp head (8.8cm diameter) provides uniform light. The compact clamp design saves desktop space.
- **USB-Powered with Adapter:** Comes with a 5V 2A mains plug for convenient power.
- **Multi-Application:** Suitable for bedside reading, college dorm study, painting, sewing, nail art, makeup, crafts, and baby night care.

10 Levels of Brightness (10%-100%)



The lamp in use, highlighting its adaptability for different environments and tasks.

7. CARE AND MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the lamp. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the lamp in a cool, dry place away from direct sunlight.
- **Handling:** Avoid excessive force when adjusting the gooseneck to prevent damage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not turn on.	Not properly plugged in; power outage; faulty adapter/cable.	<p>Ensure the USB cable is securely connected to both the lamp and the power adapter.</p> <p>Verify the power adapter is firmly plugged into a working wall outlet.</p> <p>Try plugging the lamp into a different USB port or using a different compatible USB adapter.</p>
Light flickers or is dim.	Insufficient power supply; loose connection.	<p>Ensure the power source provides adequate 5V 2A output.</p> <p>Check all connections for looseness.</p> <p>Adjust brightness using the '+' button on the control panel.</p>
Lamp turns off unexpectedly.	Auto-off timer activated; power interruption.	<p>The lamp has a 1-minute auto-off function. If this is not desired, ensure you are not activating it.</p> <p>Check for stable power supply.</p>
Cannot change light mode or brightness.	Control panel malfunction.	<p>Ensure the lamp is powered on.</p> <p>If the issue persists, contact customer support.</p>

9. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Woputne
Model Name	HL-TJ8010A
Light Source Type	LED
Power Source	USB-Powered (5V 2A Adapter included)
Wattage	5 watts
Brightness	400 Lumen (Max)
Light Colors	Warm White, Natural Light, Cool White (3 Modes)
Brightness Levels	10 (10% to 100% dimmable)
Control Method	Touch (Inline Control Panel)
Mounting Type	Clip On (Clamp mounting)
Clamp Opening	Up to 5cm (2 inches)
Gooseneck Length	Approx. 38cm
USB Cable Length	Approx. 150cm

Feature	Detail
Lamp Head Diameter	Approx. 8.8cm
Material	Acrylonitrile Butadiene Styrene, Aluminum
Item Weight	1.26 pounds
Product Dimensions	8"D x 13"W x 17"H
Indoor/Outdoor Usage	Indoor
Special Features	Dimmable, Auto Turn Off, Memory Function

10. WARRANTY AND SUPPORT

Woputne products are designed for quality and reliability. For any questions, concerns, or warranty claims, please contact Woputne customer support through your original purchase platform or visit the official Woputne store. Please retain your proof of purchase for warranty purposes.

Woputne Store: [Visit the Woputne Store on Amazon](#)