

[Manuals.plus](#) /

› [Hatteker](#) /

› Hatteker Professional Hair Clipper Electric Razor Foil Shavers User Manual

Hatteker HT-602

Hatteker Professional Hair Clipper & Electric Razor User Manual

Model: HT-602 | Brand: Hatteker

1. INTRODUCTION

Thank you for choosing the Hatteker Professional Hair Clipper and Electric Razor Grooming Kit. This versatile 2-in-1 kit is designed to meet all your grooming needs, offering precision trimming for hair, beard, nose, ear, and body hair. With its powerful motor, long-lasting battery, and waterproof design, this kit provides a professional barber-like experience in the comfort of your home.

UPGRADE CLIPPERS SET



The Hatteker Professional Hair Clipper and Electric Razor Kit, showcasing its sleek design and key features.

2. PRODUCT COMPONENTS

Your Hatteker grooming kit includes the following items:

- Hair Clipper (T-blade trimmer)
- Electric Foil Shaver with Triple Blades
- Nose/Ear Hair Trimmer Attachment
- Beard Trimmer Attachment
- 5 Guide Combs for Hair Clipper (3mm, 6mm, 9mm, 12mm, 15mm)
- 4 Guide Combs for T-blade Trimmer (1mm, 3mm, 5mm, 7mm)
- Cleaning Brush
- USB Charging Cable
- Lubricating Oil (for blade maintenance)



3. SETUP

1. **Initial Charge:** Before first use, fully charge the trimmer. Connect the USB charging cable to the device and a suitable USB power source. The LED display will indicate charging progress. The hair clipper takes approximately 1.5 hours for a full charge, providing 180 minutes of working time. The electric razor takes 1.5 hours for a full charge, providing 75 minutes of working time.

USB RECHARGEABLE

Large capacity lithium battery



Information on USB charging and battery runtime for both the clipper and shaver.

2. **Attachment Selection:** Choose the appropriate attachment (hair clipper, T-blade trimmer, nose/ear trimmer, or foil shaver) for your grooming needs.



The grooming kit is suitable for various uses including hair, beard, nose, and body hair.

3. **Guide Comb Attachment:** If using the hair clipper or T-blade trimmer, select the desired guide comb (e.g., 3mm, 6mm, 9mm, 12mm, 15mm for clipper; 1mm, 3mm, 5mm, 7mm for T-blade) and securely attach it to the blade head.



Illustration of various guide combs for precise cutting lengths.

4. OPERATING INSTRUCTIONS

4.1 General Operation

- Ensure the device is charged before use. The intelligent LED display shows the remaining battery percentage.
- Press the power button to turn the device ON/OFF.
- For optimal performance, ensure your hair is clean and dry before trimming or shaving.

4.2 Using the Hair Clipper / T-blade Trimmer

1. Attach the desired guide comb for your preferred hair length. For precise trimming, artwork, or outlining, use the T-blade trimmer without a guide comb for a 0.3mm cut.
2. Hold the clipper against the direction of hair growth and move it slowly and steadily.
3. For best results, stretch the skin taut with your free hand.



Visual guide for using the hair clipper, T-blade trimmer, and foil razor for different grooming steps.

4.3 Using the Electric Foil Shaver

1. The triple foil shaver is designed for a close and smooth shave, ideal for hair, beard, and bald heads.
2. If your hair is thick or long, it is recommended to use the clipper or T-blade trimmer first to shorten the hair before using the foil shaver for a cleaner finish.
3. Move the shaver gently against the direction of hair growth for optimal results.

4.4 Using the Nose/Ear Hair Trimmer

- Carefully insert the nose/ear hair trimmer into your nostril or ear canal.
- Move the trimmer in a circular motion to effectively remove unwanted hair.

4.5 Official Product Video



Official product video demonstrating the features and usage of the Hatteker Hair Clipper and Electric Razor Foil Shavers.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your grooming kit.

1. **Detachable Heads:** All attachments are detachable for easy cleaning.
2. **Initial Cleaning:** After each use, use the included cleaning brush to remove any loose hairs or debris from the blade and foil heads.
3. **Water Rinse:** The device features an IPX7 waterproof design, allowing it to be fully washable. Rinse the blade and foil heads under running water for thorough cleaning.



The IPX7 waterproof design allows for easy cleaning under running water.

4. **Foil Shaver Head Cleaning:** To clean the triple foil shaver head, press the hood release button to detach it. Clean the blade net with the cleaning brush, then remove the inner blades and clean them. Reinstall in reverse order after cleaning.



Detailed steps for cleaning the razor heads, including disassembly and reassembly.

- 5. **Lubrication:** After drying the blades, apply a few drops of lubricating oil to the blades to maintain their sharpness and smooth operation.
- 6. **Storage:** Store the device and its attachments in a clean, dry place. The travel lock design helps prevent accidental activation during transport.

6. TROUBLESHOOTING

If you encounter any issues with your Hatteker grooming kit, please refer to the following common solutions:

- **Device Not Turning On:** Ensure the device is fully charged. Check the LED display for battery level.
- **Poor Cutting Performance:**
 - Clean the blades and foil heads thoroughly to remove any trapped hair or debris.
 - Apply lubricating oil to the blades.
 - Ensure the correct guide comb is attached securely.
 - For thick or long hair, pre-trim with the clipper before using the shaver.
- **Excessive Heat During Use:** Prolonged continuous use can cause the trimmer to heat up. Allow the device to cool down if it becomes too warm.

If the problem persists, please contact Hatteker customer support for assistance.

7. SPECIFICATIONS

Brand	Hatteker
Model Number	HT-602
Product Dimensions	2.83 x 6.54 x 9.02 inches
Item Weight	1129 Grams (2.49 Pounds)
Battery Type	Built-in Rechargeable Lithium-ion Battery
Hair Clipper Runtime	180 minutes (after 1.5 hours charge)
Electric Razor Runtime	75 minutes (after 1.5 hours charge)
Waterproof Rating	IPX7 (Fully Washable)
Motor Speed	6500 RPM
Recommended Uses	Beard, Hair, Body, Nose, Ear
Color	Gold
Country of Origin	China

8. SAFETY INFORMATION

- Keep the device out of reach of children.

- Do not disassemble or attempt to repair the device yourself. Contact qualified personnel for service.
- Ensure the charging port is dry before connecting the USB cable.
- Avoid using the device on irritated or damaged skin.
- Do not immerse the charging cable or power adapter in water.
- Only use the provided charging cable and accessories.

9. WARRANTY AND SUPPORT

Hatteker products are manufactured with high-quality standards. For any warranty inquiries, technical support, or assistance with your product, please contact Hatteker customer service. Please refer to the product packaging or the official Hatteker website for the most up-to-date contact information.

© 2024 Hatteker. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why won't my Hatteker HT-602 foil shaver turn on, and why does it make a buzzing noise before turning off?

If your Hatteker HT-602 foil shaver is buzzing and then turning off, it usually indicates that the motor is struggling to move the blades or the battery is too low to sustain operation. Follow...

[Read full answer](#)

