onerbl ZD012M135100US

onerbl 13.5V AC-DC Adapter Instruction Manual

Model: ZD012M135100US

Introduction

This manual provides essential information for the safe and efficient use of your onerbl 13.5V AC-DC Adapter. This adapter is designed as a replacement power supply for specific Sharper Image cordless handheld vacuum models, including 1017174, 1017458, and 17577, which utilize an 11.1V Li-ion battery charging dock. It converts AC power from a wall outlet to the DC power required by your device's charging dock.

Safety Information

- Ensure the adapter is used with compatible devices only. Refer to the specifications for voltage and current requirements.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to severe impact.
- Do not attempt to open or modify the adapter.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.
- If the adapter appears damaged, discontinue use immediately.

Package Contents

- 1 x onerbl 13.5V AC-DC Adapter (Model: ZD012M135100US)

Setup

1. **Inspect the Adapter:** Before first use, visually inspect the adapter and its cable for any signs of damage.
2. **Connect to Charging Dock:** Insert the DC output plug of the onerbl adapter into the charging port of your Sharper Image vacuum's charging dock. Ensure a secure connection.
3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard 100-240V AC wall power outlet.

4. **Verify Connection:** Once connected, place your Sharper Image cordless handheld vacuum onto its charging dock. The vacuum's charging indicator (if present) should activate, indicating that charging has begun.



Image 1: The onerbl 13.5V AC-DC Adapter, showing the main unit with AC prongs and the DC output cable with its connector. The cable is

coiled for storage.

Operating Instructions

The onerbl AC-DC adapter is designed for straightforward operation. Once properly connected to a power outlet and your device's charging dock, it will automatically supply the necessary power for charging.

- Always ensure the adapter is firmly plugged into both the wall outlet and the charging dock.
- Monitor your device's charging indicator to confirm that it is receiving power.
- Disconnect the adapter from the wall outlet by pulling the plug, not the cord, when charging is complete or when the adapter is not in use.



Image 2: The onerbl AC-DC Adapter plugged into a power strip, demonstrating a typical usage scenario on a desk with other electronics.

Maintenance

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.

- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use. Avoid tightly coiling the cable to prevent damage.
- **Cable Care:** Regularly check the power cord for any cuts, fraying, or damage. Do not use if the cord is damaged.

Troubleshooting

Device Not Charging

- **Check Connections:** Ensure the adapter is securely plugged into both the wall outlet and the charging dock.
- **Verify Power Outlet:** Test the wall outlet with another device to confirm it is supplying power.
- **Inspect Adapter:** Check the adapter and its cable for any visible damage. If damaged, discontinue use.
- **Battery Condition:** Rechargeable batteries have a limited lifespan (typically 1 to 3 years). If the vacuum's battery is old or depleted beyond its capacity to hold a charge, it may not accept a charge even with a functional adapter. This is a common issue and does not indicate a fault with the charger. A voltmeter can be used to test if the charger is outputting the correct voltage.

Specifications

Model	ZD012M135100US
Input	100-240V AC, 50/60Hz, 0.3A
Output	13.5V DC, 1.0A (1000mA)
Compatibility	Sharper Image 1017174, 1017458, 17577 (for 11.1V Li-ion battery charging docks)
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Cable Length	76 inches (approx. 193 cm)




Image 3: Detailed dimensions of the adapter unit, showing its length, width, and height, along with the cable length.

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your purchase receipt as proof of purchase.

© 2025 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question