

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LAMA](#) /
- › [LAMA 64MP Digital Camera User Manual](#)

LAMA LM220C

LAMA 64MP Digital Camera User Manual

Model: LM220C

1. INTRODUCTION

This user manual provides comprehensive instructions for operating your LAMA 64MP Digital Camera (Model: LM220C). This compact point-and-shoot camera is designed for ease of use, offering high-resolution photos and Full HD video recording, making it suitable for various users including kids, students, and teenagers. It features a 2.8-inch LCD screen, 16X digital zoom, anti-shake technology, and Wi-Fi connectivity.




Image: The LAMA 64MP Digital Camera shown with its included accessories, highlighting its compact design and the 2.8-inch LCD screen.

2. PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- 1 x LAMA 64MP Digital Camera (Model: LM220C)
- 1 x User Manual
- 1 x 32GB Memory Card
- 1 x Type-C Charging Cable
- 2 x Rechargeable Batteries (BL-5B type)
- 1 x Drawstring Pouch
- 1 x Lanyard

Great Gift for Aged 4 - 15 Kids



32G SD Card
3000+ photos



2 Batteries
3-4 times
charge last one month



Storage Bag
Protection



Manual
Clear Instructions
for Use



Type-C Cable
1-2 hours
get fully charged



Lanyard
Avoid Falling

Image: A visual representation of the items included in the camera package, such as the camera, memory card, batteries, cables, and carrying pouch.

3. SETUP GUIDE

3.1 Battery and Memory Card Installation

1. Locate the battery and memory card compartment door on the bottom of the camera.
2. Slide the latch to open the compartment door.
3. Insert the BL-5B battery into the battery slot, ensuring the correct orientation as indicated inside the compartment.
4. Insert the 32GB memory card into the SD card slot until it clicks into place.
5. Close the compartment door securely until it latches.




Image: A detailed diagram illustrating the location of the battery and memory card slots, and how to insert them correctly.

3.2 Charging the Battery

Before first use, fully charge the camera battery. Connect the camera to a power source (USB wall adapter or computer) using the provided Type-C charging cable. The indicator light will show charging status and turn off when fully charged. A full charge typically takes 1-2 hours.

3.3 Initial Power On

Press and hold the Power Button located on the top of the camera until the LCD screen illuminates. The camera will display a "Welcome" message before entering shooting mode.

Your browser does not support the video tag.

Video: An official product video demonstrating the unboxing, battery and memory card installation, and initial power-on sequence of the LAMA 64MP Compact Camera.

4. OPERATING INSTRUCTIONS

4.1 Basic Photo and Video Capture

- **Taking Photos:** In photo mode, frame your shot using the 2.8-inch LCD screen. Press the Shutter Button halfway to focus, then fully press to capture the image.
- **Recording Videos:** Switch to video mode using the Mode/Menu button. Press the Shutter Button to start recording, and press it again to stop.

4.2 Zoom Function

The camera features a 16X digital zoom. Use the T/W (Telephoto/Wide-angle) button to zoom in or out. 'T' zooms

in, 'W' zooms out.



Image: Illustrates the camera's 16X digital zoom capability with examples at 4X, 8X, and 16X magnification, alongside various color filters (Normal, Gray, Red, Green, Blue).

4.3 Special Features

- **Fill Light:** The built-in fill light can be activated for improved illumination in low-light conditions. Use the UP button to toggle the fill light on/off.
- **Anti-Shake:** The camera includes anti-shake technology to help reduce blur caused by camera movement, especially useful during video recording or in challenging lighting.
- **Continuous Shooting:** Capture a rapid sequence of photos by holding down the shutter button in continuous shooting mode.
- **Smile Capture:** When enabled, the camera can automatically detect smiles and capture photos.
- **Self-Timer:** Set a delay (2s, 5s, 10s, 15s, 30s) before the camera takes a photo, allowing you to be in the shot.
- **Filters:** Apply various special filters (e.g., Normal, Gray, Red, Green, Blue) to your photos for creative effects.




Image: Visual examples of the camera's advanced features including smile detection, selfie mode, anti-shake for clear motion shots, and continuous shooting.

Fill Light

Bring a bright and charming world



Image: A comparison showing the effect of the built-in fill light, with examples of photos taken with the light off and on, demonstrating improved brightness.

4.4 Webcam Functionality

The camera can be used as a webcam for video calls or live streaming. Connect the camera to your computer using the Type-C cable. On the camera screen, select "PC Camera" mode when prompted. Note: In webcam mode, only the digital zoom button can be operated on the camera; other functions are disabled.



Image: Depicts the camera connected to a laptop, functioning as a webcam for video calls and live streaming on social media platforms.



Image: A visual guide showing the camera's menu option to select "PC Camera" mode when connected to a computer via USB.

4.5 Wi-Fi Connection and App Usage

The camera supports Wi-Fi connectivity for easy transfer of photos and videos to your mobile device. Download the "iDC CAM" app (scan the QR code provided in the product images or search your app store). Once connected, you can use your phone as a remote control for the camera, browse images, and download files for sharing.

WIFI Connection & 64MP Image & 4K Video Resolution

44MP

64MP

Download "iDC CAM" APP, it will turn your phone into a remote to control the digital camera, and browse images or download files from the camera to mobile phone by wifi for sharing.

*** Tripod is not included**

"iDC CAM" APP

Image: Illustrates the camera's Wi-Fi function, showing a smartphone connected to the camera for image transfer and remote control via the "iDC CAM" app. A QR code for the app is also visible.

Download the "iDC CAM" app here: <https://qr24.cn/FypBbk>

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera body. For the lens and screen, use a specialized lens cleaning cloth and solution. Avoid abrasive materials or harsh chemicals.
- **Battery Care:** Store batteries in a cool, dry place when not in use. If storing for extended periods, charge them to about 50% capacity. Avoid fully discharging batteries frequently.

- **Storage:** When not in use, store the camera in its provided pouch to protect it from dust and scratches. Keep it away from extreme temperatures, humidity, and direct sunlight.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera does not power on.	Battery is dead or incorrectly inserted.	Ensure battery is charged and inserted with correct polarity.
Cannot take photos/videos.	Memory card full, not inserted, or corrupted.	Check memory card. Delete old files, reinsert, or try a different card.
Images are blurry.	Camera shake, dirty lens, or out of focus.	Hold camera steady, clean lens, ensure auto-focus engages.
Wi-Fi connection fails.	Incorrect password, camera too far from device, app issue.	Verify password, move closer, restart camera/app/device.

7. SPECIFICATIONS

Feature	Detail
Model Name	LM220C
Photo Sensor Resolution	64 MP
Video Resolution	1080p FHD
Digital Zoom	16x
Screen Size	2.8 Inches
Display Type	LCD
Image Stabilization	Digital
Memory Storage Capacity	32 GB (External-Memory Size)
Connectivity Technology	Wi-Fi, USB Type-C
Item Weight	113 Grams
Battery Type	Lithium Polymer (BL-5B)
Supported File Format	JPEG (Image), MP4 (Video)
Special Feature	Wireless, Webcam Functionality, Fill Light, Anti-Shake, Continuous Shooting, Face Detection, Smile Capture, Self-Timer

8. WARRANTY AND SUPPORT


LAMA products are designed for reliability and performance. For warranty information, please refer to the warranty card included in your product packaging or visit the official LAMA website. If you encounter any issues or require technical assistance, please contact LAMA customer support through the following channels:

- **Official Website:** [Visit the LAMA Store on Amazon](#) (for product information and updates)
- **Email Support:** Refer to your user manual or product packaging for specific email contact.
- **Online FAQ/Troubleshooting:** Check the LAMA website for frequently asked questions and detailed troubleshooting guides.

Please retain your proof of purchase for warranty claims.

© 2024 LAMA. All rights reserved.

Related Documents - LM220C

	<p>Pattfield PE-550ST Jigsaw User Manual and Safety Instructions</p> <p>Comprehensive guide for the Pattfield PE-550ST Jigsaw, covering features, usage, safety precautions, maintenance, and technical specifications. Learn how to operate your jigsaw safely and effectively.</p>
	<p>KERBL Handstück mit Schneckenantrieb #18155 – Bedienungsanleitung</p> <p>Diese Bedienungsanleitung für das KERBL Handstück mit Schneckenantrieb #18155 bietet umfassende Informationen zur sicheren Verwendung, Wartung und Pflege dieses professionellen Werkzeugs für die Schur von Nutztieren wie Schafen, Ziegen, Lamas und Alpakas.</p>
	<p>LAMA Bluetooth Keyboard User Manual - Connect to Samsung Galaxy Tab A8</p> <p>User manual for the LAMA Bluetooth Keyboard, providing product specifications, operation guide, step-by-step Bluetooth connection instructions for Samsung Galaxy Tab A8, charging details, and cautions.</p>




[Catalogue KQUEO 2025 : Mobilier Ergonomique pour Espaces de Travail Modernes](#)

Découvrez le catalogue KQUEO 2025, présentant une large gamme de bureaux assis-debout, chaises ergonomiques et accessoires conçus pour améliorer le bien-être et la productivité au travail. Explorez des designs innovants et une qualité de fabrication française.



[POLAR Slush Machine Instruction Manual: DB331, DB332, DB843](#)

Comprehensive instruction manual for the POLAR Slush Machine models DB331, DB332, and DB843. Learn about safe operation, installation, cleaning, maintenance, and troubleshooting for your POLAR slush machine.



[Chöd Practice Manual and Commentary: A Guide to Buddhist Spiritual Practice](#)

Explore the profound Buddhist practice of Chöd with this comprehensive manual and commentary. Featuring teachings from the Fourteenth Karmapa, Jamgön Kongtrül Lodö Taye, and insights from Bokar Rinpoche, this guide offers detailed instructions, lineage explanations, and the Sadhana for practitioners of this significant Tibetan Buddhist tradition.