

## Xiiaozet LK300W (3 USB Port Model)

# Xiiaozet LK300W Wireless Print Server User Manual

Model: LK300W (3 USB Port Model)

## 1. PRODUCT OVERVIEW

The Xiiaozet LK300W Wireless Print Server allows you to share up to three USB printers across your local network, enabling multiple users to print wirelessly from their computers. This device supports both wired and wireless connections to your network, offering flexibility for various environments such as home offices, small businesses, and educational institutions. It is designed for easy setup and broad compatibility with most USB printers.



Front view of the Xiiaozet LK300W Wireless Print Server, showing the three USB ports, LAN port, power input, and reset button.



Detailed diagram of the print server showing its dimensions (75mm x 95mm x 27mm) and labeling of ports: USB1, USB2, USB3 (USB 2.0 ports for printers), LAN port (for router connection or direct PC configuration), Power port (DC5V-2A), and Reset button.

## 2. WHAT'S IN THE BOX

- 1x Xiiiozet LK300W Wireless Print Server
- 1x Power Adapter
- 1x Power Cable
- 1x Ethernet Cable

## 3. SETUP GUIDE

Setting up your Xiiiozet LK300W Wireless Print Server involves two main steps: network configuration and adding your printer. For Windows users, a quick installation tool simplifies the process.

### 3.1. Network Configuration

Follow these steps to connect your print server to your WiFi network:

---

Official video tutorial: "How to configure the network for print server?" This video demonstrates the step-by-step process of connecting the print server to your wireless network using a computer.

1. **Connect to the Print Server's Setup Network:** From your computer's available Wi-Fi networks list, connect to the network named "USBServer\_Setup". This is a temporary network created by the print server for initial configuration.
2. **Access the Configuration Page:** Your system should automatically redirect you to the Wi-Fi connection page in your web browser. If not, open a browser and navigate to a common test URL (e.g., <http://www.msftconnecttest.com/wifi/>) which often triggers the captive portal.
3. **Select Your Wi-Fi Network and Enter Key:** On the configuration page, select your desired Wi-Fi network name from the list and enter its Wi-Fi password (key).
4. **Apply Settings:** After confirming the Wi-Fi password is correct, click 'Next' or 'Apply'. The page will process the settings and disappear once the configuration is complete.
5. **Reconnect Your Computer:** Finally, reconnect your computer to the same Wi-Fi network that you configured the print server to join.
6. **Verify Connection:** Observe the 'Cloud' indicator light on the print server. It should stay on to indicate a successful network configuration.

#### Note:

- If your Wi-Fi key is incorrect, the configuration will fail. After approximately one minute, the 'USBServer\_Setup' network will reappear in your computer's available networks list. Please repeat the above steps carefully.

# Easy to Setup



## Step 1



Hardware  
Installation

## Step 2



Configure the Print  
Server to Network

## Step 3



Add Printer  
to Computer

For Windows users, using our designed Quick Installation Tool can install and add a printer to the computer without the need to remember the IP address.

Diagram illustrating the three easy setup steps: 1. Hardware Installation, 2. Configure the Print Server to Network, 3. Add Printer to Computer. It highlights that Windows users can use a Quick Installation Tool.

### 3.2. Adding Your Printer to Computer

After successful network configuration, you need to add the shared printer to your computer. For Windows users, a dedicated quick installation tool is available to simplify this process, eliminating the need to remember IP addresses. Refer to the software provided with your print server or the manufacturer's website for the latest installation tool and detailed instructions for your operating system.




An illustration showing the Xiiiozet print server connected to three different types of printers (laser, inkjet, and thermal label printer), demonstrating its ability to share multiple USB printers.

## 4. OPERATING INSTRUCTIONS


Once configured, the Xiiiozet LK300W allows any computer within the same network to connect to and utilize the shared printers. This enables seamless printing from various devices in different locations within your network.

# Share Your Printer with Multiple Computers

## Wired Connection Link to router with Ethernet cable



## Wireless Connection Connect via WiFi to the router



A diagram illustrating both wired and wireless connection options for sharing printers. The wired connection shows the print server linked to a router via an Ethernet cable, while the wireless connection shows it connected to the router via Wi-Fi, both allowing multiple computers to access connected printers.

# Send Your Print Jobs Anytime

All computers within the same network  
can connect to the printer



Home



Office



Shop



Warehouse

An overhead view of an office or home environment, showing how all computers within the same network can send print jobs to the printer connected via the print server, highlighting use cases for home, office, shop, and warehouse.

## 5. COMPATIBILITY

The Xiaozet Print Server is designed for wide compatibility, supporting RAW and IPP protocols. It covers approximately 95% of USB printers and 99% of network printers, including various types:


- Inkjet Printers
- Laser Printers
- Thermal Label Printers
- Dot Matrix Printers

It is compatible with major brands such as HP, Brother, and Canon (with the exception of Canon LBP series printers).

# Wide Compatibility

Supports RAW and IPP protocols

Support 95% of printer models



Inkjet Printers



Laser Printers



Thermal Label Printers



Dot Matrix Printers

Refer to our printer compatibility list or contact us for details.

An image showcasing the wide compatibility of the print server, supporting RAW and IPP protocols, and illustrating various compatible printer types: Inkjet Printers, Laser Printers, Thermal Label Printers, and Dot Matrix Printers.

## Important Compatibility Notes:

- Mobile printing and AirPrint functionalities are NOT supported by this device.
- Ensure your printer is on the compatibility list for seamless integration. If your printer uses the same drivers as those compatible with this product, it should work.

## 6. TROUBLESHOOTING

If you encounter issues during setup or operation, consider the following common solutions:

- **Network Configuration Issues:** If the 'Cloud' indicator light does not stay on after configuration, or if the 'USBServer\_Setup' network reappears, it likely indicates an incorrect Wi-Fi password was entered. Please re-attempt the network configuration steps carefully, ensuring the correct Wi-Fi key is provided.
- **Printer Not Detected:** Ensure the USB cable from the printer is securely connected to one of the print

server's USB ports. Verify that the printer is powered on and functioning correctly when connected directly to a computer.

- **Driver Installation:** Confirm that the correct printer drivers are installed on the computer attempting to print. The print server facilitates network access but does not replace the need for proper printer drivers.
- **Network Connectivity:** Ensure both the print server and the computer are connected to the same local network (either wired or wirelessly). Check your router's status and network cables.
- **Firewall/Antivirus:** Temporarily disable any firewall or antivirus software on your computer to see if it interferes with the print server's communication. If this resolves the issue, configure your security software to allow the print server's traffic.

If you continue to experience problems, please contact our technical support team for assistance. Provide details about your printer model, operating system, and the steps you have already taken.

## 7. SPECIFICATIONS

Feature	Detail
Product Dimensions	3.94 x 2.76 x 1.18 inches
Item Weight	8.8 ounces
Manufacturer	Xiiaozet
ASIN	B0D2HMPZZ1
Country of Origin	China
Item Model Number	LK300W (3 USB Port Model)
Connectivity	Wireless (Wi-Fi), Wired (Ethernet)
USB Ports	3 x USB 2.0
Supported Protocols	RAW, IPP

## 8. WARRANTY AND SUPPORT

The Xiiaozet Wireless Print Server comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included with your product or visit the official Xiiaozet website. If you require technical assistance, have questions about compatibility, or need support with setup and troubleshooting, please do not hesitate to contact our customer support team. Contact information can typically be found on the product packaging or the manufacturer's website.

