

[Manuals.plus](#) /

› [Rolosar](#) /

› User Manual for Rolosar Wireless Earbuds Q76

Rolosar Q76

User Manual

ROLOSAR WIRELESS EARBUDS Q76

Model: Q76 | Brand: Rolosar

Introduction

Thank you for choosing the Rolosar Q76 Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features such as Bluetooth 5.4, ENC noise canceling, and a comfortable, secure fit for active lifestyles. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

What's in the Box

- 2 x Wireless Earbuds
- 1 x USB C Charging Case
- 1 x User Manual
- 1 x USB C Cable
- 1 x Headphone Box



Image: The Rolosar Q76 Wireless Earbuds in their open charging case, showcasing the earbuds and the digital display on the case.

Setup

1. Charging the Earbuds and Case

Before first use, ensure both the earbuds and the charging case are fully charged.

1. Connect the provided USB-C cable to the charging port on the case and to a power source.
2. The LED display on the charging case will indicate the charging status.
3. A full charge for the charging case takes approximately 2 hours.
4. The earbuds charge automatically when placed inside the case. Earbuds charging time is approximately 1.5 hours.

IPX7 WATERPROOF

ACCOMPANY THE MOVEMENT

No Worries When Using



Image: Illustration showing the earbuds and charging case with battery life details, indicating 10 hours playtime for earbuds and 50 hours with the charging case.

2. Pairing with Your Device

The earbuds utilize advanced Bluetooth 5.4 technology for quick and stable connections.

1. Open the lid of the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn Bluetooth on.
3. Select "Q76" from the list of available devices to connect.
4. Once paired, the earbuds will automatically connect to the last paired device when taken out of the case.

Your browser does not support the video tag.

Video: Demonstration of initial pairing and connection process for the Rolosar Q76 Wireless Earbuds with a smartphone.

3. Wearing the Earbuds

The Q76 earbuds are designed with flexible ear hooks for a secure and comfortable fit, especially during sports activities.

1. Choose the right size ear tips (S/M/L) for optimal comfort and sound quality.

2. Place the earbud in your ear.
3. Gently place the earhook over your ear.
4. Rotate and adjust the earbud to a comfortable and secure angle.

Designed for sports Earhooks Design

Comfortable, firm, not easy to fall off



- 1 Choose the right size ear caps.
- 2 Place the earhook over your ear.
- 3 Rotate and adjust to a comfortable angle.

Image: Visual guide on selecting ear tip size, placing the earhook, and adjusting the earbud for a comfortable and secure fit.

Operating Instructions

The Q76 earbuds feature smart touch controls for easy management of music and calls.

SMART TOUCH CONTROL

High-sensitivity smart touch brings easy operation



Image: Detailed illustration of the touch control functions on the earbuds, including power, play/pause, volume, track skipping, and call management.

Music Control

- **Play/Pause:** Double-tap either the left or right earbud.
- **Volume Up:** Single-tap the right earbud.
- **Volume Down:** Single-tap the left earbud.
- **Next Track:** Long press the right earbud for three seconds.
- **Previous Track:** Long press the left earbud for three seconds.

Call Management

- **Answer/End Call:** Single-tap either earbud.
- **Reject Call:** Long press either earbud for two seconds.

Voice Assistant

- **Activate Voice Assistant (Siri, Google Assistant, etc.):** Triple-tap either earbud.

Maintenance

Cleaning and Care

To ensure the longevity and optimal performance of your earbuds, follow these care guidelines:

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.
- Avoid using abrasive cleaners, solvents, or harsh chemicals.

Water Resistance

The Rolosar Q76 earbuds have an IP7 waterproof rating, making them resistant to sweat, rain, and minor water splashes. They are suitable for workouts and outdoor activities.

- Do not submerge the earbuds in water.
- Ensure the charging port is dry before charging.

50H LONG PLAYTIME



Image: Visual representation of the earbuds' IPX7 waterproof capabilities, showing resistance to rain, sweat, and splashes.

Storage

Store the earbuds in their charging case when not in use to protect them and keep them charged.

Important Safety Warning

WARNING!!! Do not disassemble, hit, or burn the device.

Troubleshooting

Problem	Solution
---------	----------

Problem	Solution
Earbuds not pairing/connecting.	• Ensure earbuds are charged. • Turn off and on Bluetooth on your device. • Place earbuds back in case, close lid, wait a few seconds, then open again. • Unpair headphones: Quickly tap the left and right headphones 5 times simultaneously, then re-pair. • Try pairing with another device to check if the earbuds are functional.
No sound or low volume.	• Adjust volume on both the earbuds and your connected device. • Ensure earbuds are properly seated in your ears. • Check if the earbuds are connected to the correct device. • Clean any debris from the earbud speakers.
Charging case not charging.	• Check the USB-C cable and power adapter. • Ensure the charging port is clean and free of debris. • Try a different charging cable or power source.
Microphone not working.	• Ensure the earbuds are properly connected. • Check microphone settings on your connected device. • Clean the microphone opening on the earbuds.

Specifications

Feature	Detail
Model Name	Q76
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	15 Meters (approx. 30ft)
Noise Control	Passive Noise Cancellation (ENC for clear calls)
Audio Driver Size	13 Millimeters
Single Earbud Playtime	Approx. 10 hours
Total Playtime (with case)	Approx. 50 hours
Earbud Charging Time	1.5 hours
Case Charging Time	2 hours

Feature	Detail
Water Resistance Level	IP7 Waterproof
Control Type	Touch Control
Material	Plastic
Item Weight	1.76 ounces (50 Grams)
Product Dimensions	3.15 x 1.97 x 1.18 inches



Image: An exploded view diagram illustrating the internal structure of the earbud, highlighting features like 13mm drivers and call noise reduction.

Warranty and Support

Rolosar provides a **2-year warranty** for the Q76 Wireless Earbuds, ensuring peace of mind regarding product quality and

performance.

For any inquiries, technical assistance, or warranty claims, please contact our customer service. We aim to provide **24-hour customer service response**.

Contact Information:

• **UK Representative:**

- Company Name: CYRUS-Consulting Ltd
- Address: 40 Sheepcote Drive, Rugby, England, CV 239 FG
- Email: manager@cyrus-consultingltd.co.uk
- Tel: +44 7763 280 902

• **EC Representative:**

- Company Name: eVatmaster Consulting GmbH
- Address: Bettinastr.30, 60325 Frankfurt am Main, Germany
- Email: contact@evatmaster.com



Image: Information regarding Rolosar's 2-year warranty, 24-hour customer service response, and Climate Pledge Friendly initiative.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question