FUNLIO FL-032

FUNLIO Baby Jumper with Stand Instruction Manual

Model: FL-032

Important Safety Information

READ ALL INSTRUCTIONS BEFORE USE. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.

- **Age and Weight Limits:** Suitable for toddlers aged 6-24 months. Maximum weight capacity is 50 lbs (22 kg). Do not exceed these limits.
- **Supervision:** Never leave a child unattended in the jumper. Constant adult supervision is required.
- **Assembly:** Ensure all parts are correctly assembled and securely fastened before each use. Refer to the assembly section for detailed steps.
- **Folding Mechanism:** Exercise extreme caution when folding or unfolding the stand. Keep hands and fingers clear of pinch points to prevent injury. One user reported finger fractures during folding.
- **Placement:** Use on a flat, stable surface. Ensure adequate clear space around the jumper to prevent collisions.
- **Inspection:** Regularly inspect the jumper for any signs of wear, damage, or loose components (e.g., springs, carabiners, seat belt, frame connections). Discontinue use if any damage is found.
- **Child Readiness:** Physical therapists suggest ensuring the child can walk on flat feet before using a jumper. Use sparingly to support natural development.
- **Spring Tension:** Babies under 15 lbs may not experience sufficient bounce. The spring is designed for optimal bounce with children over 15 lbs up to 50 lbs.

Product Overview

The FUNLIO Baby Jumper with Stand provides a safe and engaging environment for infants and toddlers to exercise and play. It features a sturdy, foldable stand for indoor and outdoor use, an adjustable chain, and a comfortable seat.

Key Features:

- **Adjustable Height:** The chain length is adjustable up to 10 inches (26 cm) to accommodate growing children.
- **Durable Construction:** Equipped with strong and flexible 304 stainless steel springs, safety lock carabiners, high-

quality plastic, and non-slip rubber feet.

- **Comfortable Seat:** Made from soft, double-layer cotton fabric with a wide and firm Velcro seat belt for secure and comfortable play.
- **Portable Design:** Features a foldable stand for easy storage and transport, allowing use in various locations.
- **Safety Certifications:** Passes CPSC Certification (US), Toy Safety ASTM F963-17 (US), and European Standard EN 71 (Europe).



Image: A baby happily bouncing in the FUNLIO Jumper with an adult supervising. This image illustrates the product in use.

Assembly Instructions

Assembly typically takes less than 10 minutes. Follow these steps carefully to ensure proper setup.

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list (not provided in this document, refer to your product packaging).
2. **Assemble the Stand:** Connect the frame pieces to form the stand. Ensure all locking mechanisms click into place securely.
3. **Attach Rubber Rings:** Place the rubber rings onto the top horizontal pole of the stand.
4. **Secure the Jumper Mechanism:** Pass the screw through the hole on the top horizontal pole. Install the nut to secure it.
5. **Connect Spring and Carabiners:** Attach the strong and flexible spring to the secured screw on the stand. Use the safety lock carabiners to connect the jumper seat to the spring and chain. Ensure all carabiners are fully closed and locked.
6. **Adjust Chain Length:** Adjust the chain to the appropriate height for your child, ensuring their feet can touch the ground comfortably while slightly bent. The chain is adjustable up to 10 inches (26 cm).
7. **Final Check:** Before first use, double-check all connections, bolts, and safety features to ensure they are tight and secure.



Image: Close-up of the jumper's safety features including the spring, safety lock carabiners, adjustable seat belt, and wide Velcro seat belt.




Image: Visual guide demonstrating the four steps to attach the jumper mechanism to the stand: placing rubber rings, passing the screw, installing the nut, and connecting the carabiner.

Assembly Video:

Your browser does not support the video tag.

Video: Official FUNLIO video demonstrating the assembly process of the baby jumper with stand. This video shows how to set up the frame

and attach the jumper seat.

Operating Instructions

1. **Place Child in Seat:** Carefully place your child into the jumper seat, ensuring their legs are through the leg openings.
2. **Secure Harness:** Fasten the wide and firm Velcro seat belt, then secure the locking strap, and finally the flap with two snaps. Ensure the harness is snug but not too tight, allowing for comfortable movement.
3. **Check Height:** Verify that your child's feet can touch the ground with a slight bend in their knees. Adjust the chain length if necessary.
4. **Supervise Play:** Remain with your child at all times while they are in the jumper. Encourage gentle bouncing and interaction.
5. **Remove Child:** To remove your child, unfasten the snaps, locking strap, and Velcro. Carefully lift your child out of the seat.

Usage Tips:

- Use for short periods to prevent over-stimulation or fatigue.
- Can be used indoors or outdoors on a stable, level surface.
- Ensure the child is wearing appropriate footwear or socks to protect their feet.



Image: A baby secured in the grey jumper seat, demonstrating the harness and leg openings.

Maintenance

- **Cleaning:** The fabric seat can be spot cleaned with mild soap and water. Allow to air dry completely. Do not machine wash or tumble dry.
- **Frame Cleaning:** Wipe down the metal frame with a damp cloth. Avoid abrasive cleaners.
- **Regular Inspection:** Periodically check all screws, bolts, springs, and carabiners for tightness and wear. Replace any worn or damaged parts immediately.
- **Storage:** When not in use, fold the stand for compact storage. Store in a dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Jumper does not bounce effectively.	Child's weight is too low (under 15 lbs). Spring tension is not optimal for lighter weights.	Ensure the child meets the recommended weight for optimal bounce (over 15 lbs). The spring is designed for a specific weight range.
Parts do not align during assembly.	Misalignment of screw holes or frame components.	Carefully re-read assembly instructions and ensure all parts are oriented correctly. Do not force components. If issues persist, contact customer support for replacement parts.
Jumper feels unstable.	Stand not fully extended or locked. Used on an uneven surface. Loose connections.	Ensure the stand is fully extended and all locking pins are engaged. Place the jumper on a flat, level surface. Check all bolts and connections for tightness.
Difficulty folding the stand.	Mechanism stiff or misaligned.	Apply gentle, even pressure. Ensure no obstructions. Always keep hands and fingers clear of moving parts. If excessive force is required, inspect for damage or contact support.

Specifications

- **Model Number:** FL-032
- **Suitable Age:** 6-24 months
- **Maximum Weight Recommendation:** 50 lbs (22 kg)
- **Maximum Height:** 61 inches (155 cm) when installed
- **Adjustable Chain Length:** Up to 10 inches (26 cm)
- **Materials:** Alloy Steel (frame), Cotton (seat fabric)
- **Item Weight:** 6.46 kg
- **Color:** Grey

Warranty and Support

FUNLIO is committed to providing exceptional products and services.

- **Return Policy:** 90-day return policy.
- **Quality Service:** 3-year quality service.
- **Missing or Damaged Parts:** In case any parts are missing or damaged during transportation, please contact FUNLIO customer service immediately. Replacements or exchanges will be processed within 2 business days.
- **Contact Information:** Refer to your product packaging or the official FUNLIO website for specific customer service contact details.



Image: Graphic detailing FUNLIO's customer service commitments, including a 90-day return policy and 3-year quality service.

© 2026 FUNLIO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question