

## Nerf F8947

# Nerf Fortnite Half Tone Hero Dart Blaster

Model: F8947

Brand: Nerf

## 1. IMPORTANT SAFETY INFORMATION

**WARNING: TO AVOID EYE INJURY:** Do not aim at eyes or face. Use of eyewear is recommended for players and people within range. Use only official Nerf darts. Other darts may not meet safety standards. Do not modify darts or the blaster.

**WARNING: CHOKING HAZARD – Small parts may be generated. Not for children under 3 years.**  
Recommended age: 8 years and up.

## 2. WHAT'S IN THE BOX

Your Nerf Fortnite Half Tone Hero Dart Blaster package includes:

- Blaster
- Barrel piece
- 12 Nerf Elite foam darts
- Download code (for in-game item)
- Instructions

## 3. ASSEMBLY

Assembly is required for the Nerf Fortnite Half Tone Hero Dart Blaster. Please refer to the included instructions for detailed steps on attaching the barrel piece. Ensure all components are securely connected before use.

## 4. LOADING DARTS

1. To load darts, first open the blaster's barrel. This is achieved by swinging the barrel downwards.



Image: The blaster's barrel is shown in an open position, revealing the dart chambers.

2. Insert one Nerf Elite foam dart into each of the six available chambers. Ensure darts are fully seated.



Image: A dart is being inserted into a chamber of the open barrel.

3. Once all darts are loaded, close the barrel by swinging it back into its original position until it clicks securely.

---

## 5. OPERATING THE BLASTER

1. To prime the blaster, pull back the hammer located at the rear of the blaster until it locks into place.



Image: The hammer mechanism is shown being pulled back to prime the blaster.

2. Aim the blaster at your target, ensuring no one is in the line of fire, especially eyes or face.
3. Press the trigger to fire a dart.



Image: A person is shown firing the blaster, with a dart visible in flight.

4. To fire subsequent darts, repeat the priming and firing steps.

## Demonstration Video

Your browser does not support the video tag.

Video: A full demonstration of the Nerf Fortnite Half Tone Hero Blaster, showing the loading and firing process. This video is provided by a seller and offers a visual guide to operating the blaster.

## 6. MAINTENANCE

- **Cleaning:** Wipe the blaster with a damp cloth to remove dust and dirt. Do not submerge the blaster in water.
- **Dart Care:** Use only official Nerf Elite darts. Inspect darts regularly for damage. Damaged darts may affect performance and safety.
- **Storage:** Store the blaster and darts in a cool, dry place away from direct sunlight.

## 7. TROUBLESHOOTING

- **Darts not firing:** Ensure the blaster is fully primed by pulling the hammer back until it clicks.

Check that darts are properly loaded into the barrel.

- **Darts jamming:** Ensure only official Nerf darts are used. Inspect darts for any damage or deformities. Do not modify darts or the blaster.
- **Reduced firing range:** This can be caused by worn or damaged darts. Replace old darts with new official Nerf Elite darts.

---

## 8. SPECIFICATIONS

Feature	Detail
Model Number	F8947
Product Dimensions	3.12 x 18 x 9.25 inches
Item Weight	1.26 pounds
Dart Capacity	6 darts
Darts Included	12 Nerf Elite foam darts
Manufacturer Recommended Age	8 years and up
Manufacturer	Hasbro

---

## 9. WARRANTY AND SUPPORT

For warranty information or product support, please contact Hasbro customer service directly. Refer to the product packaging or the official Hasbro website for current contact details and warranty terms.