

Infinix Hot 11 4G (X662)

Generic 2-in-1 Wallet Case for Infinix Hot 11 4G (X662)

User Instruction Manual

1. INTRODUCTION

This manual provides comprehensive instructions for the Generic 2-in-1 Wallet Case, designed specifically for the Infinix Hot 11 4G (X662) smartphone. This protective case combines a durable TPU soft shell with a stylish PU leather wallet, offering both protection and convenience. Please read this manual carefully to ensure proper use and maintenance of your product.

2. WHAT'S IN THE BOX

Your package should contain the following items:

- 1 x PU leather card slots holder
- 1 x TPU soft shell

These two components are designed to be used together as a single protective and functional unit.

3. SETUP AND INSTALLATION

Follow these steps to install your Infinix Hot 11 4G (X662) into the 2-in-1 wallet case:

- 1. Insert Phone into Soft Shell:** Gently place your Infinix Hot 11 4G (X662) into the TPU soft shell. Ensure that all edges of the phone are securely seated within the shell and that the cutouts align with your phone's ports, buttons, camera, and sensors.
- 2. Attach Soft Shell to Wallet:** The TPU soft shell is designed to fit snugly into the PU leather card holder. Align the soft shell with the designated area inside the wallet portion and press firmly until it is securely attached. The magnetic closure will help keep the wallet closed.



TPU Soft Case + Card holder



Figure 3.1: Components of the 2-in-1 case, showing the TPU soft case and the separate card holder. The image also displays different color options for the card holder.

4. OPERATING INSTRUCTIONS

This 2-in-1 wallet case offers several functional features:

- **Card Holder Functionality:** The PU leather wallet features built-in slots designed to hold multiple cards (e.g., credit cards, ID cards) and a small amount of cash.



Figure 4.1: Interior view of the wallet case, demonstrating the card slots and cash pocket.

- **Kickstand Feature:** The wallet portion can be folded to create a kickstand, allowing you to prop your phone horizontally for hands-free viewing of videos or video calls.
- **Magnetic Closure:** The case is equipped with a magnetic closure to keep the wallet securely shut, protecting your phone screen and contents.



Figure 4.2: The wallet case partially open, highlighting the card slots and the magnetic closure.

5. MAINTENANCE

To ensure the longevity and appearance of your wallet case, follow these maintenance guidelines:

- **Cleaning:** Wipe the PU leather surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the material.
- **Avoid Overstuffing:** Do not overfill the card slots, as this can stretch the material and weaken the magnetic closure over time.
- **Protection:** Keep the case away from extreme heat, direct sunlight for prolonged periods, and sharp objects to prevent damage.

6. TROUBLESHOOTING

This product is designed for simplicity and durability. Should you encounter any issues, consider the following:

- **Case not fitting phone:** Ensure you have the correct model, Infinix Hot 11 4G (X662). The case is precisely cut for this specific model.
- **Magnetic closure not holding:** Check if the wallet is overstuffed with cards or cash, which might prevent the magnets from engaging properly.

7. SPECIFICATIONS

Feature	Detail
Compatible Phone Model	Infinix Hot 11 4G (X662)
Material	PU Leather + TPU Soft Shell
Color	Brown
Special Features	2-in-1 Structure, Integrated TPU Soft Case, Kickstand, Card Holder, Magnetic Closure, Shockproof, Anti-drop
Form Factor	Basic Case / Wallet Case
Item Weight	2.46 ounces

8. WARRANTY AND SUPPORT

For any questions or support regarding your Generic 2-in-1 Wallet Case, please refer to the retailer or point of purchase. Specific warranty information is not provided in this manual. Please retain your purchase receipt for any potential warranty claims.