

[Manuals.plus](#) /

› [GreenPan](#) /

› GreenPan Rio Essence Wood 10 Piece Cookware Set Instruction Manual

GreenPan CC008702-001

GreenPan Rio Essence Wood 10 Piece Cookware Set

INSTRUCTION MANUAL

1. Product Overview

The GreenPan Rio Essence Wood 10 Piece Cookware Set is designed for convenience and healthy cooking. This collection features durable construction, an induction-ready design, healthy ceramic nonstick coating, and stylish wood-print handles. The Thermolon healthy ceramic nonstick coating is free of PFAS, PFOA, lead, and cadmium, ensuring worry-free cooking.



Image: The complete GreenPan Rio Essence Wood 10 Piece Cookware Set, showcasing various pots, pans, and silicone utensils.

Set Includes:

- 8" Frypan
- 10" Frypan
- 5.15QT Stockpot with Lid
- 2.24QT Saucepan with Lid
- 3.04QT Sauté Pan with Lid
- Silicone Solid Spoon
- Silicone Solid Turner

2. Safety Information

- Always use oven mitts or pot holders when handling hot cookware, as handles can become hot during prolonged cooking.
- Do not leave cookware unattended on a hot stovetop.
- This cookware set is **NOT OVEN SAFE**. Do not place any pieces in an oven.
- Ensure cookware is properly seated on the burner to prevent tipping and uneven heating.
- Keep children and pets away from the cooking area.

3. Before First Use

1. Remove all packaging materials and labels.
2. Wash each piece of cookware thoroughly with warm, soapy water using a soft sponge or cloth.
3. Rinse well and dry completely.
4. While GreenPan's ceramic nonstick coating does not require seasoning, a light wipe with a small amount of cooking oil on the nonstick surface before first use can help optimize performance.

4. Operating Instructions

The GreenPan Rio Essence Wood cookware is designed for optimal performance and ease of use. Follow these guidelines for best results:

Stovetop Compatibility:

This cookware set is suitable for **all stovetops, including induction, gas, electric, halogen, and ceramic**. The innovative induction base ensures uniform heat distribution.

VERSATILE DESIGN



UNIQUE INDUCTION BASE

UNIFORM HEATING ON ALL COOKTOPS, INCLUDING INDUCTION

Image: Underside of a GreenPan Rio Essence Wood pan, showing the unique induction-ready base for even heat distribution.

Heat Settings:

- Use **low to medium heat** for most cooking. The ceramic nonstick coating is highly efficient and retains heat well, so high heat is rarely necessary and can damage the nonstick surface over time.
- Only use high heat for boiling liquids.
- Avoid overheating empty pans.

Cooking with Nonstick:

- Always use a small amount of oil or butter for optimal nonstick performance and flavor.
- Use **silicone, wooden, or heat-resistant plastic utensils** to protect the nonstick surface. Avoid metal utensils, which can scratch the coating.
- The tempered glass lids with silicone rims allow you to monitor cooking progress without releasing heat or moisture.

TOXIN-FREE: FREE OF PFAS



CUTTING-EDGE CERAMIC NONSTICK

REINFORCED WITH DIAMONDS & FREE OF PFAS, PFOA, LEAD & CADMIUM

Image: A fried egg effortlessly sliding out of a GreenPan Rio Essence Wood frying pan onto a piece of toast, demonstrating the nonstick properties.

WARM & INVITING STYLE



WOOD-PRINT HANDLES

STYLISH HANDLES PROVIDE A STAY-COOL, COMFORTABLE GRIP

Image: A close-up view of the stay-cool wood-print handle on a GreenPan Rio Essence Wood pan, highlighting its ergonomic design and aesthetic.

Official Product Video:

Your browser does not support the video tag.

Video: An official GreenPan video showcasing the features and benefits of the Rio Essence Wood Cookware Collection, including its nonstick properties, induction compatibility, and ease of cleaning.

5. Care and Maintenance

Cleaning:

- This cookware is **dishwasher safe** for easy cleanup. However, hand washing is recommended to prolong the life and appearance of the nonstick coating and wood-print handles.
- For hand washing, allow the cookware to cool completely before washing. Use warm, soapy water and a soft sponge or cloth. Avoid abrasive cleaners, steel wool, or scouring pads, as these can damage the nonstick surface.

- For stubborn food residue, soak the pan in warm, soapy water for a few minutes before cleaning.
- Dry thoroughly after washing to prevent water spots.

EFFORTLESS CLEANING



DISHWASHER SAFE

WIPE CLEAN OR SIMPLY PLACE IN THE DISHWASHER WHEN YOU'RE THROUGH

Image: A GreenPan Rio Essence Wood frying pan being rinsed under a faucet in a kitchen sink, illustrating its easy-to-clean surface.

Storage:

When storing, place a soft cloth or pan protector between stacked pieces to prevent scratching the nonstick surface.

6. Troubleshooting

- **Food Sticking:** If food begins to stick, ensure you are using a small amount of cooking oil or butter. Overheating the pan or using metal utensils can degrade the nonstick coating over time. Always cook on low to medium heat. For best longevity of the nonstick surface, hand washing is recommended over frequent dishwasher use.
- **Handle Discoloration/Burning:** The wood-print handles are designed to stay cool, but direct exposure to high flames or improper placement on the burner can cause discoloration or damage. Ensure the pan is centered on the burner and flames do not extend up the sides of the pan. Always use oven mitts if handles become hot.

- **Coating Degradation:** While durable, extreme heat, abrasive cleaning, or metal utensils can compromise the nonstick coating. Follow care instructions carefully to maintain the coating's integrity.

7. Specifications

Brand	GreenPan
Model Name	Essence
Model Number	CC008702-001
Material	Aluminum, Ceramic (Thermolon Nonstick Coating)
Color	White
Special Feature	Induction Stovetop Compatible, PFOA & PFAS-Free Coating, Stay-Cool Wood Print Handles
Product Care Instructions	Dishwasher Safe (Hand wash recommended)
Is Oven Safe	No
Item Weight	7.96 Kilograms (17.51 pounds)
Package Dimensions	24.25 x 15 x 9 inches
UPC	885837044645

8. Warranty and Support

GreenPan products are manufactured to high-quality standards. For specific warranty information, product registration, or customer support, please visit the official GreenPan website or contact their customer service department.
Official GreenPan Store: [GreenPan Store on Amazon](#)

© 2024 GreenPan. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D2J4G8VS>

More documents and user manuals: <https://manuals.plus/>