

- Manuals.plus /
- > [Gemmy](#) /
- > Gemmy Halloween Inflatable Beetlejuice Scene - Instruction Manual

Gemmy Gemmy Beetlejuice Inflatable

Gemmy Halloween Inflatable Beetlejuice Scene Instruction Manual

Model: Gemmy Beetlejuice Inflatable

1. INTRODUCTION

Thank you for choosing the Gemmy Halloween Inflatable Beetlejuice Scene. This product is designed to provide a festive and fun decoration for your indoor or outdoor Halloween display. This manual provides essential information for the safe and proper setup, operation, and maintenance of your inflatable decoration.

The Beetlejuice Scene inflatable features Beetlejuice standing between Bob and Dave, holding banners that read "The Ghost With The Most" and "The Afterlife's Leading Bio-Exorcist!". It stands approximately 5 feet tall and self-inflates for quick setup.



Figure 1: The Gemmy Halloween Inflatable Beetlejuice Scene.

2. SAFETY INFORMATION

Please read and understand all safety instructions before operating this product. Failure to follow these instructions may result in injury or damage to the product.

- **Sharp Objects:** Keep the inflatable away from sharp objects to prevent punctures and damage to the material.
- **Windy Conditions:** Ensure proper anchoring using the included stakes and tethers, especially in windy conditions, to prevent the inflatable from blowing away or causing damage.
- **Supervision:** Supervise children and pets while setting up and inflating the product.
- **Electrical Safety:** Ensure the power cord and adapter are protected from water and damage. Do not operate if the cord is frayed or damaged.
- **Ventilation:** Do not block the air intake of the fan during operation.
- **Overheating:** Do not cover the fan or motor during operation. Allow adequate airflow.

3. SETUP INSTRUCTIONS

Follow these steps for quick and easy setup of your inflatable decoration:

1. **Unpack:** Carefully remove the inflatable and all accessories (stakes, tethers) from the packaging.
2. **Position:** Choose a flat, clear area for placement, free from debris, sharp objects, and overhead obstructions. Ensure the power cord can reach an outdoor-rated electrical outlet.
3. **Unfold:** Lay the inflatable flat on the ground and spread it out completely. Ensure the fabric is not twisted or bunched up.

4. **Connect Power:** Plug the inflatable's power cord into a standard electrical outlet. The internal fan will begin to inflate the decoration automatically.
5. **Inflate:** Allow the inflatable to fully inflate. This typically takes only a few seconds. Adjust the positioning as it inflates to ensure it stands upright and is properly oriented.
6. **Secure:** Once fully inflated, use the included stakes and tethers to secure the inflatable to the ground. Attach the tethers to the designated loops on the inflatable and stake them firmly into the ground at an angle. This is crucial for stability, especially outdoors.



Figure 2: The inflatable fully set up and secured in an outdoor environment.



Figure 3: The integrated fan unit at the base of the inflatable, responsible for inflation.

4. OPERATION

Operating your Gemmy Inflatable Beetlejuice Scene is straightforward:

- **To Inflate:** Plug the power cord into a suitable electrical outlet. The internal fan will automatically activate and inflate the decoration.
- **To Deflate:** Unplug the power cord from the electrical outlet. The inflatable will begin to deflate on its own.

For optimal display, ensure the inflatable remains plugged in during desired viewing hours. The internal fan must run continuously to keep the decoration inflated.

5. MAINTENANCE AND STORAGE

Proper care and storage will extend the life of your inflatable decoration:

- **Cleaning:** If the inflatable becomes dirty, gently wipe it with a damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the inflatable is completely dry before storing.
- **Deflation:** To store, unplug the unit and allow it to fully deflate.
- **Folding:** Once deflated, carefully fold or roll the inflatable. Try to remove as much air as possible to make it compact.
- **Storage:** Store the inflatable in its original box or a suitable storage container in a cool, dry place, away from direct sunlight and extreme temperatures. Protect it from pests and sharp objects.
- **Inspection:** Before each use, inspect the inflatable, power cord, and fan for any signs of damage or wear.

6. TROUBLESHOOTING

If you encounter issues with your inflatable, refer to the following common solutions:

- **Inflatable Does Not Inflate:**
 - Check if the power cord is securely plugged into a working electrical outlet.
 - Ensure the zipper on the inflatable (if present) is fully closed to prevent air leakage.
 - Verify that the fan intake is not blocked by fabric or debris.
 - Check for any tears or holes in the fabric. Small holes can sometimes be repaired with a patch kit (not included).
- **Inflatable Does Not Stand Upright:**
 - Ensure the inflatable is fully inflated.
 - Check that the tethers and stakes are properly secured and taut.
 - Adjust the placement of stakes and tethers to provide better balance.
 - In very windy conditions, consider relocating the inflatable to a more sheltered area or adding additional anchoring.
- **Lights Not Working:**
 - Ensure the power is connected. The lights are typically powered by the same connection as the fan.
 - Check for any loose connections within the light string if accessible.

7. SPECIFICATIONS

Feature	Detail
Brand	Gemmy
Model Number	Gemmy Beetlejuice Inflatable
Theme	Halloween
Character	Beetlejuice
Color	Multi
Material	Vinyl
Product Dimensions (L x W x H)	59.84 x 40.55 x 83.86 inches

Item Weight	7.67 pounds
Special Feature	Easy Setup, Self-inflating
Usage	Indoor or Outdoor
UPC	191245535799

8. WARRANTY AND SUPPORT

For warranty information or technical support, please contact the manufacturer, Gemmy, directly. Retain your proof of purchase for any warranty claims.

You can typically find contact information for Gemmy on their official website or through the retailer where you purchased the product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0D2J8GJ9L>

More documents and user manuals: <https://manuals.plus/>