

VOLT PLUS TECH TG01

User Manual for Portable Bluetooth Earbuds

Model: TG01 | Brand: VOLT PLUS TECH

INTRODUCTION

Thank you for choosing the VOLT PLUS TECH Portable Bluetooth Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features such as noise cancellation, an intuitive LED display, and a portable charging case with an integrated power bank. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Portable Bluetooth Earbuds (Left and Right)
- Portable Charging/Storage Case with Power Bank
- USB-C Charging Cable
- User Manual
- Two (2) pairs of different sized earbud tips (small, large)

PRODUCT OVERVIEW AND FEATURES

The VOLT PLUS TECH earbuds offer a range of features designed for convenience and superior audio quality:

- **Bluetooth 5.0 Connectivity:** Ensures stable and efficient wireless connection.
- **CVC 8.0 Intelligent Noise Reduction:** Reduces ambient noise for clear calls and immersive music.
- **IPX4 Waterproof Rating:** Protects against splashes and sweat, suitable for sports (charging case is not waterproof).
- **2000mAh Charging Case:** Provides extended battery life for earbuds, offering up to 24 hours of use.
- **Intelligent LED Display:** Clearly shows the battery level of the charging case and earbuds.
- **Touch Controls:** Easy management of music playback, calls, and voice assistant.



Image: The portable Bluetooth earbuds with their charging case open, displaying the earbuds inside and the digital battery indicator.



Image: The portable Bluetooth earbuds positioned next to their closed charging case, showcasing the compact design.

LED intelligent digital display

The battery level is clear at a glance



Image: A close-up view of the charging case's LED digital display, clearly showing the battery percentage.

SETUP AND PAIRING

Follow these steps for initial setup and pairing with your device:

1. **Power On:** Remove both earbuds from the charging case. They will automatically power on. Alternatively, press and hold the touch panel on both earbuds for 3 seconds until a blue indicator light flashes.
2. **Automatic Pairing:** After powering on, you will hear voice prompts, and both earbuds will flash blue and red indicators alternatively. Wait until both earbuds pair with each other. Once paired, the left earbud will continue to flash blue and red alternatively.
3. **Connect to Device:** You will hear a voice prompt 'pairing', indicating the earbuds are ready to pair with your mobile device. Turn on the Bluetooth function on your mobile device and search for "JS25" in the list of available devices.
4. **Final Connection:** Select "JS25" to pair and connect. Once successfully connected, the earbuds will prompt "Connected".
5. **Automatic Reconnection:** Once your device and earbuds are successfully connected, your earbuds will auto-connect to the previously paired device when they are turned on and Bluetooth is enabled on your device.

6. **Troubleshooting Pairing:** If you cannot pair the earbuds, place them back in the charging case and repeat the previous steps.

1. remove both earbuds from the charging case or touch the panel on both earbuds for 3 seconds, and wait for the earbuds to automatically power on.

2. after power on you will hear voice prompts and both earbuds will flash blue and red indicator alternatively.

3. wait until both earbuds pair with each other. once paired left earbuds will flash blue and red indicator alternatively.

4. you will hear a voice prompt 'pairing' which means that earbuds are 'ready to pair'. please enable bluetooth function on your device and search for 'Mytrack' to connect.

5. once your device and earbuds are successfully connected your earbuds will auto-connect to the previously paired device (if bluetooth is enabled) when they are turned on.

6. if you cannot pair the earbuds place them back in the case and repeat the previous steps.

QUICK PAIRING



Seamless
Single and Dual
Earbuds Switch

Image: A visual guide illustrating the quick pairing process for the earbuds, from removal from case to successful connection.



Image: Depiction of the earbuds automatically connecting to a smartphone upon removal from the charging case.

OPERATING INSTRUCTIONS

Touch Controls

The earbuds feature intuitive touch controls for various functions:

- **Play/Pause:** Single tap on either earbud.
- **Next Song:** Double tap on the right earbud.
- **Previous Song:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Volume Adjustment:** Specific instructions for volume adjustment are not detailed in the provided information, but typically involve a long press or multiple taps on a specific earbud. Refer to the quick start guide for precise gestures.

Charging the Earbuds and Case

The charging case acts as a power bank for your earbuds and can also charge your mobile phone.

- **Charging Earbuds:** Place the earbuds into the charging case. They will automatically begin charging. The LED display on the case will show the charging status.
- **Charging Case:** Connect the USB-C charging cable to the charging port on the case and to a power source. The LED display will indicate the charging progress of the case.
- **Power Bank Function:** The 2000mAh battery in the charging case can provide emergency power to your mobile phone via its USB-C output port.



Image: The earbuds resting in their charging case, with text overlays indicating features like fingerprint touch control, intelligent digital display, and HD calling.



Image: The earbuds positioned near a smartphone displaying a game, illustrating their capability to deliver immersive audio for an enhanced listening experience.

MAINTENANCE

To ensure the longevity and optimal performance of your earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Earbud Tips:** Remove and clean the earbud tips periodically to prevent wax buildup. You can gently wash them with water and mild soap, then dry them completely before reattaching.
- **Charging Ports:** Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Water Exposure:** While the earbuds are IPX4 waterproof, the charging case is not. Avoid exposing the charging case to water or excessive moisture.
- **Temperature:** Avoid exposing the product to extreme temperatures (hot or cold) as this can damage the battery and internal components.

TROUBLESHOOTING

If you encounter any issues with your earbuds, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Earbuds not powering on	Low battery; Not removed from case correctly	Charge the earbuds; Ensure earbuds are fully removed from the charging case.
Earbuds not pairing with device	Bluetooth off; Earbuds not in pairing mode; Previously paired device interfering	Ensure Bluetooth is enabled on your device; Place earbuds back in case, then remove to re-enter pairing mode; Forget "JS25" from your device's Bluetooth list and re-pair.
Only one earbud working	Earbuds not paired to each other; Low battery on one earbud	Place both earbuds back in the case, close, then reopen to force re-pairing; Charge both earbuds fully.
Poor sound quality or disconnections	Distance from device; Interference; Low battery	Move closer to your device; Avoid strong electromagnetic interference; Charge earbuds fully.
Charging case LED not lighting up	Charging cable issue; Power source issue; Case fully charged	Try a different USB-C cable; Use a different power adapter/port; The case might be fully charged.

SPECIFICATIONS

Detailed technical specifications for the VOLT PLUS TECH Portable Bluetooth Earbuds Model TG01:

Feature	Specification
Model Name	TG01
Connectivity Technology	Bluetooth 5.0
Wireless Communication Technology	Bluetooth
Noise Control	Active Noise Cancellation (CVC 8.0)
Water Resistance Level	IPX4 (Earbuds only)
Headphones Jack	USB-C (for charging case)
Frequency Response	48000 KHz
Impedance	25.94 Ohm
Control Method	Touch
Compatible Devices	ZTE Axon 20 and other Bluetooth-enabled devices
Material	Aluminum, Hi Strength Plastic, Metal
Item Weight	4 Ounces
Product Dimensions	1 x 1.7 x 1.5 inches

Feature	Specification
Manufacturer	VOLT PLUS TECH
Color	Black

WARRANTY AND SUPPORT

VOLT PLUS TECH products are manufactured to the highest quality standards. For specific warranty information and customer support, please refer to the warranty card included with your purchase or visit the official VOLT PLUS TECH website. Keep your purchase receipt as proof of purchase for any warranty claims.

If you require further assistance or have questions not covered in this manual, please contact VOLT PLUS TECH customer support.