ChooChoo ET2401-BK

ChooChoo Black End Table (Model ET2401-BK) Instruction Manual

1. Product Overview

The ChooChoo Black End Table (Model ET2401-BK) is designed for small spaces, offering a narrow profile suitable for living rooms, bedrooms, and home offices. This versatile side table features a mission design with slatted sides and a convenient storage shelf, providing both functionality and a modern aesthetic.



Figure 1: ChooChoo Black End Table in a living room setting.



Figure 2: Product dimensions: 11.81"D x 23.62"W x 23.62"H.

2. Assembly Instructions

This end table requires assembly. All necessary hardware and a screwdriver are included to facilitate a straightforward setup process. Follow the detailed instructions provided in the packaging for proper assembly. Typically, assembly can be completed by one person in approximately 25 minutes.



Figure 3: Detail of the lower shelf and slatted side design, highlighting components for assembly.

3. Usage Guidelines

The ChooChoo Black End Table is designed for versatile use across various indoor settings:

- **Living Room:** Place beside a sofa or armchair for drinks, remote controls, or decorative items.
- **Bedroom:** Functions as a nightstand, holding lamps, books, or personal items.
- **Home Office:** Can be used to support a computer mainframe or as an additional surface for office supplies.
- **Decorative Use:** The lower shelf provides space for baskets, books, or other decorative accents.



Figure 4: End table used as a side table in a living room.



Figure 5: The end table as part of a matching living room set.

4. Care and Maintenance

To maintain the appearance and longevity of your ChooChoo Black End Table, follow these simple care instructions:

- Wipe clean with a soft, damp cloth. Avoid abrasive cleaners.
- Do not expose to direct sunlight or extreme temperatures for prolonged periods.
- Promptly clean up spills to prevent staining.
- Periodically check and tighten all fasteners to ensure stability.



Figure 6: Detail of the wood grain finish, which should be cleaned gently.

5. Troubleshooting

If you encounter any issues with your end table, consider the following:

- **Instability:** Ensure all screws and connections are securely tightened. Uneven flooring may also contribute to instability; consider using furniture pads.
- **Missing Parts:** If any parts are missing upon arrival, please contact customer service immediately.
- **Damage:** For any damage incurred during shipping or manufacturing defects, refer to the warranty and support section.

6. Product Specifications

Feature	Detail

Brand	ChooChoo
Model Number	ET2401-BK
Product Dimensions (D x W x H)	11.81"D x 23.62"W x 23.62"H
Frame Material	Engineered Wood
Top Material Type	Wood
Color	Black
Number of Shelves	1
Required Assembly	Yes
Tools Recommended For Assembly	Screwdriver
Indoor Outdoor Usage	Indoor

7. Safety Information

Always assemble the table according to the provided instructions. Ensure the table is stable and secure before use, especially in areas where it may be subject to accidental impact or where small children or pets are present. Do not place heavy objects on the table that could cause it to tip over.

8. Customer Support

For any questions, concerns, or assistance with your ChooChoo Black End Table, please contact our customer service team. We are committed to providing quality service and support for our products.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question