Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VOPLLS M10

VOPLLS M10 Projector User Manual

Model: M10

1. Introduction

Thank you for choosing the VOPLLS M10 Projector. This manual provides essential information for setting up, operating, and maintaining your projector to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

Product Overview

The VOPLLS M10 is a versatile and compact projector designed for home cinema and outdoor use. It features 800 ANSI lumens, official Netflix licensing, Dolby Audio support, automatic focus and keystone correction, and supports 4K Full HD 1080P resolution. With WiFi6 and Bluetooth connectivity, it offers a seamless viewing experience.



Image 1.1: The VOPLLS M10 Projector showcasing its ability to display the Netflix interface directly.

2. Safety Instructions

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not block ventilation openings. Ensure adequate airflow around the projector.
- Do not expose the projector to rain or moisture to prevent fire or electric shock.
- Use only attachments/accessories specified by the manufacturer.
- Unplug the projector during lightning storms or when unused for long periods.
- Do not look directly into the projector lens when the lamp is on.

3. Product Components

Familiarize yourself with the main components of your VOPLLS M10 Projector:



Image 3.1: Key features and design elements of the VOPLLS M10 Projector, highlighting its compact form factor, official Netflix licensing, integrated 360° rotating stand, autofocus capabilities, and advanced connectivity options (WiFi 6 and Bluetooth 5.2).

- **Projector Lens:** Projects the image onto the screen.
- **Integrated 360° Rotating Stand:** Allows for flexible projection angles.
- **Ventilation Openings:** For heat dissipation.
- **Control Panel:** Buttons for basic operation.
- **Input Ports:** HDMI, USB, etc. (refer to specific port section).
- **Power Input:** For connecting the power adapter.

4. Setup Guide

4.1 Unpacking and Placement

1. Carefully remove the projector and all accessories from the packaging.
2. Place the projector on a stable, flat surface. Ensure it is positioned within the optimal projection distance from your screen or wall.
3. The projector is designed to be portable, weighing 0.79 kg and having a thickness of 2.24 inches, making it easy to carry.



Image 4.1: The VOPLLS M10 Projector's compact design, illustrating its portability for "cinema on the go."

4.2 Power Connection

1. Connect the power adapter to the projector's power input port.
2. Plug the power adapter into a suitable electrical outlet.
3. The power indicator light will illuminate.

4.3 Initial Power On and Focus Adjustment

1. Press the power button on the projector or remote control to turn it on.

2. The projector features automatic focus and keystone correction. It will automatically adjust the image clarity and shape.
3. The automatic obstacle avoidance feature helps ensure a clear projection area.



Image 4.2: The projector's automatic focus feature actively adjusting the image for optimal clarity.

5. Operating Instructions

5.1 Navigating the User Interface

The VOPLLS M10 Projector runs on an intelligent Linux operating system, providing a user-friendly interface for easy navigation.



Image 5.1: The user-friendly operating system interface, displaying various applications and system settings like WiFi screen mirroring and sound options.

5.2 Connecting Devices

The projector supports various connectivity options:

- **HDMI:** Connect laptops, game consoles (e.g., PS5), or other HDMI-enabled devices using an HDMI cable (included).
- **Wi-Fi (WiFi6):** Connect to your home network for online streaming and app access. Supports 2.4G and 5G WiFi.
- **Bluetooth (BT 5.2):** Connect external audio devices like Bluetooth speakers for enhanced sound.
- **Screen Mirroring:** Wirelessly mirror content from your smartphone (e.g., iPhone) or other compatible devices.



Image 5.2: The projector's wireless connectivity options, including Bluetooth 5.2 and dual-band WiFi (2.4G/5G), enabling seamless integration with other devices.

5.3 Using Built-in Applications

The VOPLLS M10 Projector comes with pre-installed applications, including officially licensed Netflix, YouTube, Prime Video, Max, and Hulu, providing a wide range of entertainment options.



Image 5.3: A selection of pre-installed applications available on the projector, offering a variety of streaming content.

The projector supports native 1080P resolution with 4K support, ensuring vivid colors and high contrast for a superior viewing experience.




Image 5.4: Visual comparison demonstrating the superior image quality of the VOPLLS M10's native 1080P with 4K support, showcasing high color gamut and contrast.

Experience immersive audio with Dolby Audio and 360° surround sound capabilities.



Image 5.5: Illustration of the Dolby Audio feature, providing immersive 3D surround sound from all angles.

6. Maintenance

6.1 Cleaning the Projector

- **Lens:** Use a soft, lint-free cloth specifically designed for optical lenses. Do not use abrasive cleaners.
- **Exterior:** Wipe the projector's exterior with a soft, dry cloth. For stubborn marks, slightly dampen the cloth with water.
- **Dust Filter:** The projector has a removable dust filter for easy cleaning. Regularly remove and clean it to maintain optimal performance.

6.2 Storage

When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. Use the original packaging or a protective case to prevent dust accumulation and damage.

The projector is designed for energy efficiency and long lifespan, with a 7-layer coated glass lens and LED light source contributing to energy savings.



Image 6.1: Illustration of the projector's energy-saving features, including its 7-layer coated glass lens and LED light source, designed for long-term durability and efficiency.

7. Troubleshooting

This section addresses common issues you might encounter with your VOPLLS M10 Projector. If the problem persists, please contact customer support.

Problem	Possible Cause	Solution
No image projected	Power cable loose; Projector not turned on; Input source incorrect.	Check power connection; Press power button; Select correct input source.
Image is blurry	Out of focus; Projector too close/far; Lens dirty.	Allow auto-focus to adjust; Adjust projector distance; Clean the lens.
No sound	Volume too low; External audio device not connected; Muted.	Increase volume; Check Bluetooth connection; Unmute audio.

Problem	Possible Cause	Solution
Remote control not working	Batteries dead; Obstruction between remote and projector.	Replace batteries; Ensure clear line of sight.

8. Specifications

Feature	Detail
Brand	VOPLLS
Color	Silver Gray
Product Type	Stationary
Connectivity	Wi-Fi, Bluetooth, HDMI
Special Features	Auto-focus and Keystone Correction, Smart Linux OS, Official Netflix License, Automatic Obstacle Avoidance, Dolby Audio
Compatible Devices	Laptop, Game Console, Smartphone, PS5
Display Resolution	1920 x 1080 (Native)
Maximum Display Resolution	3840 x 2160 Pixels (4K Support)
Display Type	LCD
Mounting Type	Ceiling Mount
Included Components	HDMI Cable
Recommended Uses	Home Cinema

9. Warranty Information

Specific warranty information for the VOPLLS M10 Projector is not provided in the product details. Please refer to the product packaging or the manufacturer's official website for detailed warranty terms and conditions.

10. Customer Support

If you encounter any issues or have questions regarding your VOPLLS M10 Projector that are not covered in this

manual, please contact VOPLLS customer support. Contact details are typically available on the product packaging or the official VOPLLS website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D2KCQJRY

More documents and user manuals: **https://manuals.plus/**