

[Manuals.plus](#) /

› [VINABTY](#) /

› VINABTY AR-RY12 Remote Control User Manual

VINABTY AR-RY12

VINABTY AR-RY12 Remote Control User Manual

Replacement Remote Control for Fujitsu Wall-Mounted Air Conditioners

PRODUCT OVERVIEW

This manual provides instructions for the VINABTY AR-RY12 replacement remote control, designed for use with various Fujitsu Wall-Mounted-Type Air Conditioners. It offers essential functions for controlling your air conditioning unit.





Image: Front view of the VINABTY AR-RY12 remote control. The remote is white with a dark grey display screen at the top. Below the screen are various control buttons, including a prominent orange 'START STOP' button, and buttons for 'MASTER CONTROL', 'FAN CONTROL', 'AIR CLEAN', 'COIL DRY', 'SLEEP', 'SET TEMP.', 'SET' (for fan speed), 'SWING', 'TIMER MODE', 'TIMER', 'CLOCK ADJUST', 'TEST RUN', and 'RESET'.

SETUP

Battery Installation

The AR-RY12 remote control requires two AAA batteries (not included) for operation.

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.

4. Close the battery compartment cover securely.

Note: Remove batteries if the remote control will not be used for an extended period to prevent leakage.

OPERATING INSTRUCTIONS

The AR-RY12 remote control provides intuitive access to your air conditioner's functions. The display shows temperature in Celsius.

Basic Operation

- **START STOP Button:** Press the **START STOP** button (orange) to turn the air conditioner ON or OFF.
- **SET TEMP. Buttons:** Use the **SET TEMP.** up (▲) and down (▼) arrows to adjust the desired temperature. The temperature is displayed in Celsius.

Mode and Fan Control

- **MASTER CONTROL Button:** Press this button to cycle through operating modes such as Auto, Cool, Dry, Fan, and Heat (if supported by your AC unit).
- **FAN CONTROL Button:** Press this button to adjust the fan speed (e.g., Auto, Low, Medium, High).
- **SET (Fan Speed) Button:** This button, often next to FAN CONTROL, may be used to confirm or fine-tune fan speed settings.

Advanced Functions

- **AIR CLEAN Button:** Activates the air purification function, if available on your air conditioner.
- **COIL DRY Button:** Initiates a coil drying function to prevent mold and mildew growth on the indoor unit's coil.
- **SLEEP Button:** Activates sleep mode, which typically adjusts temperature and fan speed for comfortable sleep and energy saving.
- **SWING Button:** Controls the vertical louver swing function, directing airflow.
- **TIMER MODE Button:** Used to set or cancel timer functions (e.g., On Timer, Off Timer).
- **TIMER Buttons (-/+):** Used in conjunction with TIMER MODE to adjust timer settings.
- **CLOCK ADJUST Button:** Used to set the current time on the remote's display.
- **TEST RUN Button:** For service or diagnostic purposes. Consult your air conditioner's manual before using.
- **RESET Button:** Resets the remote control to its default settings. This may require a pointed object to press.

MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the display becomes dim or the remote's range decreases. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Remote not responding	Dead or incorrectly installed batteries. Obstruction between remote and AC unit.	Replace batteries, ensuring correct polarity. Remove any obstructions. Point remote directly at the AC unit's receiver.
Display is dim or blank	Low battery power.	Replace batteries.
AC unit not responding to specific functions	Function not supported by your specific AC model. Remote out of sync.	Refer to your air conditioner's original manual for supported functions. Try pressing the RESET button on the remote.

SPECIFICATIONS

- **Model:** AR-RY12
- **Brand:** VINABTY
- **Compatible Devices:** Fujitsu Wall-Mounted-Type Air Conditioners (AR-RAH2U, ASU18RLF, ASU18RLXS, ASU24RLF, ASU24RLXS, ASU30RLX, AUU12RLF, AUU18RLF, AUU9RLF, and others)
- **Power Source:** 2 x AAA Batteries (not included)
- **Display Temperature Unit:** Celsius
- **Dimensions:** 6.7 x 2 x 0.7 inches (approximately)
- **Weight:** 2.3 ounces (without batteries)
- **Color:** White
- **Special Feature:** Ergonomic design

SUPPORT

For further assistance or inquiries regarding your VINABTY AR-RY12 remote control, please refer to the seller's contact information on the platform where the product was purchased. Ensure you have your product model number (AR-RY12) and purchase details ready.

For specific operational details of your Fujitsu Air Conditioner, please consult the original user manual provided with your air conditioning unit.



© 2024 VINABTY. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.