Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SNZ LL-8838D-42-03

SNZ 42 Inch Ceiling Fan with Lights and Remote/App Control

Model: LL-8838D-42-03

Brand: SNZ

SNZ Brand Logo

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your SNZ 42 Inch Ceiling Fan with Lights and Remote/App Control. Please read this manual thoroughly before installation and use to ensure proper function and safety.



Image: SNZ 42 Inch Ceiling Fan with Lights and Remote/App Control, showcasing its modern design and nickel finish.

The SNZ ceiling fan is designed for both indoor and outdoor (covered patio) use, featuring a quiet reversible DC motor, integrated dimmable LED lighting with adjustable color temperature, and multiple control options including a remote and a mobile application.

2. Safety Information

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these basic precautions:

- Read all instructions before installing the fan.
- Ensure the installation site is structurally sound and can support the fan's weight (approximately 11 pounds).
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- Disconnect power at the circuit breaker or fuse box before beginning installation or performing any maintenance.
- Do not operate the fan with damaged parts. Replace any damaged components immediately.
- Keep hands, feet, and other objects away from the rotating fan blades.
- This fan is suitable for indoor and covered outdoor use. Avoid direct exposure to rain or excessive moisture.

3. Package Contents

Verify that all components listed below are included in your package. If any parts are missing or damaged, contact customer service.

- 1 × Ceiling Fan with Integrated LED Light
- 1 × Remote Control
- 1 × Wall Control (for remote mounting)
- 2 × Downrods (4-inch and 8-inch options)
- 1 × Installation Manual
- Mounting Hardware Kit



Image: Exploded view of the SNZ ceiling fan, highlighting plywood blades, stable bracket, pure copper motor, and integrated light kit.

4. Specifications

Feature	Detail
Model Name	LL-8838D-42-03
Brand	SNZ
Size	42 Inch
Product Dimensions	42"D x 42"W x 16.9"H (Max Height: 16.9", Min Height: 13.0")
Color	Nickel
Number of Blades	5
Blade Length	16.55 Inches
Motor Type	Reversible DC Motor
Noise Level	Below 35 Decibels
Wattage	32 watts
Voltage	120 Volts
Air Flow Capacity	2980 Cubic Feet Per Minute
Control Method	Remote Control, Mobile App
Light Features	3 CCT Dimmable LED (3000K, 4000K, 6500K)
Special Features	Adjustable Height, Dimmable, LED Light, Remote Controlled, Timer, Memory Function
Indoor/Outdoor Usage	Indoor, Covered Outdoor




Image: Diagram showing the 42-inch fan dimensions, including maximum and minimum heights, and illustrating the double-sided blade options (Nickel and Oak).

5. Installation

The SNZ ceiling fan features a pre-assembled design for simplified installation. It is recommended to have two people for installation. Installation typically takes approximately 30 minutes.

5.1 Pre-Installation Checklist

- Ensure power is disconnected at the circuit breaker.
- Confirm you have all necessary tools (screwdriver, wire strippers, ladder, etc.).
- Verify all package contents are present.

5.2 Mounting the Bracket

1. Secure the mounting bracket to the ceiling junction box. Ensure the bracket is firmly attached and can support the

fan's weight.

2. For angled ceilings (up to 15 degrees), ensure the mounting bracket is installed correctly to accommodate the angle.

5.3 Assembling the Fan

3. Attach the chosen downrod (4-inch or 8-inch) to the fan motor assembly.
4. Carefully lift the fan assembly and hang it from the mounting bracket.
5. Connect the electrical wires according to the wiring diagram provided in the separate installation video and manual. Ensure all connections are secure.
6. Attach the fan blades to the motor housing. The blades are double-sided, allowing you to choose between Nickel and Oak finishes.
7. Secure the light kit to the fan assembly.



Image: Illustration emphasizing the ease of installation, noting that it comes with all necessary hardware and takes about 30 minutes.

6. Operation

Your SNZ ceiling fan can be controlled via the included remote control or a mobile application.



Image: A living room scene with the SNZ ceiling fan, illustrating control via both a physical remote and a smartphone app, highlighting features like dimmable CCT, 6 speeds, reversible DC motor, and timer.

6.1 Remote Control Functions

- **Power On/Off:** Turns the fan and light on or off.
- **Fan Speed:** Adjusts between 6 wind speed settings (1-2 for comfortable breeze, 3-4 for natural wind, 5-6 for strong wind).
- **Light On/Off:** Controls the LED light independently.
- **Color Temperature (CCT) Adjustment:** Cycles through 3 color temperatures (3000K Warm Light, 4000K Natural Light, 6500K White Light).
- **Dimming:** Adjusts light brightness from 10% to 100%.
- **Reversible Motor:** Changes fan direction for summer (downdraft) or winter (updraft) mode.
- **Timer:** Sets the fan to turn off after 2 or 4 hours.
- **Nightlight Mode:** Activates a low-level light setting.



Image: Visual representation of the dimmable LED light, showing 3 color temperatures (3000K, 4000K, 6500K) and brightness levels from 10% to 100%.

6.2 Mobile App Control

Download the SNZ control app from your device's app store. Follow the in-app instructions to pair your fan. The app provides all the functionalities of the remote control, including fan speed, light settings, timer, and reversible motor control.

6.3 Reversible DC Motor

The fan's reversible DC motor allows for year-round use:

- **Summer Mode (Downdraft):** Blades rotate counter-clockwise, pushing cool air down to create a cooling effect.
- **Winter Mode (Updraft):** Blades rotate clockwise, drawing cool air up and circulating warm air trapped near the ceiling.



Image: Diagram illustrating the downdraft mode for summer (blue arrows) and updraft mode for winter (orange arrows), demonstrating the reversible DC motor function.

6.4 Memory Function

The fan features a memory function that recalls your last used lighting settings (color temperature and brightness) when the light is turned back on.

7. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your fan.

7.1 Cleaning

- Always disconnect power before cleaning.
- Use a soft, damp cloth to clean the fan housing and blades. Do not use abrasive cleaners or solvents.

- Wipe the light cover with a soft, dry cloth.

7.2 General Care

- Periodically check all connections and screws for tightness.
- The DC motor is designed for long-term, maintenance-free operation and does not require lubrication.

8. Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power supply; Loose wiring; Remote control battery low.	Check circuit breaker; Ensure all wires are securely connected; Replace remote control batteries.
Light does not work	No power to light; Loose wiring; LED module failure.	Check power supply; Verify light wiring; Contact customer support if LED module is faulty.
Fan wobbles	Loose blades; Uneven blade balance; Loose mounting bracket.	Ensure all blade screws are tight; Use the included balancing kit; Tighten mounting bracket screws.
Remote control not working	Battery low/dead; Remote not paired; Obstruction.	Replace batteries; Refer to pairing instructions in the full manual; Ensure clear line of sight (if applicable).
Fan is noisy	Loose screws; Motor issue; Blades hitting an obstruction.	Check all screws; Ensure no obstructions; Contact customer support if motor noise persists.



Image: A person sleeping peacefully, illustrating the fan's ultra-quiet operation at below 35dB, ensuring minimal disturbance.

9. Warranty and Support

9.1 Warranty Information

Your SNZ ceiling fan is covered by a **2-Year Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.



Image: A shield icon indicating a 2-year warranty.

The warranty does not cover damage caused by improper installation, misuse, accidents, or unauthorized repairs. Proof of purchase is required for warranty claims.

9.2 Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact SNZ customer service. Our team provides professional after-sales support and is available for assistance.

- **Email:** [Insert Customer Service Email Here]
- **Phone:** [Insert Customer Service Phone Number Here]
- **Website:** Visit the SNZ Store on Amazon

© 2024 SNZ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D2KPB1G1

More documents and user manuals: **https://manuals.plus/**