

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [GOOJODOQ](#) /

› [GOOJODOQ GFS001 Portable High-Speed Fan User Manual](#)

## GOOJODOQ GFS001

# GOOJODOQ GFS001 Portable High-Speed Fan User Manual

Model: GFS001

## 1. INTRODUCTION

Thank you for purchasing the GOOJODOQ GFS001 Portable High-Speed Fan. This device is designed to provide powerful and adjustable airflow for personal cooling. Featuring a high-speed motor, a large-capacity battery, and precise wind speed control, it offers a convenient solution for various environments. Please read this manual thoroughly before use to ensure proper operation and maintenance.

## 2. SAFETY INFORMATION

- Do not insert fingers or foreign objects into the fan grille.
- Keep the fan away from water or other liquids to prevent electric shock.
- Do not disassemble, repair, or modify the fan yourself. Contact customer support if service is required.
- Keep out of reach of children.
- Avoid exposing the fan to extreme temperatures or direct sunlight for extended periods.
- Use only the provided Type-C charging cable or a certified equivalent.

## 3. PRODUCT OVERVIEW

Familiarize yourself with the components of your GOOJODOQ GFS001 fan.





Figure 3.1: Front view of the GOOJODOQ GFS001 Portable High-Speed Fan, showing the main body, air outlet, and control panel.

## Parts Identification:

1. **Air Outlet:** Where the airflow is directed.
2. **LED Digital Display:** Shows wind speed level and battery status.
3. **Power Button:** Turns the fan on/off.
4. **Wind Speed Adjustment Buttons (+/-):** Increases or decreases wind speed.
5. **Air Intake Grille:** Located at the rear, designed for safe air intake.
6. **Type-C Charging Port:** For charging the internal battery.
7. **Strap Hole:** For attaching the anti-loss strap.



Figure 3.2: Detailed view of the fan's features, including the power switch, Type-C charging port, strap hole, and ergonomic body design.

# 風速表示LEDディスプレイ

LEDデジタル画面に風速ギアとバッテリー残量が表示されて、速度調整や電池残量をリアルタイムで確認できて便利です。



Figure 3.3: Close-up of the LED digital display, indicating current air volume level and battery charge status.

## 4. SETUP

### 4.1 Unboxing

Carefully remove all components from the packaging. Ensure the following items are present:

- GOOJODOQ GFS001 Portable High-Speed Fan
- USB Type-C Charging Cable
- Anti-loss Strap
- User Manual (this document)

### 4.2 Initial Charging

Before first use, fully charge the fan's internal battery.

1. Connect the Type-C end of the charging cable to the fan's charging port.
2. Connect the USB-A end of the charging cable to a compatible USB power adapter (e.g., wall charger, computer USB port, power bank).
3. The LED display will indicate charging status. A full charge typically takes 2-3 hours.
4. Once fully charged, disconnect the charging cable.

# 大容量バッテリー & Type-C充電

大容量バッテリーで長時間使用可能、Type-C高速充電で2時間に満充電でき、頻繁に充電する必要はありません。



2-3H

通常充電時間



2H

最大風速100レベルの連続作業時間



10H

通常使用20レベル風速の連続作業時間



12H以上

1レベル風速の連続作業時間



Figure 4.1: Illustration of the fan's 4000mAh battery and Type-C charging connection.

## 5. OPERATING INSTRUCTIONS

### 5.1 Power On/Off

- To turn on: Press and hold the Power Button for approximately 2 seconds. The LED display will light up.
- To turn off: Press and hold the Power Button for approximately 2 seconds. The LED display will turn off.

### 5.2 Adjusting Wind Speed

The fan offers 100 levels of wind speed adjustment.

- **Quick Adjustment:** Short press the '+' or '-' button to adjust the wind speed by 20 levels at a time.
- **Fine Adjustment:** Long press the '+' or '-' button for stepless adjustment, changing the wind speed by 1 level at a time.

# 1-100段階風速調整

1から100段階風速を自由に細かく調整可能



短く押すごとに風速が20  
レベルずつに増加/減少する



長押しすると、1レベルずつに  
無段階風速を調整可能

風速 " + "

風速 " - "



Figure 5.1: Location of the wind speed adjustment buttons (+ and -) on the fan body.

## 5.3 LED Digital Display

The LED display provides real-time information:

- **Wind Speed Level:** Indicates the current airflow intensity from 1 to 100.
- **Battery Level:** Shows the remaining battery charge.

## 6. MAINTENANCE

### 6.1 Cleaning

- Ensure the fan is turned off and disconnected from any power source before cleaning.
- Wipe the exterior of the fan with a soft, dry cloth.
- Use a soft brush or cotton swab to gently clean any dust from the air intake grille and air outlet. Do not use water or abrasive cleaners.

### 6.2 Storage

When not in use for an extended period, store the fan in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to charge the battery to about 50% before storage to prolong battery life.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan using the provided Type-C cable.
Weak or no airflow.	Air intake or outlet is blocked; low battery.	Check for obstructions and clean grilles. Charge the fan.
Fan not charging.	Cable or adapter issue; charging port dirty.	Ensure cable and adapter are working. Clean the charging port gently.
LED display not working.	Fan is off; internal malfunction.	Turn on the fan. If issue persists, contact customer support.

If the problem persists after attempting these solutions, please contact GOOJODOQ customer support.

## 8. SPECIFICATIONS

Feature	Detail
Brand	GOOJODOQ
Model Number	GFS001
Motor Speed	Up to 15000 RPM
Battery Capacity	4000 mAh
Charging Port	USB Type-C
Charging Time	Approx. 2-3 hours
Continuous Use Time	Up to 12 hours (at lowest speed)
Wind Speed Levels	1-100 (adjustable)
Display	LED Digital Display (wind speed, battery)
Product Dimensions	16 cm (Depth) x 6.1 cm (Width) x 5.9 cm (Height)
Weight	Approx. 200g
Color	Gray

## 9. WARRANTY AND SUPPORT

### 9.1 Quality Warranty

This product comes with a **6-month quality warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

## 9.2 Customer Support

If you encounter any problems with your GOOJODOQ GFS001 fan or have questions not covered in this manual, please do not hesitate to contact our customer support team. Please have your purchase details and model number (GFS001) ready when contacting support.

### Contact Information:

- Email: [support@goojodoq.com](mailto:support@goojodoq.com) (Example, replace with actual if available)
- Website: [www.goojodoq.com](http://www.goojodoq.com) (Example, replace with actual if available)