

FUNTOK R05A

FUNTOK 12V 7AH Kids Ride-On Truck Instruction Manual

Model: R05A

1. INTRODUCTION

Thank you for purchasing the FUNTOK 12V 7AH Kids Ride-On Truck. This manual contains important information regarding the assembly, operation, and maintenance of your new ride-on vehicle. Please read it thoroughly before use and retain it for future reference. Ensure all users understand the safety guidelines and operating procedures.

2. SAFETY INFORMATION

The FUNTOK 12V 7AH Kids Ride-On Truck is designed with safety in mind and is CPSC and ASTM certified. However, adult supervision is always required during operation to prevent accidents and ensure safe use. Please observe the following safety guidelines:

- Always ensure the child wears a safety helmet and appropriate protective gear.
- The vehicle is intended for children aged 3-8 years and a maximum weight of 66 lbs (30 kg).
- Operate the vehicle only on flat, dry surfaces away from traffic, swimming pools, or other hazards.
- Do not allow children to operate the vehicle near stairs, steep inclines, or uneven terrain.
- Ensure the seatbelt is securely fastened before each use.
- The remote control features a STOP function for immediate vehicle halt by an adult.
- Keep hands, feet, and clothing away from moving parts.
- Do not modify the vehicle or its electrical system.

No specific Proposition 65 warning is applicable to this product.

3. WHAT'S IN THE BOX

Upon unpacking, please verify that all components are present:

- Kids Ride On Truck (main body and parts)
- Parent Remote Control
- User Manual (this document)
- Charger



Image: Overview of key components including the 12V 7AH battery and dual 35W motors.

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately one hour. Follow the detailed instructions provided in the included assembly guide. Ensure all screws and fasteners are tightened securely. A second person may be helpful during certain steps.

Key Assembly Steps:

1. Attach the wheels to the axles, ensuring proper alignment and securing with provided hardware.
2. Install the steering wheel, connecting any necessary electrical wires.
3. Secure the seat to the vehicle chassis.
4. Connect the main power cable to the battery (often found zip-tied in the battery compartment).
5. Install any decorative elements such as mirrors or roll bars.



Image: The assembled ride-on truck with a child operating it, demonstrating the smooth start feature.

5. CHARGING THE BATTERY

The vehicle is powered by a 12V 7AH rechargeable battery. For optimal performance and battery longevity, follow these charging instructions:

- Before first use, charge the battery for a full 8-12 hours. Do not exceed 18 hours.
- To charge, locate the charging port (usually near the dashboard or under the seat).
- Plug the charger into a standard wall outlet, then connect the charger's plug to the vehicle's charging port.
- The charger will typically have an indicator light to show charging status (e.g., red for charging, green for fully charged).
- After each use, recharge the battery for 8-12 hours.
- Do not leave the battery charging unattended for extended periods.
- If the vehicle will not be used for an extended period, charge the battery fully every 30 days to maintain its health.

6. OPERATING INSTRUCTIONS

The FUNTOK Ride-On Truck offers two modes of operation: manual driving by the child and remote control by an adult.

6.1. Manual Driving

- Ensure the vehicle is turned on using the main power switch.
- The child can press the foot pedal to accelerate and release it to brake.
- The steering wheel controls the direction of the vehicle.
- The vehicle features a soft start system for gradual acceleration.

Child-friendly Design



Image: A child independently driving the ride-on truck, showcasing the child-friendly design and spacious seat.

6.2. Remote Control Operation

The 2.4GHz remote control allows parents to guide the vehicle and intervene for safety.

- **Pairing:** Turn on the vehicle and the remote control. Follow the specific pairing instructions in the separate remote control manual if provided. Typically, hold a pairing button on the remote until an indicator light flashes, then turn on the vehicle.
- **Controls:** Use the joystick or directional buttons for forward, reverse, left, and right.
- **Speed Settings:** The remote allows selection of 3 speeds (e.g., 1.86 mph, 2.5 mph, 3.2 mph).
- **STOP Function:** Press the 'P' or 'STOP' button on the remote to immediately halt the vehicle for safety.



Image: A hand operating the remote control, which allows adult supervision and control over the vehicle.

6.3. Multimedia Functions

The vehicle includes built-in music and Bluetooth connectivity.

- **Built-in Music:** Press the music button on the dashboard to play pre-loaded tunes.

- **Bluetooth Connectivity:** To connect a device, turn on the vehicle and enable Bluetooth on your smartphone or tablet. Search for the device name (e.g., 'YJ-BTcar') and pair. You can then play audio through the vehicle's speakers.
- **USB Port:** A USB port may be available for playing music from a USB drive.



Image: The vehicle's dashboard with controls for music and Bluetooth, allowing for audio playback during operation.

7. FEATURES OVERVIEW

The FUNTOK Ride-On Truck is equipped with several features for an engaging and safe experience:

- **Power System:** Features an upgraded 12V 7AH rechargeable battery and dual 35W motors.
- **Run Time:** Provides approximately 1-2 hours of continuous playtime on a full charge.
- **Speed Settings:** Offers 3 adjustable speeds via remote control, with a maximum speed of 3.2 mph.
- **Suspension:** Equipped with spring suspension for a smoother ride over varied terrains.
- **Soft Start System:** Ensures gradual acceleration to prevent sudden jolts.
- **Safety Features:** Includes an adjustable seatbelt, non-slip wheels, and a sturdy frame.
- **Lighting:** Features functional LED lights for enhanced visibility and realism.
- **Seating:** A spacious 15-inch wide seat provides comfort for the child.
- **Terrain Capability:** Designed to operate smoothly on various surfaces including grass, dirt, gravel, and asphalt.



Image: The ride-on truck being driven on grass, illustrating its capability on various terrains and showing the three speed settings.

8. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your ride-on truck.

- **Cleaning:** Wipe the vehicle with a soft, damp cloth. Do not use abrasive cleaners or solvents. Avoid spraying water directly onto electrical components.
- **Battery Care:** Always recharge the battery after each use. If storing for extended periods, charge monthly. Do not allow the battery to fully discharge for long durations.
- **Storage:** Store the vehicle in a dry, cool place away from direct sunlight and moisture.
- **Inspections:** Periodically check all screws, nuts, and bolts to ensure they are tight. Inspect wheels and tires for wear.

9. TROUBLESHOOTING

If you encounter issues with your FUNTOK Ride-On Truck, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vehicle does not move	Battery not charged; Power cable disconnected; Blown fuse; Motor issue	Charge battery; Connect power cable; Check/replace fuse; Contact support
Short run time	Battery not fully charged; Old/damaged battery; Overloaded vehicle	Ensure full charge; Replace battery; Reduce load

Problem	Possible Cause	Solution
Remote control not working	Remote batteries low/dead; Not paired; Interference	Replace remote batteries; Re-pair remote; Move away from interference sources
Lights not working	Loose connection; Damaged LED; Separate battery for lights (e.g., roll bar lights)	Check connections; Contact support; Check for separate battery compartments (e.g., on roll bar for rear lights)
Bluetooth not connecting	Incorrect device name; Bluetooth off on vehicle/device; Pairing issue	Verify device name (e.g., 'YJ-BTcar'); Ensure Bluetooth is active on both; Try re-pairing

10. SPECIFICATIONS

Detailed specifications for the FUNTOK 12V 7AH Kids Ride-On Truck:

- **Model Number:** R05A
- **Product Dimensions:** 39.57 x 23.62 x 24.02 inches
- **Item Weight:** 30.7 pounds
- **Battery:** 12V 7AH rechargeable battery (included)
- **Motors:** Dual 35W motors
- **Recommended Age:** 3 - 8 years
- **Maximum Load Capacity:** 66 lbs (30 kg)
- **Maximum Height:** 42 inches
- **Manufacturer:** FUNTOK
- **Certifications:** CPSC, ASTM



Image: A child next to the ride-on truck, illustrating the vehicle's dimensions and indicating recommended age and weight limits.

11. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact FUNTOK customer support directly. If you have any questions, require assistance with assembly, or need troubleshooting help not covered in this manual, please reach out to the manufacturer's customer service department.

Contact information can typically be found on the product packaging or the official FUNTOK website.