

[Manuals.plus](#) /

› [Livofloral](#) /

› Livofloral Large Printer Stand with Power Outlet and Storage Shelf Instruction Manual

Livofloral B0D2L1L4YS

Livofloral Large Printer Stand Instruction Manual

Model: B0D2L1L4YS

IMPORTANT SAFETY INFORMATION

- Ensure all parts are securely fastened before use.
- Do not overload the stand beyond its weight capacity.
- Keep electrical components (power outlets, USB ports) away from liquids.
- Use on a level surface to prevent tipping.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. Refer to the included parts list in your packaging for specific quantities.

- Desktop panel
- Shelf panels (various sizes)
- Steel frame components
- Sliding shelf with wheels
- Power outlet unit with USB ports
- Adjustable feet
- Assembly hardware (screws, Allen wrench, etc.)

ASSEMBLY INSTRUCTIONS

Follow the numbered instructions provided in your product packaging. All parts are numbered for easy identification. Use the tools provided for assembly.

1. **Unpack and Identify Parts:** Lay out all components and hardware. Match them against the parts list.
2. **Assemble Frame:** Begin by connecting the main steel frame components. Do not fully tighten screws until the entire frame is loosely assembled.

3. **Install Shelves:** Secure the desktop and other shelf panels to the frame. Ensure proper alignment of all holes.
4. **Attach Power Outlet:** The charging post can be mounted on either the left or right side of the stand as per your preference. Secure it firmly.
5. **Install Sliding Shelf:** Attach the sliding shelf with its wheels to the designated lower section. Ensure it slides smoothly.
6. **Attach Adjustable Feet:** Screw in the adjustable feet to the bottom of the stand. If using, ensure any locking wheels are positioned correctly.
7. **Final Tightening:** Once all components are in place and aligned, fully tighten all screws.



Figure 1: Overall dimensions of the Livofloral Printer Stand.



Whole Board



Smooth Handrail




Metal Mesh Shelf



2 Tier Shelves



Sliding Shelf




Adjustable Feet

Figure 2: Detailed view of the whole board, smooth handrail, metal mesh shelf, two-tier shelves, sliding shelf, and adjustable feet.



120V/12A
(2 AC Outlets)



5V/2A
(2 USB)



6.5 FT
(Power Cord)

Figure 3: Integrated power outlet with 2 AC outlets and 2 USB ports, featuring a 6.5 ft power cord.

OPERATION

The Livofloral Printer Stand is designed for versatile use in home and office environments.

- **Power Outlets:** Utilize the integrated 2 AC outlets (120V/12A) and 2 USB ports (5V/2A) to power your printer, shredder, mobile devices, or other electronics directly from the stand.
- **Multi-purpose Storage:** The large desktop accommodates printers, scanners, or other office machines. The multi-level storage dividers and metal mesh shelf provide space for documents, stationery, and office supplies.
- **Sliding Shelf:** The bottom sliding shelf is ideal for housing a shredder or other items that require occasional access. Its wheels allow for easy pull-out and push-in functionality.
- **Versatile Placement:** This stand can function as a printer stand, computer host stand, file organizer, shredder stand, or even a microwave stand, adapting to various needs.



Figure 4: The printer stand in use, showcasing a printer on top and a shredder on the sliding shelf.



Figure 5: The printer stand organized with various office devices and accessories.

MAINTENANCE

Proper care will ensure the longevity and appearance of your Livofloral Printer Stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.

- **Spills:** Promptly clean any spills to prevent damage to the engineered wood.
- **Fasteners:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Environment:** Avoid placing the stand in direct sunlight or near heat sources to prevent material degradation.

TROUBLESHOOTING

If you encounter issues, refer to the following common solutions:

- **Difficulty during Assembly:** If parts do not align or fit correctly, re-check the instruction manual and part numbers. Ensure screws are not fully tightened until all components are loosely assembled, allowing for minor adjustments.
- **Sliding Shelf Handles Detaching:** Ensure the handles are fully inserted into their designated holes. When pulling the shelf, apply even and gentle force.
- **Wheels Not Rolling Smoothly on Carpet:** The included wheels are designed for general use. For optimal mobility on thick carpets, consider replacing them with casters specifically designed for carpeted surfaces. Ensure wheel locks are disengaged.
- **Power Outlets Not Working:** Verify the stand's main power cord is securely plugged into a functional wall outlet. Check for any tripped circuit breakers.

SPECIFICATIONS

Feature	Detail
Model Number	B0D2L1L4YS
Dimensions (L x W x H)	23.62 x 18.89 x 30.31 inches
Weight	22 Pounds
Material	Engineered Wood, Powder-Coated Steel
AC Outlets	2 (120V/12A)
USB Ports	2 (5V/2A)
Power Cord Length	6.5 FT
Mounting Type	Floor Stand
Color	Rustic Brown

CUSTOMER SUPPORT

For any questions regarding assembly, operation, or parts, please contact Livofloral customer support. We are committed to assisting you within 24 hours.

Please refer to your purchase documentation for specific contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question