

Ordtop i13

Ordtop i13 Wireless Earbuds User Manual

Model: i13

INTRODUCTION

Thank you for choosing the Ordtop i13 Wireless Earbuds. This manual provides detailed instructions for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual carefully before use and retain it for future reference.

PACKAGE CONTENTS

- Ordtop i13 Wireless Earbuds (L/R)
- Charging Case
- USB Charging Cable (Type-C, typically)
- Multiple Sizes of Ear Tips
- User Manual

PRODUCT OVERVIEW

The Ordtop i13 Wireless Earbuds are designed for comfort and high-quality audio, featuring Bluetooth 5.3 connectivity, IP7 waterproofing, and intuitive touch controls.



Image: Ordtop i13 Wireless Earbuds and Charging Case. This image displays the earbuds in their charging case, highlighting their compact design.

Key Features

- **Advanced Bluetooth 5.3:** Ensures stable connection, longer transmission range, and lower power consumption.
- **Hi-Fi Stereo Deep Bass:** Equipped with 13mm dynamic drivers for powerful bass and clear treble.
- **Crystal-clear Calls:** Enhanced microphones effectively block out 85% of background noise, making your voice clearer.
- **IP7 Waterproof:** Provides protection against rain, sweat, and splashes, suitable for various activities.
- **Dual LED Power Display:** Shows remaining battery capacity for both earbuds and the charging case.
- **Smart Touch Control:** Manage music, calls, and voice assistant with simple taps.
- **Ergonomic Design:** Super light (3.8g per earbud) and mini for a comfortable and secure fit.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case.
2. Connect the USB charging cable to the charging port on the case and to a power source.
3. The LED display on the case will show the charging status. A full charge for the case takes approximately 1.5 hours.

Dual LED Power Display

It does enable you to take a quick look at the current remaining capacity and for easier tracking and recharging



Power display of
earbud(L/R)



Power display of
the case



8 hrs

Single Charge

40 hrs

Charging Case

1.5 hrs

Quickly Charged

Image: Dual LED Power Display and Battery Life. This image illustrates the LED display on the charging case showing battery percentages for both earbuds and the case, along with battery life details.

2. Initial Pairing

The earbuds feature one-step pairing for convenience.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "i13" in the list of available Bluetooth devices and select it to connect.
4. Once connected, the earbuds will automatically pair with your device when you open the case for future use.

One Step Pairing

After the first pairing, the earbud auto pairs with your phone while opening the case



Image: One Step Pairing Process. This image shows the earbuds in their case and a smartphone screen displaying the Bluetooth pairing menu, with "i13" listed as a discoverable device.

OPERATING INSTRUCTIONS

Smart Touch Controls

The Ordtop i13 earbuds utilize touch sensors for various functions. The touch control area is located on the outer surface of each earbud.

Smart Touch Control



Image: Smart Touch Control Functions. This image displays the touch-sensitive areas on the earbuds and lists various touch commands for functions like Siri, Answer/Reject calls, Volume control, Next/Previous track, and Play/Pause.

Function	Action
Power On/Off	Automatically on when opening case, off when closing case. Long press touch area to manually power on/off.
Play/Pause Music	Single tap on either earbud.
Next Track	Double tap on the right earbud.
Previous Track	Double tap on the left earbud.
Volume Up	Triple tap on the right earbud.
Volume Down	Triple tap on the left earbud.
Answer/End Call	Single tap on either earbud during an incoming call or active call.
Reject Call	Long press on either earbud during an incoming call.

Function	Action
Activate Voice Assistant (Siri)	Long press on either earbud (when not on a call).

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently remove any earwax or debris from the ear tips and speaker mesh using a small brush or cotton swab.

Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid storing in extreme temperatures (hot or cold) or high humidity.

Water Resistance (IP7)

The earbuds are IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for 30 minutes. This makes them suitable for workouts and light rain.

IP-X7 Waterproof

Provide seal protection for your music life



Rainy Day

Sweat Resistance

Splashproof

Image: IP-X7 Waterproof Features. This image highlights the IP-X7 waterproof rating, indicating resistance to rainy days, sweat, and splashes.

Note: The charging case is not waterproof. Do not expose the charging case to water or moisture.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing with device	<ul style="list-style-type: none">◦ Ensure earbuds are charged and out of the case.◦ Turn off and on Bluetooth on your device.◦ Forget "i13" from your device's Bluetooth list and try pairing again.◦ Ensure earbuds are not connected to another device.

Problem	Possible Solution
Only one earbud working	<ul style="list-style-type: none"> Place both earbuds back into the charging case, close the lid, then open it again. Ensure both earbuds are charged. Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise, re-pair).
No sound or low volume	<ul style="list-style-type: none"> Check the volume level on both your device and the earbuds. Ensure earbuds are properly connected. Clean any debris from the earbud speaker mesh.
Charging case not charging	<ul style="list-style-type: none"> Ensure the charging cable is securely connected to both the case and the power source. Try a different USB cable or power adapter.
Poor call quality	<ul style="list-style-type: none"> Ensure earbuds are clean and positioned correctly. Move closer to your connected device to avoid interference. Check for any obstructions between the earbuds and your mouth.

SPECIFICATIONS

Feature	Detail
Model Number	i13
Brand	Ordtop
Connectivity Technology	Wireless
Wireless Technology	Bluetooth 5.3
Earbud Placement	In-Ear
Form Factor	In-Ear
Noise Control	Active Noise Suppression
Control Type	Touch Control
Earbud Weight	3.8 grams (single earbud)
Water Resistance Level	IP7 (Waterproof)
Average Battery Life (Earbuds)	8 hours (single charge)
Average Battery Life (with Case)	48 hours total
Charging Case Battery Capacity	350 mAh

Feature	Detail
Charging Time (Case)	1.5 hours
Frequency Range	20 Hz - 20,000 Hz
Compatible Devices	Bluetooth-enabled devices
Internal Material	Plastic
Case Dimensions (L x W x H)	2 cm x 4 cm x 5 cm
Case Weight	35 grams

WARRANTY AND SUPPORT

Ordtop products are designed for reliability and performance. For warranty information, please refer to the documentation included with your purchase or contact Ordtop customer support.

If you encounter any issues or have questions not covered in this manual, please contact our customer support team through the retailer's platform or the official Ordtop website for assistance.