

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ordtop](#) /
- › [Ordtop i13 Wireless Earbud Bluetooth 5.4 Headphones User Manual](#)

Ordtop i13

Ordtop i13 Wireless Earbud Bluetooth 5.4 Headphones User Manual

Model: i13

INTRODUCTION

Welcome to the user manual for your Ordtop i13 Wireless Earbud Bluetooth 5.4 Headphones. This guide provides essential information to help you get started, operate, and maintain your earbuds for optimal performance. Please read this manual thoroughly before using the product.

PACKAGE CONTENTS

Upon opening your Ordtop i13 package, you should find the following items:

- 2x Earbuds (Left and Right)
- 1x Lightweight Charging Case
- 1x USB-C Charging Cable
- 3x Pairs of Ear Caps (Sizes S/M/L)



Figure 1: Contents of the Ordtop i13 package, including earbuds, charging case, USB-C cable, and ear tips.

PRODUCT OVERVIEW

Components and Audio Features

The Ordtop i13 earbuds consist of two individual earbuds (left and right) and a portable charging case. They feature

a 13mm dynamic driver for rich audio output and integrated microphones with Environmental Noise Cancellation (ENC) for clear calls.



Figure 2: Ordtop i13 Wireless Earbuds and Charging Case.

Dual LED Power Display

It does enable you to take a quick look at the current remaining capacity and for easier tracking and recharging



Power display of earbud(L/R)



Power display of the case



8 hrs
Single Charge

40 hrs
Charging Case

1.5 hrs
Quickly Charged

Figure 3: Hi-Fi Stereo Sound and ENC Noise Reduction Microphones.

Touch Controls

The earbuds are equipped with smart touch controls for easy management of music, calls, and voice assistant functions. The touch sensitive area is located on the outer surface of each earbud.

One Step Pairing

After the first pairing, the earbud auto pairs with your phone while opening the case




Figure 4: Smart Touch Control functions.

- **Play/Pause:** Single tap on either earbud.
- **Next Song:** Long tap on the Right earbud for 1 second.
- **Previous Song:** Long tap on the Left earbud for 1 second.
- **Volume Up:** Double tap on the Right earbud.
- **Volume Down:** Double tap on the Left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long tap on either earbud.
- **Activate Voice Assistant (Siri):** Triple tap on either earbud.
- **Power On/Off:** Long tap on either earbud (specific duration may vary, typically 3-5 seconds).

SETUP

Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case features an LED display to

indicate the battery level of the case and individual earbuds.


1. Place the earbuds into the charging case. Ensure they are correctly seated to initiate charging.
2. Connect the USB-C charging cable to the charging port on the case and plug the other end into a USB power source (e.g., wall adapter, computer USB port).
3. The LED display on the case will show the charging status. A full charge for the case typically takes about 1 hour, providing up to 40 hours of total playtime with the earbuds. Earbuds provide approximately 8 hours of continuous use per charge.



13mm Dynamic Driver

Hi-Fi Stereo Deep Bass
13mm speaker produce powerful bass and stunning streble

Crystal-clear Calls
The enhanced microphones can effectively block out 85% of background noise and make your voice 3 times clearer



Before Noise Reduction **After Noise Reduction**

Figure 5: Dual LED Power Display on the charging case.

Pairing with a Device

The Ordtop i13 earbuds utilize advanced Bluetooth 5.4 technology for a stable and efficient connection, ensuring lower latency and longer transmission range.

Upgraded Bluetooth 5.4 Technology

Dual-channel transmission creates an unbreakable connection



Figure 6: Bluetooth 5.4 Technology benefits.

1. First-time Pairing:

- Open the charging case. The earbuds will automatically enter pairing mode.
- On your device (smartphone, tablet, laptop, etc.), enable Bluetooth and search for available devices.
- Select "i13" from the list of detected devices to connect.
- Once connected, you will hear an audible confirmation, and the earbuds will be ready for use.

2. **Automatic Reconnection:** After the initial pairing, the earbuds will automatically connect to the last paired device when you open the charging case, provided Bluetooth is enabled on your device.

3. **Single Earbud Use:** Either earbud can be used independently. Simply take one earbud out of the case, and it will connect to your device.

IP-X7 Waterproof

Provide seal protection for your music life



Rainy Day



Sweat Resistance



Splashproof

Figure 7: One-step pairing process.

OPERATING INSTRUCTIONS

Wearing the Earbuds

Choose the ear tips that provide the most comfortable and secure fit for your ears. A proper fit is crucial for optimal sound quality and noise isolation.



Figure 8: Proper earbud fit and ear tip selection.

Audio Playback

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Long tap on the Right earbud.
- **Previous Track:** Long tap on the Left earbud.
- **Volume Up:** Double tap on the Right earbud.
- **Volume Down:** Double tap on the Left earbud.

Call Management

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long tap on either earbud.

Voice Assistant

- **Activate Voice Assistant (Siri, Google Assistant, etc.):** Triple tap on either earbud.

MAINTENANCE

Cleaning

Regular cleaning helps maintain sound quality and hygiene.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water if necessary. Ensure they are completely dry before

reattaching.

- Use a dry cotton swab to carefully clean the mesh and charging contacts on the earbuds and inside the case.

Water Resistance (IP7 Rating)

The Ordtop i13 earbuds are rated IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. This makes them suitable for sports and protection against sweat and rain. However, the charging case is not waterproof. Avoid exposing the charging case to water.



Figure 9: IP7 Waterproof rating for earbuds.

Storage

When not in use, store the earbuds in their charging case to protect them and ensure they remain charged. Store the case in a cool, dry place away from extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Earbuds not pairing/connecting.	Bluetooth is off on device, earbuds not in pairing mode, or previously paired to another device.	Ensure Bluetooth is enabled. Place earbuds in case, close, then open to re-enter pairing mode. Forget "i13" from your device's Bluetooth list and re-pair.
No sound from one or both earbuds.	Low battery, earbud not properly seated, or connection issue.	Check battery levels. Ensure earbuds are clean and properly seated in the case. Reconnect to your device.
Charging case not charging.	Faulty cable or power source.	Try a different USB-C cable and power adapter. Ensure the cable is securely connected.
Poor sound quality or dropped connection.	Distance from device, interference, or improper earbud fit.	Move closer to your device. Avoid environments with strong wireless interference. Adjust earbud fit and try different ear tips.

SPECIFICATIONS

Feature	Detail
Model Name	i13
Brand	Ordtop
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Bluetooth Range	Up to 15 meters
Audio Driver Size	13 mm Dynamic Driver
Noise Control	Environmental Noise Cancellation (ENC)
Earbud Battery Life	Up to 8 hours (single charge)
Total Playtime (with case)	Up to 40 hours
Charging Time (Case)	Approximately 1 hour
Charging Port	USB-C
Water Resistance	IP7 (earbuds only)
Control Method	Touch Control
Earbud Weight	3.8 grams (single earbud)
Included Components	Earbuds, Charging Case, USB-C Cable, 3x Ear Caps (S/M/L)

WARRANTY AND SUPPORT

Warranty Information

