

Manuals.plus /

> plplaaoo /

> plplaaoo Cordless Table Lamp User Manual

plplaaoo B0D2LG61MQ

plplaaoo Cordless Table Lamp User Manual

Model: B0D2LG61MQ

1. INTRODUCTION

Thank you for purchasing the plplaaoo Cordless Table Lamp. This manual provides essential information for the safe and efficient operation of your new lamp. Please read it thoroughly before use and retain it for future reference.

2. SAFETY INSTRUCTIONS

- Do not expose the lamp to water or excessive moisture.
- Avoid disassembling or modifying the lamp, as this may void the warranty and pose safety risks.
- Use only the provided USB Type-C cable for charging.
- Keep the lamp away from heat sources and direct sunlight to prevent battery damage.
- Ensure the lamp is placed on a stable, flat surface to prevent tipping.
- This lamp is designed for indoor use only.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Cordless Table Lamp
- 1 x USB Type-C Charging Cable







Image: USB Type-C Charging Cable. This cable is included for charging your lamp.

4. PRODUCT OVERVIEW

The plplaaoo Cordless Table Lamp features a sleek design with a durable iron, aluminum, and acrylic construction. It includes a built-in 2000mAh rechargeable lithium battery, offering 10-15 hours of working time on a full charge. The lamp provides three light sources: white light, warm light, and ordinary light, with adjustable brightness up to 150lm.



Image: Three plplaaoo Cordless Table Lamps. The lamps are available in various finishes, showcasing their elegant design.

LED Table Lamp

Built in 2000mAh rechargeable lithium battery
10-15 hours working time



Image: Single plplaaoo Cordless Table Lamp. This image highlights the lamp's rechargeable battery and extended working time.

5. SETUP

Initial Charging

Before first use, fully charge the lamp. Connect the provided USB Type-C cable to the charging port on the lamp's base and plug the other end into a compatible USB power adapter (not included).

1. Locate the USB Type-C charging port on the base of the lamp.
2. Insert the USB Type-C cable into the lamp's charging port.
3. Connect the USB-A end of the cable to a standard USB power adapter (e.g., phone charger, computer USB port).
4. The charging indicator (if present) will show the charging status. Allow several hours for a full charge.

6. OPERATING INSTRUCTIONS

Power On/Off and Brightness Adjustment

The lamp features both a bottom switch and a top touch control for operation.

1. **Bottom Switch:** Flip the switch on the bottom of the lamp to the 'ON' position to enable the touch control function.
2. **Top Touch Control:** Gently touch the top surface of the lamp to cycle through the three light modes: white light, warm light, and ordinary light. Continue touching to adjust brightness levels within each mode.
3. To turn off the lamp, either cycle through all light modes until it turns off via touch control, or flip the bottom switch to the 'OFF' position.



Image: Three plplaaoo Cordless Table Lamps illuminated. This demonstrates the different light modes available.



Image: plplaaoo Cordless Table Lamp with white light. One of the available light modes.



Image: p|plaaoo Cordless Table Lamp with warm light. Another available light mode.



Image: plplaaoo Cordless Table Lamp with ordinary light. The third available light mode.

7. MAINTENANCE

- **Cleaning:** Wipe the lamp with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the lamp in a cool, dry place. Ensure the battery is partially charged before storage to prolong its lifespan.
- **Battery Care:** To maintain battery health, avoid completely draining the battery frequently. Recharge the lamp when the light output becomes noticeably dim.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted. Bottom switch is off.	Charge the lamp using the USB Type-C cable. Ensure the bottom switch is in the 'ON' position.
Light is dim or flickers.	Low battery.	Recharge the lamp.
Cannot change light mode/brightness.	Bottom switch is off. Touch control malfunction.	Ensure the bottom switch is 'ON'. Try restarting the lamp by turning the bottom switch off and on again.
Lamp does not charge.	Faulty cable or adapter. Charging port issue.	Try a different USB Type-C cable and power adapter. Ensure the cable is fully inserted.

9. SPECIFICATIONS

Feature	Detail
Model	B0D2LG61MQ
Material	Iron, Aluminum, Acrylic
Height	Approx. 28.5cm / 11.2in
Diameter	Approx. 13cm / 5.1in
Weight	Approx. 0.66 kg / 23.4 oz
Built-in Battery	Lithium 2000mAh
Light Source	White light, Warm light, Ordinary light (3 levels brightness)
Max Brightness	150lm
Charging Method	USB Type-C
Control	Bottom switch, Top touch control




Image: Dimensions of the plplaaoo Cordless Table Lamp. The lamp measures approximately 28.5cm in height and 13cm in diameter.

10. WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact the retailer where you purchased the item. For technical support or inquiries, please visit the official plplaaoo store or contact customer service.

Visit the plplaaoo Store