

XINJISHIMIN C124041801D04(zi_hei_TCL+zhijia)

User Manual: Replacement Remote Control for Emerson Quiet Kool Portable Air Conditioners

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your new XINJISHIMIN Replacement Remote Control. This remote is specifically designed to be compatible with Emerson Quiet Kool portable air conditioner models EQK EAPC10RD1, EBPC8RD1, EBPC10RD1, and EAPC8RD1. Please read this manual thoroughly before using the remote control to ensure proper functionality and longevity.

PRODUCT OVERVIEW

The XINJISHIMIN Replacement Remote Control offers a convenient way to manage your Emerson Quiet Kool portable air conditioner. It features an ergonomic design and a clear display that can show temperature in both Fahrenheit and Celsius. A wall mounting bracket is included for easy storage.





Figure 1: Front view of the XINJISHIMIN Replacement Remote Control.



Figure 2: The remote control shown with its wall mounting bracket, positioned near a portable air conditioner.

SETUP

1. Battery Installation

The remote control requires two (2) AAA 1.5V batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.

2. Wall Mounting (Optional)

The included wall mounting bracket allows for convenient storage of your remote control. To install:

1. Choose a suitable location near your air conditioner, ensuring it is within easy reach and line of sight for optimal signal transmission.
2. Use appropriate screws (not included) to secure the bracket to the wall. Ensure the bracket is level.
3. Slide the remote control into the bracket for storage.

OPERATING INSTRUCTIONS

Point the remote control directly at the infrared receiver on your Emerson Quiet Kool portable air conditioner for proper operation. Ensure there are no obstructions between the remote and the air conditioner.

Power Button (): Press to turn the air conditioner ON or OFF.

Mode Button (□□): Press repeatedly to cycle through available operating modes: Auto, Cool, Dry, Fan, Heat (if applicable to your AC model). The current mode will be displayed on the remote's screen.

Temperature Adjustment Buttons (▲ / ▼): Press the ▲ button to increase the desired temperature and the ▼ button to decrease it.

Fan Speed Button (↔): Press to adjust the fan speed. Options typically include Auto, Low, Medium, and High.

Timer Button ():: Use this button to set a timer for the air conditioner to turn ON or OFF automatically. Refer to your air conditioner's main manual for detailed timer setting procedures.

Sleep Button ():: Activates the sleep mode, which typically adjusts temperature and fan speed for comfortable sleeping conditions and energy saving.

Swing Button (△): Controls the automatic swing function of the air conditioner's louver, directing airflow.

°C/°F Button: Press to switch the temperature display between Celsius and Fahrenheit.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control not responding.	Dead or incorrectly installed batteries.	Replace batteries with new AAA 1.5V batteries, ensuring correct polarity.
Remote control range is limited.	Obstruction between remote and AC unit; weak batteries.	Ensure a clear line of sight to the AC unit's infrared receiver. Replace batteries if necessary.
Display is dim or blank.	Low battery power.	Replace batteries.
AC unit does not respond to specific commands.	Remote not compatible with all AC functions; AC unit issue.	Verify the function is supported by your specific Emerson Quiet Kool model. Consult your AC unit's manual.

SPECIFICATIONS

Brand	XINJISHIMIN
Model Number	C124041801D04(zi_hei_TCL+zhijia)
Compatible Devices	Emerson Quiet Kool EQK EAPC10RD1, EBPC8RD1, EBPC10RD1, EAPC8RD1 Portable Air Conditioners
Connectivity Technology	Infrared
Batteries Required	Yes (2 x AAA 1.5V)

Item Weight	1.06 ounces
Package Dimensions	0.39 x 0.2 x 0.08 inches
Special Feature	Ergonomic, Fahrenheit/Celsius Display, Wall Mounting Bracket Included

WARRANTY AND SUPPORT

This XINJISHIMIN Replacement Remote Control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as described under normal use.

For technical support, warranty claims, or any questions regarding your remote control, please contact the seller or manufacturer directly through the platform where the product was purchased. Please have your purchase details and product model number ready when contacting support.