Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

artfone C1+4G

artfone C1+4G Big Button Cell Phone User Manual

Model: C1+4G | Brand: artfone

1. Introduction

The artfone C1+4G is a user-friendly mobile phone designed with simplicity and accessibility in mind, particularly for seniors, children, and individuals with visual impairments. It features large buttons, a clear display, and essential functions for reliable communication. This manual provides detailed instructions to help you set up, operate, and maintain your device.

2. Product Overview

Familiarize yourself with the components of your artfone C1+4G phone:



Figure 2.1: artfone C1+4G phone with its charging dock. The phone features a 1.77-inch color display and large, easy-to-read buttons.



Figure 2.2: Physical dimensions of the phone: 122.1mm (L) x 59.3mm (W) x 13.9mm (T), or 4.8 inches (L) x 2.33 inches (W) x 0.55 inches (T).



Figure 2.3: The dedicated SOS button located on the back of the phone, designed for quick access to emergency contacts.



Figure 2.4: The built-in strong flashlight, activated by a dedicated button on the side of the phone.

Key Features:

- **Large Buttons & Clear Display:** Designed for ease of use with a 1.77-inch color display, large buttons, and clear icons.
- **Loud Speakers:** Ensures clear sound for calls, beneficial for users with hearing difficulties.
- **SOS Button:** A dedicated emergency button that can call up to 5 pre-set emergency numbers.
- **Flashlight:** A convenient, bright flashlight accessible via a side button.
- **Long Battery Life:** Equipped with an 1800mAh battery, offering extended talk and standby times.
- **USB-C & Charging Dock:** Provides flexible and easy charging options.
- **Unlocked 4G Phone:** Compatible with T-Mobile, MetroPCS, SpeedTalk, Tello, and RedPocket GSMT SIM cards.

3. Setup

3.1. Installing the SIM Card and Battery

To begin using your artfone C1+4G, you will need to install a Nano SIM card and the included battery. The phone supports 4G networks for optimal call quality and coverage.

1. Carefully remove the back cover of the phone.
2. Locate the SIM card slot. Insert your Nano SIM card into the designated slot. Ensure it is correctly oriented.
3. Insert the 1800mAh battery into the battery compartment, aligning the gold contacts.
4. Replace the back cover, ensuring it clicks securely into place.

3.2. Charging the Phone

Your phone comes with both a USB-C cable and a convenient charging dock. It is recommended to fully charge the phone before first use.

- **Using the Charging Dock:** Connect the USB-C cable to the charging dock and then to a power adapter. Place the phone into the charging dock. The phone will begin charging automatically. This method is ideal for easy, regular charging.
- **Direct USB-C Charging:** Alternatively, you can connect the USB-C cable directly to the phone's USB-C port and then to a power adapter for charging.

The battery is designed for safety and quality, providing up to 5-6 hours of talk time and 8-10 days of standby time.

4. Operating Instructions

4.1. Powering On/Off

- **To Power On:** Press and hold the red End Call button (usually marked with a power symbol) until the screen lights up.
- **To Power Off:** Press and hold the red End Call button until the "Goodbye" message appears and the phone shuts down.

4.2. Making and Receiving Calls

- **Making a Call:** Use the large numeric keypad to dial the desired phone number. Press the green Call button to initiate the call.
- **Receiving a Call:** When the phone rings, press the green Call button to answer.
- **Ending a Call:** Press the red End Call button to terminate a call.
- **Call Volume:** The phone features loud and clear call volume, which can be adjusted using the volume buttons on the side of the device.

4.3. SOS Emergency Button

The SOS button is a critical safety feature. You can program up to 5 emergency contact numbers.

1. **Setting Up SOS Numbers:** Navigate to the phone's settings menu, find "SOS settings," and add up to 5 emergency contacts.
2. **Activating SOS:** In an emergency, press and hold the SOS button on the back of the phone. The phone will automatically dial the pre-set emergency numbers in sequence until one is answered.

4.4. Flashlight

The phone includes a built-in flashlight for convenience.

- **To Turn On/Off:** Slide the dedicated flashlight button located on the right side of the phone.

4.5. Other Functions

The artfone C1+4G includes several other useful features:

- **FM Radio:** Enjoy your favorite radio stations.
- **Calculator:** Basic arithmetic functions.
- **Alarm:** Set reminders and wake-up calls.
- **Calendar:** Keep track of dates.
- **Phonebook:** Store up to 100 contacts.
- **Speed Dial:** Assign frequently called numbers to specific keys for quick dialing.

5. Maintenance

To ensure the longevity and optimal performance of your artfone C1+4G, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the phone's exterior. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Avoid overcharging the battery. If the phone will not be used for an extended period, charge it to about 50% before storing.
- **Protection:** The phone features an anti-slip design. Consider using a protective case to prevent damage from impacts or drops.

6. Troubleshooting

This section addresses common issues you might encounter with your artfone C1+4G.

Problem	Possible Cause	Solution
Phone does not power on.	Low battery; battery not installed correctly.	Charge the phone for at least 30 minutes. Ensure the battery is properly inserted.
Cannot make or receive calls.	No SIM card; SIM card not activated; out of network coverage.	Ensure SIM card is inserted and activated. Check network signal strength. Contact your carrier if issues persist.
Poor call quality.	Weak signal; environmental interference.	Move to an area with better signal. Ensure speakers are not obstructed.
Phone not charging.	Charging cable/dock faulty; phone not properly seated in dock.	Check cable and adapter. Ensure phone is correctly placed in the charging dock or cable is fully inserted into the USB-C port.
SOS button not working.	No emergency numbers set; incorrect numbers.	Verify that emergency numbers are correctly programmed in the SOS settings.

7. Specifications

Feature	Detail
Model Name	C1+4G Black
Brand	artfone

Feature	Detail
Color	Black
Operating System	artfone OS
Screen Size	1.8 Inches
Resolution	128 x 160
Human Interface Input	Buttons
Cellular Technology	4G
Wireless Carrier Compatibility	T-Mobile, MetroPCS, SpeedTalk, Tello, RedPocket GSMT (Not compatible with AT&T, Cricket, Verizon, Sprint, Boost Mobile)
Battery Capacity	1800 Milliamp Hours (mAh)
Talk Time	Up to 5-6 hours
Standby Time	Up to 8-10 days
Memory Storage Capacity	0.13 GB
RAM Memory Installed Size	48 MB
Item Weight	8.4 ounces
Package Dimensions	5.2 x 4.65 x 2.32 inches
What's in the Box	USB Cable, Charging Dock, Phone, Battery

8. Warranty and Support

For warranty information or technical support, please contact the manufacturer, artfone, or the seller, Shenzhen Yujie Communication Co., Ltd, through their official channels. Refer to the product packaging or purchase documentation for specific contact details and warranty terms.

© 2024 artfone. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D2LP8QH7

More documents and user manuals: **https://manuals.plus/**