



[Manuals.plus](#) /

› [Quicklock Cabinets](#) /

› Quicklock RTA Base Kitchen Cabinet with Lazy Susan, Magnetic Gray (Model QLRTAB)

Quicklock Cabinets QLRTAB

Quicklock RTA Base Kitchen Cabinet with Lazy Susan, Magnetic Gray (Model QLRTAB)

Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Quicklock RTA (Ready-to-Assemble) Base Kitchen Cabinet with Lazy Susan. This Shaker style cabinet, finished in Magnetic Gray, is designed for durability and efficient kitchen storage. Please read all instructions carefully before beginning assembly or use.

SAFETY INFORMATION

Always exercise caution during assembly and installation. Ensure all components are securely fastened. Keep small parts away from children. If you are unsure about any step, consult a professional.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present. Refer to the included parts list (not provided in this digital manual, but typically included with physical product) to ensure no components are missing.

- Cabinet panels (sides, back, bottom, top supports)
- Shaker style door(s)
- Soft-close hinges
- Lazy Susan shelves (2)
- Lazy Susan hardware (center pole, rotating mechanisms)
- Assembly fasteners (screws, cam locks, dowels)
- Adjustable legs/toe kick components

SETUP: ASSEMBLY INSTRUCTIONS

The Quicklock RTA cabinet is designed for straightforward assembly. Follow these steps carefully.

QuickLOCK

CABINETS

Easy Assembly



Image Description: A four-step diagram illustrating the Quicklock cabinet assembly process. Step 1 shows side panels attaching to the base. Step 2 shows the back panel being inserted. Step 3 depicts the top supports being placed. Step 4 shows the final securing of components with screws.

- 1. Prepare the Workspace:** Clear a clean, flat, and spacious area for assembly. Lay out all components and hardware.
- 2. Assemble the Cabinet Box:**
 - Attach the side panels to the base panel using the provided cam locks and dowels. Ensure the grooves for the back panel are aligned.
 - Slide the back panel into the grooves of the side and base panels.
 - Secure the top supports to the side panels.
 - Use screws to reinforce all connections, ensuring the cabinet box is square and stable.
- 3. Install the Lazy Susan Mechanism:**
 - Mount the bottom Lazy Susan rotating mechanism to the cabinet base according to the pre-drilled holes.
 - Insert the center pole into the bottom mechanism.
 - Place the first Lazy Susan shelf onto the pole and secure it.
 - Install the top Lazy Susan rotating mechanism and the second shelf, ensuring smooth rotation.
- 4. Attach Doors and Hinges:**
 - Attach the soft-close hinges to the cabinet door(s) using the provided screws.
 - Mount the door(s) to the cabinet frame, aligning the hinges with the pre-drilled holes.
 - Adjust the hinges as needed to ensure proper door alignment and soft-close functionality.

5. **Install Toe Kick/Legs:** Attach the toe kick or adjustable legs to the bottom of the cabinet as per the design.



Image Description: An assembled Quicklock base kitchen cabinet with the door open, revealing two circular Lazy Susan shelves inside. The cabinet features a Magnetic Gray shaker style door and natural birch plywood interior.



Image Description: An assembled Quicklock base kitchen cabinet with its Magnetic Gray shaker style doors closed, showcasing the corner unit design.

OPERATING INSTRUCTIONS

Your Quicklock Lazy Susan cabinet is designed for convenient access to stored items.

- **Accessing Contents:** Open the cabinet door(s). The Lazy Susan shelves can be rotated manually to bring items from the back to the front.
- **Soft-Close Functionality:** The integrated soft-close hardware ensures that the cabinet door(s) close gently and quietly, preventing slamming. Simply push the door(s) gently, and the mechanism will engage to close it smoothly.
- **Weight Capacity:** Distribute weight evenly on the Lazy Susan shelves. Avoid overloading to ensure smooth operation and longevity of the mechanism.

MAINTENANCE

Proper care will extend the life and appearance of your Quicklock cabinet.

- **Cleaning:**
 - For painted surfaces (Magnetic Gray doors), wipe with a soft, damp cloth and a mild, non-abrasive cleaner. Dry immediately with a clean cloth.
 - For birch plywood interiors, wipe with a dry or slightly damp cloth. Avoid excessive moisture.
 - Do not use harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the finish.
- **Hardware:** Periodically check all screws and fasteners for tightness. Tighten if necessary. The soft-close hinges and Lazy Susan mechanism are designed for long-term use and generally require no lubrication.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood and finish.

TROUBLESHOOTING

Refer to these common issues and solutions.

- **Door Not Closing Properly:**
 - Check hinge alignment. Most soft-close hinges have adjustment screws to fine-tune door position (up/down, left/right, in/out).
 - Ensure no obstructions are preventing the door from closing fully.
- **Lazy Susan Sticking or Not Rotating Smoothly:**
 - Check for obstructions on or around the shelves.
 - Ensure weight is evenly distributed and not exceeding the capacity.
 - Verify that the center pole and rotating mechanisms are securely fastened and not loose.
- **Cabinet Wobbles:**
 - Ensure the cabinet is placed on a level surface.
 - If equipped with adjustable legs, adjust them to stabilize the cabinet.
 - Check all assembly fasteners for tightness.

SPECIFICATIONS

Feature	Detail
Brand	Quicklock Cabinets
Model Number	QLRTAB
Color	Magnetic Gray
Product Dimensions	24"D x 30"W x 34.5"H
Construction Material	½" Birch Plywood (Cabinet Box), Maple Wood (Frame)
Door Style	Shaker
Finish Type	Painted
Number of Shelves	2 (Lazy Susan)
Mounting Type	Floor Mount

Installation Type	Freestanding
Assembly Required	Yes (Ready-to-Assemble)
UPC	198546006355

QuickLOCK

C A B I N E T S




Image Description: A technical diagram showing the top and side views of the Quicklock Lazy Susan cabinet with key dimensions labeled, including 18" D x 30" W x 34.5" H for the Lazy Susan section and overall cabinet dimensions.

WARRANTY INFORMATION

For specific warranty details regarding your Quicklock RTA Base Kitchen Cabinet, please refer to the warranty card included with your product or visit the official Quicklock Cabinets website. General warranty terms typically cover manufacturing defects under normal use conditions.

SUPPORT

If you require further assistance or have questions not covered in this manual, please contact Quicklock Cabinets customer support. Contact information can typically be found on the product packaging or the official brand website. You can also visit the [Quicklock Cabinets Store on Amazon](#) for additional product information and resources.

