

[Manuals.plus](#) /

› [Pomya](#) /

› Pomya 1080P HD Mini DV Camera User Manual


Pomya Pomya46smqa3vec-12

Pomya 1080P HD Mini DV Camera User Manual

Brand: Pomya | Model: Pomya46smqa3vec-12

1. INTRODUCTION

This manual provides instructions for the operation and maintenance of your Pomya 1080P HD Mini DV Camera. Please read this manual thoroughly before using the device to ensure proper functionality and to prevent damage.



The Pomya Mini DV Camera is designed for various recording scenarios, from sports to family moments.

2. PRODUCT FEATURES

- **High Definition Lens:** Records videos in 1080P HD resolution and captures clear images with an optical lens. Features a flip-up flashlight for low-light environments.
- **Large Advanced Screen:** Equipped with a 1.44-inch display for real-time previews, aiding in clearer photo capture.
- **Long Battery Life:** Includes a 480mAh battery. When used with the charging case, the device can operate for up to a week.
- **Automatic Loop Recording:** Automatically saves segmented videos and overwrites the earliest segment when the memory card is full, ensuring continuous recording.
- **OTG Connection:** Compatible with Android 8.0 and newer systems for instant transfer and viewing of photos on

smartphones.



OTG Instant Sharing
Faster to transfer your phone

Front view of the Pomya Mini DV Camera, highlighting its lens and flip-up flashlight.

Powerful core



Internal architecture diagram, representing the camera's powerful core processing capabilities.

3. WHAT'S IN THE BOX

Verify that all items are present in the package:


- 1 x Small DV Camera
- 1 x Charging Case
- 1 x Hand Strap
- 1 x Charging Cable



Included accessories: the camera, charging case, hand strap, and charging cable.

4. SETUP

1. **Insert Memory Card:** Locate the memory card slot on the camera. Insert a compatible storage card (up to 512GB, not included) into the slot until it clicks into place.
2. **Charge the Device:** Connect the charging cable to the camera's USB port and a power source. The camera has a 480mAh battery, and the charging case has an 180mAh battery. Ensure both are fully charged before first use.
3. **Power On:** Press and hold the top power button to turn on the camera.







The USB port for charging the camera.

Your browser does not support the video tag.

Video: Demonstrates the unboxing and initial setup of the Pomya Mini DV Camera, including connecting the charging cable and hand strap.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

1. **Power On/Off:** Press and hold the top power button to turn the camera on or off.
2. **Menu Navigation:** Use the side buttons to navigate through the menu options. You can select between photo mode, video mode, and gallery.
3. **Switch Shooting Effect:** The side buttons also allow you to switch between different shooting effects.



The 1.44-inch color screen provides a clear view for framing shots and reviewing content.

5.2 Using the Flashlight

The camera features a flip-up flashlight to enhance visibility in low-light conditions. Activate or deactivate the flashlight as needed to improve image quality.



Turn off the flash effect



Turn on the flash effect

Demonstration of the flashlight effect, showing improved illumination when activated.

5.3 OTG Connection

For quick transfer and viewing of media, connect the camera to your Android 8.0 or higher smartphone using the OTG function. This allows for instant access to your photos and videos without needing a computer.



The camera supports OTG for direct connection and sharing with compatible smartphones.

Your browser does not support the video tag.

Video: Overview of the camera's features, including its 1.44-inch color screen and 1080P HD recording capabilities.

Your browser does not support the video tag.

Video: Demonstrates the camera's compact size and its ability to record 1080P HD video with a color screen.

Your browser does not support the video tag.

Video: A brief demonstration of the camera's compact design and its function as a DVR camcorder for video recording.

6. MAINTENANCE

To ensure the longevity and optimal performance of your camera, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the camera body. For the lens and screen, use a specialized lens cleaning cloth and solution to avoid scratches.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Battery Care:** If not using the camera for an extended period, charge the battery periodically to maintain its health.

7. TROUBLESHOOTING

If you encounter issues with your Pomya Mini DV Camera, refer to the following common solutions:

- **Camera not turning on:** Ensure the battery is charged. Connect the camera to a power source and try again.
- **Cannot record video/take photos:** Check if a memory card is inserted correctly and if it has sufficient free space. The card might be full or corrupted.
- **Poor image/video quality:** Ensure the lens is clean and free from smudges. Check lighting conditions and use the flashlight if necessary.
- **OTG connection issues:** Verify that your smartphone supports OTG functionality and that the cable is securely connected.

8. SPECIFICATIONS

Feature	Detail
Brand Name	Pomya
Item Weight	3.32 ounces
Package Dimensions	4.33 x 3.54 x 1.97 inches
Item Model Number	Pomya46smqa3vec-12
Color	Pink
Special Features	Adjustable
Shooting Modes	RM
Exposure Control Type	Manual
Video Capture Resolution	1080p
Water Resistance Level	Not Water Resistant
Storage Support	Up to 512G storage card (not included)
Battery Capacity	480mA (camera), 180mAh (charging case)

9. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. Please refer to the product packaging or retailer's website for specific warranty terms and conditions.

For technical support or customer service inquiries, please contact your point of purchase or visit the official Pomya website for assistance.

© 2024 Pomya. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question