

[Manuals.plus](#) /

› [COMHOMA](#) /

› COMHOMA Convertible Futon Sofa Bed User Manual

COMHOMA 68" Fabric Futon Couch

COMHOMA Convertible Futon Sofa Bed User Manual

Model: 68" Fabric Futon Couch

INTRODUCTION

Thank you for choosing the COMHOMA Convertible Futon Sofa Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read it thoroughly before use and retain it for future reference.




Image: The COMHOMA Convertible Futon Sofa Bed, showcasing its versatile design as a sofa.

SAFETY INSTRUCTIONS

- Ensure all parts are present and undamaged before assembly.
- Do not overtighten screws during assembly to avoid damaging components.
- Keep small parts away from children during assembly.
- Do not stand or jump on the futon.
- Distribute weight evenly when sitting or sleeping.
- Regularly check all fasteners to ensure they remain tight.
- Maximum weight capacity: 300 pounds.

PACKAGE CONTENTS

Before beginning assembly, verify that all the following components are included in your package:

- Futon Sofa Sections (2)
- Legs (4-6, depending on design)
- Throw Pillows (2)
- Assembly Hardware (screws, bolts, wrench)
- Instruction Manual (this document)

SETUP AND ASSEMBLY

Assembly of the COMHOMA Futon Sofa Bed is designed to be straightforward and typically takes less than 30 minutes. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Legs:** Identify the designated attachment points on the bottom of each futon section. Securely fasten the legs using the provided hardware and wrench. Ensure all legs are firmly attached and stable.

STEEL METAL FEET

5.9"Gap-Effortlessly Navigate with the Sweeping Robot
Strong load-bearing capacity for stable and enduring
Safety & Durability.



Image: Illustration of the steel metal feet, highlighting their stability and load-bearing capacity. The 5.9-inch gap allows for easy cleaning underneath.

3. **Connect Sofa Sections:** Align the two futon sections. There are connecting mechanisms (often bolts and receivers) that will join the two halves. Carefully push the sections together until they lock or can be secured with additional hardware. *Tip: Placing a pillow under one side can help align the holes during connection.*




Image: A comparison highlighting the COMHOMA futon's stable bed structure with additional supporting legs, contrasting it with less stable designs.

4. **Final Check:** Once assembled, gently shake the futon to ensure all connections are secure and the structure is stable. Place the throw pillows as desired.

OPERATING INSTRUCTIONS

Your COMHOMA Futon Sofa Bed is designed for easy conversion between sofa and bed modes, and features an adjustable backrest for optimal comfort.

Adjusting the Backrest

The backrest can be adjusted to various reclining positions. To adjust, simply push the backrest forward slightly to release the locking mechanism, then recline it to your desired angle. Release to lock it into place. This allows for a comfortable seating experience, whether upright or slightly reclined.



L. Lawson

★★★★★ **Beautiful couch-futon.**

Reviewed in the United States on May 17, 2024

Verified Purchase

This is more of a 'burnt sienna' color than orange, but it looks great with my color theme.

I'm a 73 year old woman and I put this into my house and got it together by myself. The only hard part was joining the two pieces together and lining up the holes. I found putting a pillow under one side to leverage it helped. It's a nice looking couch and comfortable enough.



Image: Detailed view of the ergonomic curved design of the futon's backrest, illustrating how it supports the body and relieves tension.

Converting to Bed Mode

To transform your futon into a bed:

1. **Release Backrest:** Push the backrest forward to disengage the locking mechanism.
2. **Lower Backrest:** Gently push the backrest all the way down until it lies flat, creating a continuous sleeping surface.
3. **Extend Support Legs:** For enhanced stability in bed mode, pull out the two additional support legs located at the bottom of the backrest frame. Ensure they are fully extended and firmly on the floor.

To convert back to sofa mode, simply lift the backrest until it clicks into an upright position, and retract the support legs.



Image: The COMHOMA futon fully unfolded into a bed, demonstrating its spacious sleeping area.



Image: A visual representation of the futon transforming from a compact sofa to a full-sized bed, highlighting its ease of conversion.

MAINTENANCE

Proper care will extend the life and appearance of your futon sofa bed.

- **Cleaning:** For general cleaning, use a soft, damp cloth. For spills, blot immediately with a clean, dry cloth. The sofa cover is removable and washable. Refer to the care label for specific washing instructions (typically gentle cycle, cold water).
- **Vacuuming:** Regularly vacuum the fabric to remove dust and debris.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals, as they may damage the fabric or frame.




Image: An illustration emphasizing the full coverage washable sofa cover, highlighting its benefits for easy maintenance and durability.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Futon feels unstable after assembly.	Loose fasteners or improper connection of sections.	Ensure all screws and bolts are tightened. Re-check the connection between the two sofa sections.
Backrest does not lock into position.	Mechanism obstructed or not fully engaged.	Ensure no fabric or debris is blocking the mechanism. Push the backrest fully forward before reclining to reset the lock.
Difficulty converting to bed mode.	Backrest not fully released or support legs not extending.	Ensure the backrest is pushed forward to release the lock before lowering. Check that the support legs are not jammed.
Squeaking noises.	Loose connections or friction between parts.	Tighten all assembly hardware. Apply a small amount of silicone lubricant to moving metal parts if necessary.

SPECIFICATIONS

Brand	COMHOMA
Type	Futon Sofa Bed
Color	Black
Product Dimensions (Sofa)	39.7"D x 42.1"W x 30.1"H
Product Dimensions (Bed)	Approx. 68.5"L x 41"W (unfolded)
Item Weight	48.5 Pounds
Weight Limit	300 Pounds
Seat Height	15 Inches
Frame Material	Iron
Upholstery Material	Fabric (with high resilient sponge cushion)
Assembly Required	Yes
Special Feature	Adjustable Backrest, Convertible to Bed, Recliner



Image: Detailed dimensional drawing of the futon in both its upright sofa configuration and fully extended bed configuration, showing key measurements.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact COMHOMA customer service directly. Refer to the product packaging or the manufacturer's official website for contact details.

You can also visit the COMHOMA Store on Amazon for more information:[COMHOMA Store](#)

© 2024 COMHOMA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D2M5GTVM>

More documents and user manuals: <https://manuals.plus/>