

Pravoluxmax SH20.006B03C

Pravoluxmax Retractable Baby Gate - Instruction Manual

Model: SH20.006B03C | Brand: Pravoluxmax

1. INTRODUCTION AND OVERVIEW

The Pravoluxmax Retractable Baby Gate is designed to provide a secure barrier for children and pets in various areas of your home. Its retractable mesh design offers flexibility, allowing the gate to be extended when needed and retracted for clear passage. This manual provides essential information for safe installation, operation, and maintenance of your gate.

This gate is suitable for doorways, hallways, and the top or bottom of stairs, for both indoor and outdoor use. It features a no-threshold design to minimize tripping hazards.



Figure 1: Pravoluxmax Retractable Gate in use, securing an area for a baby and a dog.

2. SAFETY INFORMATION

Always ensure the gate is properly installed and securely locked before leaving children or pets unattended. This gate is equipped with a dual locking mechanism for enhanced safety.

- **Dual Locking Mechanism:** Designed to be easy for adults to operate but difficult for children.
- **No-Threshold Design:** Reduces the risk of tripping when passing through.

- **Soft Mesh Fabric:** Minimizes injury risk compared to rigid gates.
- Regularly inspect the gate for any signs of damage or wear. Do not use if damaged.
- Never allow children to climb on or play with the gate.



Figure 2: Illustration of the Dual Locks System, highlighting the mesh lock and concealed gate lock.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning installation:

- Retractable Gate Unit (Mesh and Housing)
- Mounting Brackets (for both sides)
- Screws and Wall Anchors
- Installation Template
- User Manual

4. SETUP AND INSTALLATION

The Pravoluxmax Retractable Baby Gate requires hardware mounting for secure installation. Follow these steps carefully:

1. **Assemble the Iron Tube Part:** Connect any necessary components of the gate's main housing.
2. **Mark Holes:** Use the provided template to mark the drilling locations for the mounting brackets on both sides of the opening. Ensure the marks are level and at the correct height, accounting for baseboards if present.
3. **Drill Holes:** Drill pilot holes at the marked locations. Use appropriate drill bits and wall anchors for your wall type (wood, brick, concrete). Avoid drywall without proper reinforcement.
4. **Install the Iron Tube Part:** Secure the main gate housing to the wall using the screws and anchors.
5. **Install the Gate:** Attach the retractable mesh unit to the installed housing and the receiving brackets on the opposite side.
6. **Finished:** Test the gate's operation and locking mechanism to ensure it is securely installed.




Figure 3: Step-by-step installation instructions for the retractable gate.



Figure 4: Adjustable mounting bracket for compatibility with different baseboard heights.

5. OPERATING INSTRUCTIONS

The gate is designed for convenient one-handed operation while maintaining security.

- **To Open:** Press the hidden button on the lock mechanism. This disengages the mesh lock, allowing the gate to be pulled open.
- **To Close:** Extend the mesh across the opening and push the rod back into the receiving clips until it securely locks. The gate self-locks upon closing.
- **Dual Locking:** The gate features both a mesh lock (to prevent retraction) and a concealed gate lock (to secure the extended mesh). Ensure both are engaged for maximum safety.



Figure 5: One-handed operation for opening and closing the gate.



Figure 6: Enhanced hook latch design for secure closure.

6. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your retractable gate.

- **Cleaning:** Wipe the mesh fabric and plastic components with a damp cloth and mild soap. Do not use abrasive cleaners.
- **Inspection:** Periodically check all mounting hardware, screws, and the locking mechanism for tightness and proper function.
- **Smooth Operation:** Ensure the mesh retracts and extends smoothly. If resistance is felt, check for obstructions.

7. TROUBLESHOOTING

If you encounter issues with your gate, refer to the following common solutions:

- **Gate not retracting fully:** Check for any debris or obstructions in the retraction mechanism. Ensure the mesh lock is disengaged.
- **Gate not locking securely:** Verify that the mounting brackets are aligned correctly and that the gate is fully extended into the receiving clips. Ensure the concealed gate lock is engaged.
- **Gate feels loose:** Tighten all mounting screws. If the issue persists, re-evaluate the installation method and wall anchors.

8. SPECIFICATIONS

| Feature | Detail |
|---------------------------|--|
| Model Number | SH20.006B03C |
| Dimensions (Max Extended) | 34 inches (Height) x 55 inches (Width) |
| Material | Mesh Fabric |
| Mounting Type | Hardware Mounted |
| Color | White |

9. WARRANTY AND SUPPORT

Pravoluxmax is committed to customer satisfaction. Your retractable baby gate comes with comprehensive after-sales support and a lifetime replacement policy for manufacturing defects.

For installation guidance, product assistance, or warranty claims, please contact our professional support team:

- **Email:** support@pravoluxmax.com
- **Phone:** 1-800-XXX-XXXX (Monday-Friday, 9 AM - 5 PM EST)
- **Website:** [Pravoluxmax Official Store](#)