

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Moni](#) /

› [Moni i-Size Multi Infant Car Seat User Manual](#)

Moni i-Size Multi

Moni i-Size Multi Infant Car Seat User Manual

Model: i-Size Multi

Brand: Moni

INTRODUCTION

This manual provides essential information for the safe and proper use of your Moni i-Size Multi Infant Car Seat. Designed for infants from 40 to 87 cm in height (Group 0+), this car seat ensures maximum safety and comfort for your child. Please read these instructions carefully before use and keep them for future reference.

IMPORTANT SAFETY INFORMATION

- Always install the car seat rear-facing in the vehicle. This is the safest way for infants to travel.
- Ensure the 3-point safety harness is correctly fastened and adjusted to your child's size.
- Never leave your child unattended in the car seat.
- Do not use the car seat if it has been involved in an accident, even if there is no visible damage.
- Refer to your vehicle's owner's manual for specific car seat installation guidelines.
- The car seat is suitable for children from birth up to 13 kg.

PRODUCT COMPONENTS

The Moni i-Size Multi Infant Car Seat includes the following main components:

- Ergonomic carrying handle (3-position adjustable)
- Adjustable memory foam headrest
- Adjustable and removable sun canopy
- 3-point safety harness with shoulder pads and lower buckle covers
- Soft full-body support cushion
- Removable and washable cover



Image: Moni i-Size Multi Infant Car Seat with the footmuff attached, showing the overall design and carrying handle.



Image: Moni i-Size Multi Infant Car Seat without the footmuff, highlighting the internal padding and harness system.

SETUP AND INSTALLATION

This car seat is designed for rear-facing installation using the vehicle's 3-point seat belt.

Installing the Car Seat in Your Vehicle

1. Place the car seat on the vehicle seat, ensuring it is positioned rear-facing.
2. Route the vehicle's 3-point seat belt through the designated belt guides on the car seat. Refer to the labels on the car seat for correct routing.
3. Fasten the vehicle's seat belt buckle.
4. Pull the shoulder belt tightly to remove any slack, ensuring the car seat is securely fastened and does not move more than 1 inch (2.5 cm) from side to side or front to back at the belt path.
5. Ensure the carrying handle is in the upright or designated travel position as per the instructions.



Image: Side view of the car seat, illustrating the correct belt path for vehicle installation.

Adjusting the Headrest

The memory foam headrest is adjustable to accommodate your child's growth. Locate the adjustment mechanism (usually a lever or button at the back or top of the headrest) and slide the headrest up or down until it is at the correct height for your child's shoulders.



Image: Close-up view of the adjustable headrest and the 3-point harness system.

OPERATING INSTRUCTIONS

Securing Your Child

1. Place your child in the car seat.
2. Bring the two buckle tongues together and insert them into the buckle until you hear a click.
3. Pull the harness adjustment strap to tighten the harness until it is snug against your child's body. You

should not be able to pinch any slack in the harness straps at the child's collarbone.

4. Ensure the shoulder pads are positioned correctly over your child's shoulders.



Image: Front view of the car seat showing the 3-point harness system properly fastened.

Adjusting the Carrying Handle

The ergonomic carrying handle can be adjusted to 3 positions. Press the buttons on both sides of the handle simultaneously and rotate the handle to the desired position (carrying, stable base, or storage).



Image: Car seat with the carrying handle in the upright position, ready for transport.

Using the Sun Canopy

The sun canopy is adjustable and removable. Extend or retract the canopy as needed to protect your child from direct sunlight. To remove, detach it from its anchor points on the car seat frame.

MAINTENANCE AND CARE

Cleaning the Fabric Cover

The fabric cover is removable and washable.

1. Carefully remove the fabric cover from the car seat frame.
2. Wash the cover at 30 degrees Celsius (86 degrees Fahrenheit) using a mild detergent.

3. Do not bleach, tumble dry, or iron the cover.
4. Allow the cover to air dry completely before reattaching it to the car seat.

Cleaning the Frame

Wipe the plastic and metal parts of the car seat frame with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.

TROUBLESHOOTING

Car Seat Feels Loose After Installation

Ensure the vehicle's 3-point seat belt is routed correctly through all designated belt guides and pulled tightly. The car seat should not move more than 1 inch (2.5 cm) at the belt path. Re-read the installation instructions and consult your vehicle's manual.

Harness is Difficult to Adjust

Check for any twists in the harness straps. Ensure the harness adjustment strap is not obstructed. If the harness is still stiff, ensure the child is not leaning against the straps, which can create tension.

Buckle is Sticking

Clean the buckle area. Food crumbs or debris can cause sticking. Do not lubricate the buckle. If the issue persists, contact customer support.

PRODUCT SPECIFICATIONS



Feature	Detail
Model	i-Size Multi
Recommended Age	From birth
Weight Capacity	0 to 13 kg
Height Capacity (Rear-facing)	40 to 87 cm
Product Dimensions (L x W x H)	42 x 33 x 73 cm
Product Weight	3 kg
Material Composition	100% Polyester Fabric
Harness Type	3-point safety harness
Installation Type	Vehicle 3-point seat belt (rear-facing)
Compatibility	Compatible with Moni Kali, Tokyo, Rio, Ciara, Rafaello strollers (strollers not included)

WARRANTY AND CUSTOMER SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact Moni customer service. Keep your proof of purchase for any warranty claims.

For further assistance, please visit the official Moni website or contact their customer support line.

Related Documents - i-Size Multi

	<p><u>Moni i-Maxx LSA05AB i-Size Baby Car Seat (40-150 cm)</u></p> <p>Information about the Moni i-Maxx LSA05AB i-Size baby car seat, approved under ECE R129/03, suitable for children weighing 0-36 kg and heights 40-150 cm. Includes usage guidelines, specifications, and manufacturer details.</p>
	<p><u>Moni Serengeti i-Size Car Seat Instruction Manual</u></p> <p>Comprehensive instruction manual for the Moni Serengeti i-Size car seat, covering installation, usage, safety features, and maintenance for children from 40-150 cm.</p>
	<p><u>Moni i-Maxx LSA05AB i-Size Baby Car Seat (40-150 cm)</u></p> <p>Information on the Moni i-Maxx LSA05AB i-Size baby car seat, approved under ECE R129/03 for children 0-36 kg and 40-150 cm height. Features ISOFIX and midnight black color.</p>
	<p><u>Moni ARMOR GJ999 Baby Car Seat Instruction Manual</u></p> <p>Comprehensive instruction manual for the Moni ARMOR GJ999 baby car seat. Covers installation, safety features, maintenance, and warranty for this child safety restraint system, suitable for Groups 1, 2, and 3 (9-36kg).</p>
	<p><u>Moni Ari Children's Swing - Assembly and User Manual</u></p> <p>Comprehensive guide for the Moni Ari children's swing, covering assembly, usage, safety instructions, and maintenance. Model PD-B03.</p>



Moni Rocky Електрическа Бебешка Люлка - Ръководство за Употреба

Подробно ръководство за употреба на електрическата бебешка люлка Moni Rocky (модел BY059). Инструкции за сглобяване, безопасна експлоатация и поддръжка.