Satisfyer 4061504002767

Satisfyer Ribbed Petal Connect App Vibrator User Manual

Introduction

The Satisfyer Ribbed Petal Connect App Vibrator is a wearable device designed for internal stimulation. It features a ribbed surface and can be controlled via a remote or the Satisfyer Connect App, offering customizable vibration patterns. This manual provides essential information for safe and effective use, including setup, operation, maintenance, and troubleshooting.

Important Safety Information

- Read all instructions before first use.
- This device is intended for adult use only.
- Clean the device thoroughly before and after each use as described in the "Cleaning and Maintenance" section.
- Do not use the device if it appears damaged or defective.
- Discontinue use immediately if you experience any discomfort, pain, or irritation. Consult a healthcare professional if symptoms persist.
- Use only water-based lubricants with this device. Oil-based lubricants can damage the silicone material.
- Keep out of reach of children.
- Do not expose the device to extreme temperatures or direct sunlight for prolonged periods.

Package Contents

- Satisfyer Ribbed Petal Connect App Vibrator
- Remote Control
- USB Magnetic Charging Cable
- User Manual (this document)

Product Features

- **Material:** Body-safe medical-grade silicone.
- **Design:** Ergonomic, ribbed surface for enhanced G-spot stimulation.

- **Control:** Operable via included remote control or the Satisfyer Connect App.
- **Vibration Programs:** 12 preset vibration patterns.
- **App Connectivity:** Bluetooth-enabled for custom vibration patterns and remote play via the Satisfyer Connect App.
- **Waterproof:** Designed for easy cleaning and use in wet environments.
- **Charging:** Convenient magnetic USB charging.

The image shows the Satisfyer Ribbed Petal Connect App Vibrator covered in water droplets, emphasizing its waterproof construction for easy cleaning and use.

Setup

1. Charging the Device

Before first use, fully charge the device. Connect the magnetic USB charging cable to the charging points on the device and to a USB power source (e.g., computer, USB wall adapter). The LED indicator will show charging status (refer to device for specific light patterns). A full charge typically takes approximately 2 hours.

2. App Installation (Optional)

To unlock advanced features and customization, download the "Satisfyer Connect" app from your smartphone's app store (available for iOS and Android). Follow the on-screen instructions to install the app.

This image shows the Satisfyer Ribbed Petal Connect App Vibrator alongside icons indicating access to infinite vibration programs and the availability of a free companion application.

3. Device Pairing (Bluetooth)

1. Ensure the device is charged and turned off.
2. Press and hold the Bluetooth button on the device for 5 seconds until you feel a double pulse. The LED light will start flashing, indicating it is ready for pairing.
3. Open the Satisfyer Connect App on your smartphone.
4. Follow the app's instructions to search for and connect to your device.
5. Once connected, the LED light on the device will stop flashing and remain solid (or turn off, depending on the model).

This image illustrates the basic controls of the Satisfyer Ribbed Petal Connect App Vibrator and its remote. It shows how to power on the device, cycle through vibration programs, and initiate Bluetooth pairing for app connectivity.

Operating Instructions

1. Basic Device Operation

- **Power On/Off:** Press and hold the power button on the device for 2 seconds to turn it on or off.
- **Change Programs:** While the device is on, press the program button to cycle through the 12 preset vibration programs.

2. Using the Remote Control

The included remote control allows for convenient adjustment of the device's functions without using the app.

- **Power Button:** Press and hold to turn the device on/off.
- **Program Button:** Press to cycle through vibration patterns.
- **Intensity Buttons (+/-):** Adjust the vibration intensity.

This image shows a person holding the Satisfyer Ribbed Petal Connect App Vibrator and its remote control, illustrating how the device can be operated.

3. Using the Satisfyer Connect App

Once paired, the Satisfyer Connect App offers extensive control and customization options:

- **Custom Vibration Patterns:** Create and save your own unique vibration sequences.
- **Intensity Adjustment:** Fine-tune vibration intensity beyond the remote's capabilities.
- **Remote Play:** Control the device from a distance.
- **Interactive Features:** Explore additional app features such as guided meditations, playlist vibrations, and partner control options.

This image highlights key features of the Satisfyer Connect App, such as chat functionality, remote control, data security, guided meditation, custom vibration pattern creation, and playlist vibration.

Cleaning and Maintenance

Proper cleaning and maintenance ensure hygiene and prolong the lifespan of your device.

- Always clean the device before and after each use.
- Wash the device with warm water and a mild, toy-friendly soap or a specialized toy cleaner.
- Rinse thoroughly with clean water.
- Pat dry with a lint-free cloth or allow it to air dry completely before storing.
- Do not use harsh chemicals, alcohol-based cleaners, or abrasive materials, as these can damage the silicone.

Storage

Store the device in a clean, dry, and dust-free place, away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent material degradation.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Low battery.	Charge the device fully using the magnetic USB cable.
Vibrations are weak or inconsistent.	Low battery; device malfunction.	Ensure the device is fully charged. If the issue persists, contact customer support.
Cannot connect to Satisfyer Connect App.	Bluetooth not enabled; device not in pairing mode; app issue; device not compatible with phone.	Ensure Bluetooth is enabled on your smartphone. Put the device into pairing mode (hold Bluetooth button for 5 seconds). Restart the app and/or your smartphone. Check app store for device compatibility with your phone model.
Remote control not working.	Remote battery low; loss of connection.	Ensure the remote's battery is functional (if replaceable) or charged (if rechargeable). Try re-pairing the remote with the device (refer to remote's specific instructions if different from main device).

Specifications

Feature	Detail
Model Number	4061504002767
Dimensions (L x W x H)	5.91 x 4.72 x 4.72 inches
Weight	8.82 ounces
Material	Medical-grade Silicone
Battery Type	1 Lithium Ion battery (included)
Connectivity	Bluetooth (for app control)
Waterproof	Yes
Manufacturer	Satisfyer

Warranty and Support

Satisfyer offers a 15-year warranty on this product, ensuring long-lasting satisfaction and product quality. For warranty claims, technical support, or any questions regarding your device, please contact Satisfyer customer service through their official website

or the contact information provided with your purchase documentation.
You can visit the official Satisfyer website for more information: www.satisfyer.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question