

[Manuals.plus](#) /

› [Vagusicc](#) /

› Vagusicc C Shaped End Table with Charging Station User Manual

Vagusicc B0D2NW6SSS

Vagusicc C Shaped End Table User Manual

Model: B0D2NW6SSS

1. PRODUCT OVERVIEW

The Vagusicc C Shaped End Table is a versatile furniture piece designed for convenience and functionality in small spaces. It features a unique C-shaped base that slides under sofas or chairs, providing easy access to its surface. A built-in charging station with USB, Type-C, and standard AC outlets, along with a multi-pocket storage organizer, enhances its utility. This table is ideal for use in living rooms, bedrooms, or as a bedside companion.



Image 1.1: The Vagusicc C Shaped End Table, showcasing its design, integrated charging station, and side storage pockets.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always assemble the table according to the included instructions.
- Do not overload the table beyond its maximum weight capacity of 22 pounds (10 kg).
- Exercise caution when using the integrated charging station. Ensure all electrical connections are secure and avoid liquid spills near the outlets.
- Use the adjustable feet to properly level the table on uneven surfaces to prevent instability and potential tipping.
- Keep the power cord away from high-traffic areas to prevent tripping hazards.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Couch Side Table components (Engineered Wood top, Metal Frame)
- Integrated Charging Station (pre-installed in table top)
- Storage Pocket (fabric organizer)
- Installation Tool (e.g., Allen wrench)
- User Manual (this document)
- All necessary screws and fasteners

4. SETUP AND ASSEMBLY

The Vagusicc C Shaped End Table is designed for simple and straightforward assembly. Follow the numbered instructions provided in the included assembly guide for best results.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Frame:** Connect the metal frame pieces using the provided screws and installation tool. Ensure all connections are secure but do not overtighten.
3. **Attach Tabletop:** Secure the engineered wood tabletop to the assembled frame. The charging station will be pre-installed in the tabletop.
4. **Install Storage Pocket:** Attach the fabric storage pocket to the side of the table frame. This pocket is designed to be detachable for cleaning or repositioning.
5. **Adjust Leveling Feet:** Once assembled, place the table in its desired location. Adjust the four plastic leveling feet at the bottom of the frame to ensure the table is stable and does not wobble on uneven floors.
6. **Connect Power:** Plug the 4.9-foot power cord from the charging station into a standard wall outlet.



Image 4.1: Exploded view illustrating the simple assembly process of the table components.



Image 4.2: Detail of the C-shaped bottom frame and adjustable leveling feet for stability.

5. OPERATING INSTRUCTIONS

5.1 C-Shaped Design and Placement

The unique C-shaped base allows the table to slide easily under most sofas, chairs, or beds, bringing the tabletop surface closer to you. This design is particularly beneficial for small spaces, providing a convenient surface for various activities.

Pull it Closer

Slide it under the sofa for convenient working or studying.



Image 5.1: The table positioned under a sofa, demonstrating its utility for working or relaxing.

5.2 Integrated Charging Station

The table is equipped with a convenient charging station located on the side of the tabletop, designed to minimize the risk of spills. It includes:

- One (1) 125V/12A AC Power Outlet
- One (1) USB-A Port (5V/2A)
- One (1) USB-C Port (5V/2A)

This allows you to charge multiple devices simultaneously, such as phones, tablets, and laptops, without needing additional power strips. The 4.9-foot power cord provides flexibility in placement.



Image 5.2: Detailed view of the charging station, highlighting the various power outlets and USB ports.

5.3 Storage Pocket

A multi-functional storage pocket is attached to the side of the table, offering organized storage for various items. It includes one large pocket (approximately 14.35" x 9.59") suitable for tablets and magazines, and four smaller cloth bags for items like pens, remote controls, or mobile phones. The pocket is detachable for convenience.



Image 5.3: The side storage pockets, demonstrating their capacity and detachable design.

5.4 Versatile Uses

This C-shaped table can serve multiple purposes:

- **End Table:** A compact surface next to your sofa or armchair.
- **Under Couch Table:** Slides under furniture for close access.
- **TV Tray Table:** Convenient for meals or snacks while watching TV.
- **Laptop Table:** Provides a stable surface for working on a laptop or tablet.
- **Bedside Table:** A functional alternative to traditional nightstands, especially in tight spaces.



Image 5.4: The table serving as a bedside companion, highlighting its adaptability.

6. MAINTENANCE

Proper care will ensure the longevity of your Vagusicc C Shaped End Table.

- **Cleaning:** Wipe the engineered wood surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. The surface is designed to be waterproof and anti-scratch, making cleaning easy.
- **Spills:** Promptly wipe up any spills, especially near the charging station, to prevent damage.
- **Frame Care:** Clean the metal frame with a soft, dry cloth.
- **Storage Pocket:** The fabric storage pocket can be detached and spot cleaned as needed.
- **Weight Limit:** Do not exceed the stated load capacity of 22 lbs (10 kg) to prevent structural damage.



Image 6.1: Close-up showing the waterproof surface of the table, simplifying maintenance.

7. TROUBLESHOOTING

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
Table wobbles or is unstable.	Uneven floor surface; loose assembly screws.	Adjust the leveling feet at the bottom of the table until stable. Check and tighten all assembly screws.
Charging station not working.	Power cord not fully plugged in; wall outlet not active; device cable faulty.	Ensure the table's power cord is securely plugged into a live wall outlet. Test the wall outlet with another device. Try a different charging cable for your device.
Storage pocket detaches easily.	Improper attachment; excessive weight in pockets.	Ensure the storage pocket is correctly attached to the designated points on the frame. Avoid overloading the pockets with heavy items.

8. SPECIFICATIONS

Feature	Detail
Brand	Vagusicc
Model Number	B0D2NW6SSS
Material	Engineered Wood, Metal Frame, Fabric
Product Dimensions (D x W x H)	10.84"D x 16.35"W x 28.23"H (27.5cm D x 41.5cm W x 71.7cm H)
Color	Rustic Brown
Item Weight	6.5 Pounds (2.95 kg)
Load Capacity	Up to 22 lbs (10 kg)
Charging Station	1x AC Outlet (125V/12A), 1x USB-A Port (5V/2A), 1x USB-C Port (5V/2A)
Power Cord Length	4.9 feet (1.5 meters)
Special Features	C-shaped design, Integrated Charging Station, Storage Pocket, Adjustable Feet, Waterproof & Anti-scratch Surface




Image 8.1: Key dimensions and weight capacity of the Vagusicc C Shaped End Table.

9. WARRANTY AND SUPPORT

Vagusicc is committed to providing high-quality products and excellent customer service.

- **After-Sale Service:** If you have any questions or concerns regarding your Vagusicc C Shaped End Table, please do not hesitate to contact us. Our friendly and professional customer service team aims to respond within 24 hours.
- **Product Testing:** Every end table undergoes thorough and rigorous testing to ensure quality and durability.
- **Contact Information:** For support, please refer to the contact details provided on the product packaging or the official Vagusicc website.

