

[Manuals.plus](#) /

› [Insta360](#) /

› Insta360 Invisible Selfie Stick 85cm User Manual

Insta360 CINSCAVG

Insta360 Invisible Selfie Stick 85cm User Manual

Model: CINSCAVG

1. INTRODUCTION AND OVERVIEW

The Insta360 Invisible Selfie Stick 85cm is designed to enhance your 360-degree camera experience by automatically disappearing from your footage, creating unique third-person perspectives and impossible angles. This lightweight and portable accessory is compatible with Insta360 X4 and X3 cameras. It features a comfortable grip sleeve and extends to 85cm for wider shots, while retracting to a compact size for easy transport.



Image: The Invisible Selfie Stick in action, demonstrating how it disappears from 360-degree video, allowing for dynamic third-person shots.

2. WHAT'S IN THE BOX

Verify that all items are present in the package:

- Insta360 Invisible Selfie Stick 85cm
- Removable Grip Sleeve




Image: The Insta360 Invisible Selfie Stick and its separate grip sleeve, as included in the package.

3. SETUP

Follow these steps to prepare your Invisible Selfie Stick for use:

1. **Attach the Grip Sleeve:** If not already attached, unscrew the top cap of the selfie stick. Align the grip sleeve with the stick and slide it onto the handle section. Screw the top cap back on securely to hold the sleeve in place.
2. **Attach Your Camera:** Locate the 1/4-inch screw mount at the top of the selfie stick. Carefully screw your compatible Insta360 camera onto this mount until it is finger-tight. Do not overtighten.



Image: Visual guide demonstrating the process of sliding the grip sleeve onto the selfie stick and securing it.

4. OPERATING INSTRUCTIONS

Using your Invisible Selfie Stick is straightforward:

1. **Extend the Stick:** Hold the base of the stick and gently pull the top section upwards to extend it. Continue pulling each section until the desired length is reached, up to 85cm.
2. **Retract the Stick:** Push the extended sections back into the main body of the stick until it is fully collapsed.
3. **Invisible Effect:** When recording with a compatible Insta360 360-degree camera, the selfie stick will be automatically removed from your footage during post-processing or in the Insta360 app, creating an 'invisible' effect. Ensure your camera firmware and app are up to date for optimal performance.





Image: The selfie stick in its compact 194mm form (left) and fully extended to 850mm (right), illustrating its versatility.

5. MAINTENANCE

Proper care will ensure the longevity of your selfie stick:

- **Cleaning:** Wipe the stick and sleeve with a soft, dry, or slightly damp cloth. Avoid using abrasive cleaners or solvents, as these can damage the finish.
- **Storage:** Store the selfie stick in a dry place, away from direct sunlight and extreme temperatures. Ensure it is fully retracted before storage.
- **Inspection:** Periodically check the screw mount for any debris or wear. Ensure all sections extend and retract smoothly.

6. TROUBLESHOOTING

If you encounter any issues, refer to the following common solutions:

- **Camera Not Attaching Securely:** Ensure the 1/4-inch screw mount on the stick and the corresponding thread on your camera are clean and free of obstructions. Screw the camera on straight and tighten firmly by hand.
- **Stick Not Extending/Retracting Smoothly:** Check for any dirt, sand, or foreign objects lodged between the sections. Gently clean the sections. Do not apply excessive force, as this may cause damage.
- **Invisible Effect Not Working:** Confirm that you are using a compatible Insta360 360-degree camera (e.g., X4, X3). Ensure your camera's firmware and the Insta360 mobile app are updated to the latest versions. The effect is typically applied during editing in the Insta360 app or desktop software.

7. SPECIFICATIONS

Model Name	CINSCAVG
Brand	Insta360
Color	Black
Compatible Devices	Insta360 X4, Insta360 X3, and other 360° Cameras
Extended Length	850 mm (85 cm)
Folded Length	190 mm (19 cm)
Item Weight	120 Grams

Max Recommended Load	400 Grams
----------------------	-----------

8. WARRANTY AND SUPPORT

This Insta360 product is covered by a limited warranty. For specific warranty terms, conditions, and duration, please refer to the warranty card included with your product or visit the official Insta360 website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Insta360 customer service or visit their official brand store:

[Visit the Insta360 Brand Store](#)

Please retain your proof of purchase for warranty claims.