

Armitron 75-5943

Armitron Women's Genuine Diamond Dial Bracelet Watch

MODEL: 75-5943

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Armitron Women's Genuine Diamond Dial Bracelet Watch, model 75-5943. Please read this guide thoroughly to ensure proper use and care of your timepiece.

Product Overview

The Armitron 75-5943 is an elegant women's bracelet watch featuring a genuine diamond accent. Its design combines functionality with a sophisticated aesthetic.

- **Crystal:** Wall-to-wall faceted mineral crystal lens.
- **Dial:** Champagne sunray dial with a genuine diamond at the 12 o'clock position, complemented by gold-tone hands and markers.
- **Bracelet:** Gold-tone adjustable link bracelet with a jewelry clasp and extender.





Figure 1: Front view of the Armitron 75-5943 watch, showcasing the champagne dial and gold-tone bracelet.

Setup

Setting the Time

1. **Pull the Crown:** Gently pull the crown (the small knob on the side of the watch case) outwards to the time-setting position.
2. **Adjust the Time:** Rotate the crown clockwise or counter-clockwise to move the hands and set the desired time.
3. **Push the Crown Back:** Once the time is set, push the crown back into its original position to start the watch movement.





Figure 2: Side view illustrating the watch crown for time adjustment.

Adjusting the Bracelet

The watch features an adjustable link bracelet with a jewelry clasp and extender. To achieve a comfortable fit, links may need to be added or removed. While some minor adjustments can be made with the extender, significant resizing involving link removal or addition is best performed by a professional jeweler to prevent damage to the bracelet.





Figure 3: Back view displaying the bracelet and clasp mechanism.

Operating Your Watch

Basic Operation

Once the time is set and the crown is pushed back into place, your watch will begin to keep time. This watch operates on a quartz movement, providing accurate timekeeping.

Water Resistance

Important: This watch is **not water resistant**. Avoid all contact with water, including showering, swimming, or exposure to rain. Water exposure can cause irreversible damage to the watch movement.

Maintenance

Cleaning

To maintain the appearance of your watch, wipe the case and bracelet with a soft, dry cloth. Do not use chemical cleaners or abrasive materials, as these can damage the finish.

Battery Replacement

When the watch stops running, it indicates that the battery needs replacement. Battery replacement should be performed by a qualified watch technician to ensure the integrity of the watch and prevent damage.

Storage

When not wearing your watch, store it in a dry place, away from direct sunlight and extreme temperatures. The original

watch box (Figure 4) can provide suitable protection.



Figure 4: The Armitron watch presented in its box.

Troubleshooting

- **Watch Not Running:**

Ensure the crown is fully pushed in. If it is, the battery may need replacement. Consult a professional watch technician.

- **Time is Inaccurate:**

Check if the crown is accidentally pulled out. If not, the battery might be low, or the movement may require service. Seek professional assistance.

- **Bracelet Discomfort:**

If the bracelet is too tight or too loose, consider having links adjusted by a professional jeweler.

Specifications

Feature	Detail
Model Number	75-5943CHGP
Brand	Armitron
Dial	Champagne sunray with genuine diamond at 12
Crystal	Facetted mineral crystal
Bracelet	Gold-tone adjustable link, jewelry clasp with extender
Water Resistance	Not water resistant
Package Dimensions	4.37 x 3.15 x 2.91 inches
Item Weight	6.35 ounces

Warranty and Support

For detailed warranty information, please refer to the official Armitron website or the warranty card included with your purchase. For product support or service inquiries, please contact Armitron customer service directly. You can visit the official Armitron store for more products and information:[Armitron Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question