

## LEGO 71045

# LEGO Minifigures Series 25 Sprinter Instruction Manual

Model: 71045

## INTRODUCTION

Welcome to your LEGO Minifigures Series 25 Sprinter. This manual provides essential information for the assembly, care, and maintenance of your collectible minifigure. Please read these instructions carefully before assembly and use.

## SETUP

### Unboxing and Initial Assembly

Carefully open the packaging. Inside, you will find the Sprinter minifigure, its accessories, a baseplate stand, and a collector's leaflet.



Image: Packaging for LEGO Minifigures Series 25, indicating the collection of 12 unique figures. The Sprinter minifigure is one of these.

## Assembling the Sprinter Minifigure

1. Identify all components: Sprinter minifigure body, head, hair/helmet, and any specific accessories (e.g., running shoes, medal, water bottle).
2. Attach the head to the minifigure body.
3. Place the hair or helmet onto the head.
4. Attach any accessories to the minifigure's hands or body as depicted on the collector's leaflet.
5. Secure the assembled minifigure onto the provided baseplate stand.

Assembly typically takes approximately 1 minute. Ensure all pieces are securely connected.

## OPERATING

### Display and Play

The LEGO Minifigures Series 25 Sprinter is designed for display and imaginative play.

- **Display:** Use the included baseplate to stand your Sprinter minifigure upright on any flat surface.
- **Play:** This minifigure is compatible with any standard LEGO building set, allowing for integration into

larger LEGO creations and play scenarios.

*Note: This product contains small parts and is recommended for ages 5 and up.*

## MAINTENANCE

### Cleaning and Care

To maintain the quality and appearance of your LEGO Minifigures Series 25 Sprinter:

- **Cleaning:** Wipe with a soft, dry cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly with clean water. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store minifigures away from direct sunlight and extreme temperatures to prevent discoloration or damage to the plastic.
- **Handling:** Handle with care to prevent loss of small accessories.

This product does not contain electronic components.

## TROUBLESHOOTING

### Common Issues

If you encounter any issues with your Sprinter minifigure:

- **Loose Parts:** Ensure all connections are firm. LEGO elements are designed to fit snugly.
- **Missing Pieces:** Refer to the collector's leaflet to verify all included components. If a piece is genuinely missing from a new, sealed package, contact LEGO customer service.
- **Damage:** Avoid excessive force during assembly or play to prevent breakage.

For further assistance, please refer to the official LEGO customer support channels.

## SPECIFICATIONS

### Product Details

Feature	Detail
Brand	LEGO
Model Name	Minifigures Series 25 - Sprinter
Model Number	71045
Dimensions (L x W x H)	1.5 x 1 x 0.5 inches (approximate for minifigure)
Weight	9.07 g (approximate)
Material	Plastic
Recommended Age	5 years and up
Included Components	Minifigure, Accessories, Baseplate Stand, Collector's Leaflet

## WARRANTY AND SUPPORT

### Customer Service

For information regarding product warranty, missing parts, or further assistance, please visit the official LEGO website or contact their customer support directly.

[LEGO Customer Service](#)

---

© 2026 LEGO Group. All rights reserved.