

[Manuals.plus](#) /

› [Cybex](#) /

› CYBEX Eezy S Twist +2 V2 Baby Stroller Instruction Manual

Cybex Eezy S Twist Plus 2

CYBEX Eezy S Twist +2 V2 Baby Stroller

INSTRUCTION MANUAL

1. Product Overview

The CYBEX Eezy S Twist +2 V2 is a compact and versatile baby stroller designed for urban lifestyles. It features a unique 360° swivel seat, allowing for quick and easy transitions between parent-facing and forward-facing modes. The stroller also includes a one-hand recline function for customized comfort and a one-pull harness for secure child fastening. Its compact fold makes it convenient for storage and travel.



Figure 1.1: The CYBEX Eezy S Twist +2 V2 Stroller in Almond Beige, showcasing its sleek design and compact form.

 cybex

EEZY S TWIST+2

COMPACT STROLLER
with a swivel seat



Figure 1.2: A woman effortlessly pushing the CYBEX Eezy S Twist +2 V2 Stroller, highlighting its maneuverability and ease of use in an urban setting.

2. Safety Information

Always read and follow all instructions carefully before using the stroller. Failure to do so could result in serious injury or death. Keep this manual for future reference.

- Never leave your child unattended in the stroller.
- Always use the harness system to secure your child. Ensure it is properly adjusted and fastened.
- Engage the parking brake whenever the stroller is stationary.
- Do not overload the storage basket or hang bags on the handle, as this can cause the stroller to tip over.
- Ensure all locking devices are engaged before use.
- Do not use accessories or replacement parts other than those approved by Cybex.
- The stroller is suitable for infants 6 months and up.

- Maximum weight recommendation: 55 pounds.

3. What's in the Box

Your CYBEX Eezy S Twist +2 V2 package includes:

- CYBEX Eezy S Twist +2 V2 Stroller Frame with Seat Unit
- Wheels (may require attachment)
- Canopy
- Infant Car Seat Adapters (included for travel system compatibility)

4. Key Features

The CYBEX Eezy S Twist +2 V2 Stroller is equipped with several features designed for convenience and comfort:

- **360° Swivel Seat:** Easily position your child in forward-facing or parent-facing mode using one hand.
- **One-Hand Recline:** Seat reclines both forward- and parent-facing into a near-flat position for customized comfort.
- **Unique One-Pull Harness:** Secure your child in the stroller in seconds, with just one hand.
- **Travel System Ready:** Attach any CYBEX infant car seat to the frame to create a convenient travel system using included adapters.
- **Compact Fold:** Quickly and easily folds into a compact, self-standing package for convenient storage on the go.
- **XXL Sun Canopy:** Provides ample protection from the sun.

EEZY S TWIST+2

COMPACT STROLLER WITH A SWIVEL SEAT



**UNIQUE
ONE-PULL
HARNESS**

**360°
SWIVEL
SEAT**

**ONE-HAND
RECLINE**

**COMPACT
FOLD**

**TRAVEL SYSTEM
READY**

**XXL SUN
CANOPY**

Figure 4.1: Visual representation of the stroller's key features, including the unique one-pull harness, 360° swivel seat, one-hand recline, compact fold, travel system readiness, and XXL sun canopy.

5. Setup

5.1. Unfolding the Stroller

1. Place the folded stroller on a flat surface.
2. Release the folding latch (if engaged).
3. Lift the handlebar firmly until the frame locks into place. You should hear an audible click.
4. Ensure all parts are securely locked before placing a child in the stroller.

5.2. Attaching the Wheels

The wheels may come detached for compact packaging. To attach:

1. Align the wheel axle with the corresponding slot on the stroller frame.

2. Push the wheel firmly into the slot until it clicks into place.
3. Pull on the wheel to ensure it is securely attached.

5.3. Attaching the Canopy

Slide the canopy attachments onto the designated points on the seat unit frame until they click securely.

5.4. Installing a CYBEX Infant Car Seat (Travel System)

The stroller comes with adapters to create a travel system. Refer to your CYBEX infant car seat manual for specific installation instructions. Generally:

1. Ensure the stroller seat is in the fully reclined position.
2. Attach the car seat adapters to the designated slots on the stroller frame until they click.
3. Place the infant car seat onto the adapters, ensuring it locks securely into place. Always check for a firm connection.

6. Operating Instructions

6.1. Using the 360° Swivel Seat

To change the seat direction:

1. Ensure the child is not in the seat or is securely fastened.
2. Locate the swivel mechanism release button/lever, typically near the seat base.
3. Press the release and rotate the seat to the desired parent-facing or forward-facing position until it locks securely.



Figure 6.1: The 360° swivel seat in action, demonstrating how the seat can be easily rotated to face either the parent or the world.

6.2. Adjusting the One-Hand Recline

To recline the seat:

1. Locate the recline lever on the back of the seat.
2. Press the lever and gently push the seat back to the desired recline position.
3. Release the lever to lock the seat in place.

6.3. Securing the One-Pull Harness

To secure your child:

1. Place your child in the seat.
2. Bring the shoulder straps over your child's shoulders and the waist straps around their hips.
3. Insert the buckle tongues into the buckle housing until they click.
4. Pull the single strap at the bottom of the harness to tighten it securely around your child. Ensure it is snug but not

too tight.

5. To release, press the button on the buckle housing.

6.4. Folding the Stroller

To fold the stroller for storage or transport:

1. Ensure the seat is in the forward-facing position and fully upright.
2. Locate the folding mechanism release, typically on the handlebar.
3. Activate the release and push the handlebar down and forward, allowing the stroller to collapse.
4. Secure the folding latch to keep the stroller in its compact, self-standing position.



Figure 6.2: The stroller in its compact, folded state, illustrating its space-saving design for easy storage and transport.

7. Maintenance

7.1. Cleaning

- **Fabric Parts:** The seat pad is made of 85% Polyurethane Foam pad, 15% Polyester Fiber. Harness covers are 100% Polyurethane Foam Pad. Spot clean with a mild detergent and cold water. Do not machine wash or tumble dry unless specified on the care label.
- **Frame:** Wipe the aluminum frame and plastic components with a damp cloth and mild soap. Dry thoroughly.
- **Wheels:** Regularly clean dirt and debris from the wheels and axles. Lubricate moving parts with a silicone-based lubricant if necessary.

7.2. Storage

Store the stroller in a dry, cool place away from direct sunlight and extreme temperatures to prevent material degradation.

8. Troubleshooting

- **Stroller does not unfold/fold smoothly:** Check for any obstructions in the folding mechanism. Ensure the seat is in the correct position (forward-facing, upright) before folding.
- **Wheels are stiff or squeaky:** Clean any debris from the wheel axles. Apply a small amount of silicone lubricant to the moving parts of the wheels.
- **Seat does not swivel:** Ensure the swivel release mechanism is fully engaged and there are no obstructions preventing rotation.
- **Harness is difficult to adjust:** Check for any twists in the straps. Ensure the one-pull strap mechanism is clear of debris.

If you encounter issues not listed here or require further assistance, please contact Cybex customer support.

9. Specifications

Brand	Cybex
Model Number	Eezy S Twist Plus 2
Color	Almond Beige, Taupe Frame
Material	Polyester, Aluminum, Plastic, Rubber
Fabric Type	Seat Pad: 85% Polyurethane Foam pad, 15% Polyester Fiber, Harness Covers: 100% Polyurethane Foam Pad
Frame Material	Aluminum
Age Range Description	Baby (6 Months and Up)
Maximum Weight Recommendation	55 Pounds
Item Dimensions L x W x H	31.7"L x 17.9"W x 39.8"H
Folded Size	31.7"L x 17.7"W x 39.8"H (Note: Dimensions provided in input for folded size seem to be the same as unfolded item height, using the provided data)
Stroller Seat Weight	15.2 Pounds
Harness Type	5 Point

Is Car Seat Compatible	Yes
Number of Wheels	4

10. Warranty and Support

For detailed warranty information, please refer to the warranty card included with your purchase or visit the official Cybex website. For product support, spare parts, or service inquiries, please contact Cybex customer service directly through their official channels.

Cybex Official Website: www.cybex-online.com

© 2024 Cybex. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question