UGREEN 45376

UGREEN Magnetic Phone Stand User Manual

Model: 45376 | Brand: UGREEN

1. Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your UGREEN Magnetic Phone Stand. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

2. Product Overview

The UGREEN Magnetic Phone Stand is designed to securely hold your smartphone, offering adjustable viewing angles and height for enhanced ergonomic comfort. Its robust construction and powerful magnetic attachment ensure stability for various uses.

Key Features:

- **Powerful Magnetic Force:** Equipped with 1600g magnetic attraction force and N52 magnets for secure phone fixation.
- **Adjustable Height:** Extends from 4.7 to 5.9 inches (120mm to 150mm) for personalized viewing.
- **360° Rotation:** The metal base supports full 360° rotation, allowing easy switching between portrait and landscape modes.
- **180° Angle Adjustment:** Flexible shaft allows for a wide range of tilt angles.
- **Foldable & Compact:** Folds to 1.06 inches (27mm) thick for easy portability.
- **Broad Compatibility:** Compatible with iPhone 12 series and later (including 17/16/15/14/13/12 series) and MagSafe cases. Includes a magnetic metal ring for non-MagSafe phones and cases.



Figure 2.1: UGREEN Magnetic Phone Stand in various configurations.

Official Product Video:

Your browser does not support the video tag.

Video 2.1: Official UGREEN Magnetic Phone Stand overview, demonstrating key features and functionality.

3. Setup Instructions

1. **Unpack the Stand:** Carefully remove the phone stand from its packaging.
2. **Position the Stand:** Place the stand on a flat, stable surface. The large metal base with anti-slip pads ensures stability.
3. **Adjust Initial Height and Angle:** Gently extend the stand to your desired height and adjust the magnetic head to a comfortable viewing angle. The stand features a flexible shaft for 180° angle adjustment.
4. **Attach Your Phone:**
    - **For MagSafe Compatible Phones/Cases (iPhone 12 series and later):**Simply align your phone or MagSafe case with the magnetic head of the stand. The powerful magnets will securely attach your device.

- **For Non-MagSafe Phones/Cases (iPhone 11 and earlier models, Android devices, or non-MagSafe cases):** Use the included magnetic metal ring. Clean the back of your phone or phone case thoroughly. Peel off the adhesive backing from the metal ring and carefully center it on the back of your device or case. Press firmly for 30 seconds. Allow 24 hours for the adhesive to fully cure before attaching to the stand. *Note: The metal ring is suitable for TPU/PC and other plastic materials, not for silicone, leather, or fabric. For phones with cases, stick the metal ring on the surface of the phone case.*



Figure 3.1: Compatibility and use of the magnetic metal ring for non-MagSafe devices.

4. Operating Instructions

The UGREEN Magnetic Phone Stand offers versatile adjustments to suit your needs.

- **Height Adjustment:** To adjust the height, gently pull the extendable arm upwards or push it downwards. The stand can extend up to 5.90 inches (150mm) high.
- **Angle Adjustment:** The magnetic head can be tilted 180° on its flexible shaft to achieve your preferred viewing angle.

- **360° Rotation:** The metal base of the stand allows for a full 360° rotation. This enables seamless switching between portrait and landscape orientations without re-positioning your phone.
- **One-Handed Operation:** The strong magnetic connection allows for easy one-handed attachment and removal of your phone.



Figure 4.1: Demonstrating 180° angle adjustment and 360° swivel base.



Figure 4.2: Illustrating the adjustable height feature.

5. Maintenance

- **Cleaning:** Wipe the stand with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Storage:** When not in use or for travel, fold the stand to its compact form to protect its mechanisms.
- **Avoid Over-forcing:** Do not apply excessive force when adjusting the height or angle to prevent damage to the hinges.



Figure 5.1: The stand's foldable design for easy storage and portability.

6. Troubleshooting

- **Phone not attaching securely:**
  - Ensure your phone or case is MagSafe compatible.
  - If using the metal ring, verify it is correctly centered and securely attached to a compatible case material.
  - Check for any obstructions between the phone/case and the magnetic head.
- **Stand feels unstable:**
  - Ensure the stand is placed on a flat, level, and stable surface.
  - Verify that the anti-slip pads on the base are clean and intact.
- **Difficulty adjusting height or angle:**
  - The hinges are designed to be firm for stability. Apply steady, gentle pressure.

- Avoid forcing movements beyond the specified 180° angle or maximum height.

7. Specifications

Brand	UGREEN
Model Number	45376
Color	Black
Item Weight	9.9 ounces
Package Dimensions	5.98 x 4.76 x 1.14 inches
Form Factor	Adjustable and Foldable Stand
Compatible Devices	Smartphones (iPhone 12 series and later, Android with magnetic ring)
Magnetic Force	1600g (N52 Magnets)
Height Adjustment Range	4.7 - 5.9 inches (120mm - 150mm)
Angle Adjustment	180° Flexible Shaft
Rotation	360° Swivel Base



Figure 7.1: Dimensional information of the phone stand.

8. Warranty and Support

UGREEN products are designed and manufactured to the highest quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact details provided with your product packaging or visit the official UGREEN website. Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question