

GDFStudio Outdoor Wicker Hanging Chair with Stand

GDFStudio Outdoor Wicker Hanging Chair with Stand Instruction Manual

Model: Outdoor Wicker Hanging Chair with Stand

INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your GDFStudio Outdoor Wicker Hanging Chair with Stand. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product. Retain this manual for future reference.

SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity of 400 lbs (approximately 181 kg). Overloading can cause structural failure and injury.
- **Assembly:** Ensure all components are securely fastened according to the assembly instructions. Improper assembly can lead to instability.
- **Placement:** Place the chair on a flat, stable, and level surface. Uneven surfaces can cause the chair to tip over.
- **Clearance:** Ensure adequate clearance around the chair to prevent collisions with walls, furniture, or other objects during swinging.
- **Children and Pets:** Keep children and pets away from the chair during assembly. Supervise children when they are near or using the chair.
- **Weather Conditions:** While designed for outdoor use, extreme weather conditions (strong winds, heavy rain, snow) may require the chair to be moved indoors or covered to prevent damage.
- **Inspection:** Regularly inspect all parts for wear, damage, or loose connections. Do not use the chair if any part is damaged or compromised.
- **Standing:** Do not stand on the chair or stand on the cushion.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Hanging Chair Basket (Faux Rattan and Iron Frame)
- Steel Stand (Iron)
- Suspension Chain and Spring Mechanism
- Water-Resistant Cushion (100% Polyester)
- Assembly Hardware (Bolts, Washers, Nuts, Wrench - typically included)

SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended that two adults assemble the chair. Clear a spacious area for assembly and keep all parts within reach.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Assemble the Base:** Connect the base sections of the stand. Ensure all bolts are finger-tightened initially.
3. **Attach the Upright Pole:** Secure the curved upright pole to the assembled base. Align holes and insert bolts.
4. **Tighten All Connections:** Once all stand components are loosely assembled, fully tighten all bolts using the provided wrench. Ensure the stand is stable and does not wobble.
5. **Attach Suspension Mechanism:** Connect the spring and chain to the top hook of the stand.
6. **Hang the Chair Basket:** Carefully lift the chair basket and attach its hanging loop to the chain. Ensure the connection is secure.
7. **Place Cushion:** Position the water-resistant cushion inside the chair basket for comfort.



Figure 1: Product Dimensions. Refer to this diagram for overall measurements during setup.



Figure 2: Detail of the suspension chain and spring mechanism. Ensure secure attachment.

OPERATING INSTRUCTIONS (USAGE)

To ensure a safe and enjoyable experience with your hanging chair:

- **Entering the Chair:** Approach the chair carefully. Sit down gently, distributing your weight evenly. Avoid jumping or forcefully dropping into the chair.
- **Swinging:** The chair is designed for gentle swinging. Avoid excessive or aggressive swinging, which can strain the stand and suspension components.
- **Exiting the Chair:** Stand up slowly and carefully, maintaining balance.
- **Single User:** This chair is designed for single-person use within its weight capacity.



Figure 3: GDFStudio Outdoor Wicker Hanging Chair in use on a patio.

MAINTENANCE AND CARE

Regular maintenance will help preserve the appearance and extend the life of your hanging chair.

- **Cleaning Wicker and Frame:** Wipe down the faux rattan and iron frame with a soft cloth dampened with mild soap and water. Rinse thoroughly and dry completely to prevent rust or water spots. Avoid harsh chemicals or abrasive cleaners.
- **Cushion Care:** The cushions are water-resistant. For general cleaning, spot clean with a mild soap solution and a soft brush. Allow to air dry completely. For prolonged outdoor exposure or heavy rain, it is recommended to store cushions indoors to prevent mildew and fading.
- **Hardware:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten as necessary.
- **Storage:** During off-seasons or periods of non-use, store the chair and stand in a dry, protected area to prevent weather damage. Using a furniture cover is also recommended for outdoor storage.



Figure 4: Detail of the water-resistant cushion fabric.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair wobbles or is unstable.	Uneven surface; loose bolts.	Move chair to a level surface. Check and tighten all assembly bolts.
Squeaking noise during swinging.	Friction in suspension components (spring, chain, hook).	Apply a small amount of silicone lubricant to the spring, chain links, and hook points.
Cushion appears flattened or misshapen.	Prolonged compression; moisture retention.	Fluff the cushion regularly. Ensure it is completely dry after cleaning or rain. Store indoors when not in use.
Rust spots on metal frame.	Exposure to moisture; scratches in protective coating.	Clean and dry immediately. Lightly sand rust spots and apply rust-inhibiting paint. Store in a dry area.

SPECIFICATIONS

- Brand:** GDFStudio
- Model:** Outdoor Wicker Hanging Chair with Stand
- Material (Chair):** Faux Rattan, Iron Frame
- Material (Stand):** Iron
- Cushion Material:** Water Resistant Fabric (100% Polyester)
- Weight Capacity:** 400 lbs (181 kg)
- Chair Dimensions:** 25.00" D x 34.50" W x 46.25" H (63.5 cm D x 87.6 cm W x 117.5 cm H)
- Seat Dimensions:** 20.50" D x 25.50" W x 1.00" H (52.1 cm D x 64.8 cm W x 2.5 cm H)
- Stand Dimensions:** 44.00" D x 44.00" W x 80.00" H (111.8 cm D x 111.8 cm W x 203.2 cm H)
- Assembly:** Required

WARRANTY AND SUPPORT

For warranty information or assistance with your GDFStudio Outdoor Wicker Hanging Chair with Stand, please refer to your purchase documentation or contact GDFStudio customer support directly. Ensure you have your purchase receipt and product model information available when contacting support.

GDFStudio Customer Support: Please visit the official GDFStudio website or refer to your product packaging for contact details.