Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DEEBYCOO P03

DEEBYCOO Key Finder P03 Instruction Manual

Model: P03

1. Introduction

The DEEBYCOO Key Finder P03 is a compact Bluetooth tracker designed to help you locate your valuable items using the Apple Find My network. This device is compatible exclusively with iOS devices (iPhone, iPad) and integrates seamlessly with the native Find My app, requiring no additional applications or subscription fees. It features a replaceable battery, privacy protection, and various alert functions to ensure you can always find your belongings.

2. Setup Guide

Follow these steps to set up your DEEBYCOO Key Finder P03 and connect it to your Apple Find My app:

1. **Enable Find My and Bluetooth:** On your iPhone or iPad, ensure that the Find My app is installed and enabled, and Bluetooth is turned on in your device settings.
2. **Activate the Key Finder:** Press the button on your DEEBYCOO Key Finder P03 to turn it on. You can confirm its status by pressing the button.
3. **Add Item in Find My App:** Open the Find My app on your iOS device. Navigate to the 'Items' tab and tap the '+' icon. Select 'Add New Item' or 'Add Other Supported Item'.
4. **Connect:** The app will search for nearby compatible items. Tap 'Connect' when your DEEBYCOO Key Finder P03 appears on the screen.
5. **Name and Customize:** Follow the on-screen prompts to name your item (e.g., "Keys," "Wallet," "Backpack") and choose an emoji to represent it.
6. **Agree to Terms:** Review and agree to the privacy and registration terms.
7. **Complete Registration:** Once registered, your Key Finder will appear in the 'Items' tab of your Find My app, ready for use.




Image: Visual guide showing the step-by-step process of connecting the DEEBYCOO Key Finder P03 to the Apple Find My application on an iPhone, from enabling Bluetooth to naming the item.

3. Operating Instructions

Utilize the various features of your DEEBYCOO Key Finder P03 through the Apple Find My app:

3.1 Locating Your Item

- **View on Map:** Open the Find My app and select the 'Items' tab. Tap on your DEEBYCOO Key Finder P03 to see its last known location on a map.
- **Play Sound:** If your item is nearby, tap 'Play Sound' in the Find My app. The Key Finder will emit an audible alert (up to 100 decibels) to help you pinpoint its exact location.




Image: A hand holding an iPhone displaying the Find My app with the 'Play Sound' option, next to a couch where the Key Finder is hidden, illustrating the sound alert feature.

3.2 Left-Behind Alerts

Receive instant notifications if you leave your item behind:

- **Enable Alerts:** In the Find My app, select your Key Finder, then enable 'Notify When Left Behind'. You can customize safe locations where you don't want to receive alerts.
- **Notification:** If you move away from your item, your iPhone or iPad will send a notification indicating its last detected location.




Image: An iPhone displaying a 'Time Sensitive' notification for a 'Key' left behind, with a person walking out a door in the background, demonstrating the left-behind alert feature.

3.3 Lost Mode

If your item is truly lost, activate Lost Mode:

- **Activate Lost Mode:** In the Find My app, select your Key Finder and enable 'Lost Mode'.
- **Contact Information:** You can enter a phone number and a message that will be displayed to anyone who finds your item and scans the Key Finder.
- **Find My Network:** The vast Apple Find My network will anonymously and securely help locate your item. If another Apple device user passes by your lost item, its location will be updated in your Find My app.




Image: A hand holding the DEEBYCOO Key Finder P03 next to an iPhone screen showing the 'About this Micflip P03' information within the Find My app, illustrating the Lost Mode functionality.

3.4 Share with Friends and Family

You can share the location of your items with trusted contacts:

- **Share Item:** In the Find My app, select your Key Finder and choose the option to 'Share This Item'. Select contacts from your address book to share its location.



Image: A collage showing individuals interacting with their phones, demonstrating the ability to share the location of tracked items with friends and family through the Find My app.

4. Maintenance

4.1 Battery Replacement

The DEEBYCOO Key Finder P03 uses a replaceable CR2032 coin cell battery, providing up to one year of battery life. When the battery is low, you will receive a notification in the Find My app.

1. **Open the Casing:** Gently twist or pry open the casing of the Key Finder to access the battery compartment. Refer to the diagram below for guidance.
2. **Remove Old Battery:** Carefully remove the old CR2032 battery.
3. **Insert New Battery:** Insert a new CR2032 battery with the positive (+) side facing up.
4. **Close Casing:** Securely close the casing of the Key Finder.




Image: A diagram illustrating the DEEBYCOO Key Finder P03 with its casing open, showing the CR2032 battery being replaced, highlighting the long-lasting and replaceable battery feature.



Image: A visual representation of the DEEBYCOO Key Finder P03 with its internal components, emphasizing the replaceable CR2032 battery and its long-lasting nature.

5. Troubleshooting

If you encounter issues with your DEEBYCOO Key Finder P03, try the following solutions:

- **Device Not Connecting:**
  - Ensure Bluetooth is enabled on your iOS device.
  - Make sure the Key Finder battery is not depleted. Replace if necessary.
  - Restart your iOS device and try pairing again.
  - Ensure the Find My app is updated to the latest version.
- **No Sound from Key Finder:**
  - Check if the Key Finder is within Bluetooth range of your iOS device.
  - Verify the battery level. A low battery might affect sound output.
- **Inaccurate Location:**
  - Location accuracy depends on the density of the Apple Find My network. In areas with fewer Apple devices, location updates may be less frequent or precise.
  - Ensure Location Services are enabled for the Find My app on your iOS device.
- **Left-Behind Alerts Not Working:**
  - Confirm that 'Notify When Left Behind' is enabled for your Key Finder in the Find My app.
  - Check if you have set any 'safe locations' where alerts are suppressed.

6. Specifications

Brand	DEEBYCOO
Model	P03
Connectivity Technology	Bluetooth, NFC
Compatible Devices	Smartphone, Tablet (iOS only)
Battery Type	CR2032 Coin Cell (included)
Battery Life	Up to 12 months
Audible Noise	100 Decibels
Material	Aluminum, Plastic
Item Weight	0.07 Kilograms

7. Warranty and Support

For warranty information and customer support, please refer to the product packaging or contact DEEBYCOO customer service directly. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D2SP6YR9

More documents and user manuals: **https://manuals.plus/**