Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

aoluiwlis A18-135P1A

aoluiwlis Chicony A18-135P1A 135W AC Power Adapter User Manual

Model: A18-135P1A / AD065G2Uz

1. Introduction

Thank you for choosing the aoluiwlis Chicony A18-135P1A 135W AC Power Adapter. This adapter is designed to provide reliable power to compatible Acer laptops. This manual provides important information on how to properly set up, operate, maintain, and troubleshoot your power adapter to ensure optimal performance and safety.



Image 1.1: The aoluiwlis Chicony A18-135P1A 135W AC Power Adapter.

2. Setup Instructions

Follow these steps to correctly set up your AC power adapter:

1. **Unpack the Adapter:** Carefully remove the power adapter and any included cables from its packaging. Verify that you have received one power adapter.
2. **Check Compatibility:** Ensure that your laptop's power requirements (voltage and amperage) match the adapter's

output specifications (19.5V, 6.92A, 135W) and that the plug size (5.5x1.7mm) is compatible with your laptop's power input port. This adapter is compatible with various Acer models, including AN515-55-544R and A715-75G.

3. **Connect to Laptop:** Insert the adapter's output plug (DC connector) firmly into the power input port on your laptop.



Image 2.1: The 5.5x1.7mm DC output plug of the adapter.

4. **Connect to Power Outlet:** Plug the AC input cable into the adapter's input port. Then, insert the other end of the AC input cable into a standard wall power outlet (100-240V, 50-60Hz).



Image 2.2: The AC input port on the power adapter.

5. **Verify Connection:** Once connected, your laptop should indicate that it is receiving power or charging.

3. Operating Instructions

The power adapter is designed for straightforward operation:

- **Powering Your Laptop:** Connect the adapter as described in the Setup section. The adapter will supply power to your laptop and charge its battery simultaneously.
- **Charging Indicator:** Most laptops have an indicator light that illuminates when the battery is charging. Refer to your laptop's manual for specific details.
- **Safety Precautions:**
  - Do not expose the adapter to water or excessive moisture.
  - Avoid using the adapter in extremely hot or cold environments.

- Do not attempt to open or modify the adapter.
- Ensure proper ventilation around the adapter during use to prevent overheating.
- Use only with compatible devices and power outlets.

4. Maintenance

Proper maintenance helps extend the life of your power adapter:

- **Cleaning:** Disconnect the adapter from both the laptop and the wall outlet before cleaning. Use a soft, dry cloth to wipe the exterior of the adapter. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place. Avoid tightly winding the cables, which can cause damage over time.
- **Cable Care:** Regularly inspect the power cables for any signs of fraying, cuts, or damage. If any damage is observed, discontinue use and replace the cable or adapter.

5. Troubleshooting

If you encounter issues with your power adapter, try the following steps:

- **No Power/Charging:**
  - **Check Power Outlet:** Ensure the wall outlet is functional by plugging in another device.
  - **Verify Connections:** Make sure all cables are securely connected to the adapter and the laptop.
  - **Inspect Cables:** Check for any visible damage to the power cables or adapter.
  - **Restart Laptop:** Sometimes a simple laptop restart can resolve power issues.
- **Adapter Overheating:**
  - Ensure the adapter is in a well-ventilated area and not covered.
  - Disconnect for a few minutes to allow it to cool down.
- **Incorrect Plug Size:** If the plug does not fit your laptop, verify the plug size (5.5x1.7mm) against your laptop's specifications. This adapter is designed for specific Acer models.

If the problem persists after attempting these steps, contact customer support for further assistance.

6. Specifications

Detailed technical specifications for the aoluiwlis Chicony A18-135P1A AC Power Adapter:



Image 6.1: Product label with electrical specifications and certifications.

Feature	Specification
Brand	aoluiwlis
Model Number	A18-135P1A / AD065G2Uz
Input Voltage	100-240V ~ 50-60Hz
Output Voltage	19.5V

Feature	Specification
Output Current	6.92A
Power Output	135W
Adapter Plug Size	5.5mm x 1.7mm
Compatible Brand	For Acer
Compatible Devices	Acer Aspire, Acer Predator, Acer Nitro, and other Acer laptop models (e.g., AN515-55-544R, A715-75G)
Included Components	1 x Power Adapter

7. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your purchase receipt as proof of purchase.

© 2023 aoluiwlis. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D2TTHJP3

More documents and user manuals: **https://manuals.plus/**