

[Manuals.plus](#) /

› [Fotopro](#) /

› Fotopro 59-inch Carbon Fiber Travel Tripod User Manual

Fotopro CSPTSJ32CYPLBK

Fotopro 59-inch Carbon Fiber Travel Tripod User Manual

Model: CSPTSJ32CYPLBK

1. INTRODUCTION

Thank you for choosing the Fotopro 59-inch Carbon Fiber Travel Tripod. This versatile and lightweight tripod is designed for photographers and videographers seeking portability and stability. Crafted from durable carbon fiber, it features a smooth hydraulic head, adjustable leg angles, and a detachable monopod function, making it suitable for various shooting environments and creative needs.

Please read this manual thoroughly before using your tripod to ensure proper operation and to maximize its lifespan.

Your browser does not support the video tag.

Official product video demonstrating the compact carbon fiber video tripod features and usage.

2. PRODUCT COMPONENTS

Your Fotopro Carbon Fiber Travel Tripod package includes the following items:

- Fotopro Carbon Fiber Tripod with Fluid Head
- Arca-Swiss Quick Release Plate
- Carrying Bag
- Removable Rubber Feet (pre-installed or as accessories)
- Allen Wrenches (for adjustments)
- Shoulder Strap

2-1 Tripod and Monopod



Detailed view of the tripod's key components and features.

3. SETUP GUIDE

Follow these steps to set up your tripod for use:

1. **Unfold the Tripod:** Gently spread the tripod legs until they lock into position. The legs have three levels of adjustment for various angles.
2. **Adjust Leg Length:** Loosen the twist locks on each leg section, extend the legs to your desired height, and then firmly tighten the twist locks to secure them.
3. **Adjust Center Column:** If additional height is needed, loosen the center column lock, raise the center column, and then tighten the lock.
4. **Attach Camera:** Secure your camera to the Arca-Swiss quick release plate. Then, attach the quick release plate with your camera to the fluid head, ensuring it is locked firmly in place.
5. **Level the Tripod:** Use the integrated bubble level on the fluid head to ensure your camera is perfectly level for stable shots.

X-GO CARBON E2 LIGHTWEIGHT TRIPOD

**ULTRA LIGHTWEIGHT
IDEAL FOR TRAVEL**



Weight only

2.35 lbs
(1.07kg)

FOLDED

16.1
inches
(41cm)



The tripod's compact folded size makes it ideal for travel and easy storage in a backpack.

4. OPERATING INSTRUCTIONS

4.1. Adjusting Height and Leg Angles


The tripod features 5-section legs with twist locks for quick height adjustments. The legs can extend from a minimum of 13.38 inches (34 cm) to a maximum of 59.8 inches (152 cm). Each leg also offers three adjustable angles, allowing for stable positioning on uneven terrain or for low-angle shots.

Adjustable Height Tripod



Visual guide to the tripod's adjustable height settings.

3 Gears alternative leg angles



Examples of the tripod's three adjustable leg angles for diverse shooting scenarios.

4.2. Using the Fluid Head

The smooth hydraulic head is designed for fluid panning and tilting, making it ideal for video recording. It supports cameras up to 5 kg (11 lbs). Use the handle to control movements and the locking knobs to secure your desired position.

4.3. Monopod Conversion


One of the tripod legs can be detached and combined with the center column and ball head to form a monopod. This feature is useful for situations requiring quick mobility or when a full tripod is impractical. The monopod can also serve as a trekking pole or selfie stick.

- To convert: Unscrew the designated leg from the tripod body.
- Remove the center column from the tripod.
- Attach the ball head to the top of the detached leg.
- Optionally, attach the center column to the leg for extended monopod height.

Fotopro Multifunctional Tripod



Remove the monopod leg tube from the tripod



Attach the ball head to the monopod leg



Twist the hook and center column, then combine the leg and center column



Hiking stick



Monopod



selfie stick



Ball Head + Monopod Leg

Ball Head + Centre Column + Monopod Leg

Instructions for converting the tripod into a monopod for increased versatility.

4.4. Counterweight Hook

For added stability, especially with heavier camera equipment or in windy conditions, utilize the removable counterweight hook located at the bottom of the center column. Attach a bag or weight to this hook to lower the tripod's center of gravity.

5. MAINTENANCE

- **Cleaning:** After use, especially in dusty or sandy environments, wipe down the tripod legs and head with a soft, damp cloth. Avoid harsh chemicals.
- **Lubrication:** Periodically check the twist locks and moving parts. If they feel stiff, apply a small amount of silicone-based lubricant.
- **Storage:** Store the tripod in its carrying bag in a dry, cool place away from direct sunlight and extreme temperatures.
- **Inspection:** Regularly inspect all screws, joints, and locks for any signs of wear or damage. Tighten any loose

components using the provided Allen wrenches.

6. TROUBLESHOOTING

- **Tripod is Unstable:**
 - Ensure all leg sections and the center column are fully extended and securely locked.
 - Verify that the leg angles are set appropriately for the terrain.
 - Consider using the counterweight hook for added stability.
- **Fluid Head Movement is Not Smooth:**
 - Check that all locking knobs on the fluid head are sufficiently loosened for movement.
 - Clean any dust or debris from the head's moving parts.
- **Leg Sections Stick or are Hard to Extend/Retract:**
 - Clean the leg sections and twist locks to remove any accumulated dirt or sand.
 - Apply a small amount of silicone lubricant to the threads of the twist locks.

7. SPECIFICATIONS

Feature	Detail
Model Number	CSPTSJ32CYPLBK
Material	Carbon Fiber
Item Weight	1.07 kg (2.35 lbs)
Maximum Load Capacity (Fluid Head)	5 kg (11 lbs)
Maximum Load Capacity (Tripod)	10 kg (22 lbs)
Maximum Height	152 cm (59.8 inches)
Minimum Height	34 cm (13.38 inches)
Folded Length	41 cm (16.1 inches)
Leg Sections	5
Tripod Head Type	Fluid Head
Monopod Function	Yes
Color	Green



Product Data

Max Height	152.4cm/60inch
Folded Length	41cm/16.1inch
Leg Sections	5 Sections
Max Load	5kg/11lbs
Tube Dia	22mm/0.86inch
Weight	1.07kg/2.35lbs
Ball Head Dia	25mm/0.98inch
with Monpod	Yes

Key product data and dimensions for the tripod.

8. WARRANTY INFORMATION

Fotopro products are covered by a limited warranty against defects in materials and workmanship. Please refer to the warranty card included in your package or visit the official Fotopro website for detailed terms and conditions. Keep your purchase receipt as proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

For any questions, technical assistance, or support regarding your Fotopro tripod, please contact our customer service team:

- **Online Support:** Visit the [Fotopro Official Store on Amazon](#).
- **Email:** Refer to your product packaging for specific email contact information.

Our support team is available to assist you with any product-related inquiries.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D2VNDMLW>

More documents and user manuals: <https://manuals.plus/>