Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > DOOGEE /
- > DOOGEE T30S Android 14 Tablet User Manual

DOOGEE T30S

DOOGEE T30S Android 14 Tablet User Manual

Model: T30S

Introduction
Getting Started
Basic Operation
Advanced Features
Battery Management
Care & Maintenance
Troubleshooting
Specifications
Warranty & Support

1. Introduction

This manual provides essential information for the safe and efficient use of your DOOGEE T30S Android 14 Tablet. Please read it thoroughly before operating your device. Keep this manual for future reference.

Product Overview

The DOOGEE T30S is an 11-inch Android 14 tablet designed for productivity, entertainment, and communication. It features a 2.4K IPS display, an octa-core processor, and a large 8580mAh battery. The tablet comes with a comprehensive set of accessories including a Bluetooth keyboard, mouse, capacitive touch pen, and a leather case.



Figure 1: DOOGEE T30S Tablet and Accessories

The tablet's ultra-thin metal body, measuring just 7.6mm thick and weighing 506 grams, ensures portability without compromising on durability. The 11-inch display offers a 16:10 aspect ratio and 85% screen-to-body ratio for an immersive visual experience.



Figure 2: Ultra-thin and Lightweight Design

Video 1: An overview of the DOOGEE T30S tablet, showcasing its design, features, and accessories.

2. GETTING STARTED

Package Contents

Ensure all items are present in the box:

- 1 x DOOGEE T30S Android 14 Tablet
- 1 x Keyboard
- 1 x Mouse
- 1 x Stylus Pen
- 1 x Leather Case
- 1 x Charger (Note: Charger plug type may vary by region. An adapter may be required for your local outlets.)
- 1 x USB-C Cable
- 1 x User Manual
- 1 x Warranty Card

Charging the Tablet

Before first use, fully charge the tablet. Connect the provided USB-C cable to the tablet's charging port and the other end to the charger. Plug the charger into a power outlet. The tablet supports 10W fast charging.

Power On/Off

- Power On: Press and hold the Power button until the DOOGEE logo appears.
- Power Off: Press and hold the Power button, then select "Power off" from the options on the screen.
- Restart: Press and hold the Power button, then select "Restart" from the options.

Inserting SIM and SD Cards

The DOOGEE T30S supports dual SIM cards and expandable storage via a TF (MicroSD) card. Use the provided SIM ejector tool to open the SIM tray.

- 1. Locate the SIM tray on the side of the tablet.
- 2. Insert the SIM ejector tool into the small hole next to the tray and press gently until the tray pops out.
- Place your Nano-SIM cards and/or TF card into the designated slots on the tray. Ensure they are correctly oriented.
- 4. Carefully push the tray back into the tablet until it clicks into place.

3. BASIC OPERATION

Android 14 Operating System

Your DOOGEE T30S runs on Android 14, offering enhanced privacy, security, and a personalized user experience. Navigate through the interface using touch gestures.



Figure 3: Android 14 Features

Display Features

The tablet features an 11-inch 2.4K IPS In-cell touchscreen with a resolution of 1920x1200 FHD+ and a pixel density of 207 PPI. It is certified with TÜV blue light technology, which helps reduce eye fatigue by filtering harmful blue light.



Figure 4: 11-inch IPS FHD+ Display

Audio Experience

The T30S is equipped with Smart PA technology and four BOX speakers, providing a rich and immersive audio experience. It also includes a 3.5mm headphone interface for private listening.



Figure 5: Immersive Audio



Figure 6: 3.5mm Headphone Interface

4. ADVANCED FEATURES

Camera Functionality

The tablet features a 13MP rear camera and an 8MP front camera. The 13MP rear camera is designed for capturing detailed photos and videos, while the 8MP front camera is suitable for HD video calls.




Figure 7: Dual Camera System

Connectivity

Stay connected with dual 4G LTE support, dual-band 2.4Ghz/5Ghz Wi-Fi, and Bluetooth 5.0. The dual SIM slot allows for simultaneous calls and network access via VoLTE.

- Network Frequencies: GSM:B2/B3/B5/B8; WCDMA:B1/B2/B5/B8; TDD-LTE:B34/B38/B39/B40/B41;
 FDD-LTE:B1/B3/B5/B7/B8/B20/B28A/B28B.
- Wi-Fi: Supports 802.11a, 802.11ac, 802.11b, 802.11g, 802.11n for high-speed internet access.
- Bluetooth 5.0: For efficient wireless peripheral connections.



Figure 8: Wireless Connectivity

GPS Navigation

The tablet is equipped with a high-precision quad navigation system, including GPS, Glonass, Galileo, and Beidou, providing reliable route guidance for various activities.



Figure 9: GPS Navigation

Multitasking and Accessories

The large 11-inch screen supports a Smart Split Screen function, allowing you to use two applications simultaneously for enhanced productivity. The included Bluetooth keyboard, mouse, and capacitive touch pen further expand the tablet's versatility for work, learning, and creative tasks.



Figure 10: Smart Split Screen





Figure 11: Included Accessories

5. BATTERY MANAGEMENT

The DOOGEE T30S is equipped with an 8580mAh large-capacity battery, providing extended usage times. It supports 10W fast charging.



Optimizing Battery Life

- · Adjust screen brightness to a comfortable level.
- · Close unused applications running in the background.
- Disable Wi-Fi, Bluetooth, and GPS when not in use.
- Enable power-saving modes in the tablet settings.

6. CARE AND MAINTENANCE

General Care

- Avoid exposing the tablet to extreme temperatures, direct sunlight, or high humidity.
- Do not drop or subject the tablet to strong impacts.
- · Keep the tablet away from liquids and dust.

Cleaning

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- Do not use harsh chemicals or abrasive cleaners.
- For stubborn smudges, lightly dampen the cloth with water or a screen-cleaning solution.

7. TROUBLESHOOTING

If you encounter issues with your DOOGEE T30S, refer to the following common solutions:

Tablet Not Powering On

- Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on.
- Press and hold the Power button for at least 10-15 seconds to force a restart.

Screen Unresponsive or Lagging

- · Restart the tablet.
- Close background applications that may be consuming resources.
- · Clear cache for problematic applications.

Wi-Fi or 4G Connectivity Issues

- Toggle Wi-Fi/4G off and on.
- Restart your router (for Wi-Fi).
- Ensure SIM cards are correctly inserted and activated with your carrier.
- Check network settings for correct APN (Access Point Name) configurations for 4G.

Charging Problems

- Ensure the charging cable and adapter are securely connected.
- Try a different USB-C cable and charger to rule out faulty accessories.
- Inspect the charging port for any debris or damage.

Audio Issues

- Check the volume settings.
- Ensure no headphones are connected if you expect sound from speakers.
- · Restart the tablet.

If problems persist, contact customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Model Name	T30S
Operating System	Android 14
Screen Size	11 Inches
Screen Resolution	1920 x 1200 pixels (2.4K IPS)
Processor	Octa-Core (1.6GHz, A75 architecture Core)
RAM	16GB (6GB physical + 10GB virtual expansion)
Internal Storage	256GB
Expandable Storage	Up to 1TB via TF card
Rear Camera	13 MP
Front Camera	8 MP
Battery Capacity	8580mAh
Charging	10W Fast Charging
Wireless Connectivity	802.11a/b/g/n/ac Wi-Fi (2.4G/5G), Bluetooth 5.0
Cellular Connectivity	Dual 4G LTE (TD-LTE, FDD-LTE)
Navigation	GPS, Glonass, Galileo, Beidou
Dimensions (LxWxH)	10.12 x 6.64 x 0.3 inches (7.6mm thick)
Weight	1.11 pounds (506 grams)



Figure 13: Processor and Memory Details




Figure 14: Expandable Storage

9. WARRANTY AND SUPPORT

Warranty Information

Your DOOGEE T30S tablet comes with a limited warranty. Please refer to the included Warranty Card for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

Customer Support

If you have any questions, encounter issues, or require technical assistance, please contact DOOGEE customer support. Contact details can typically be found on the official DOOGEE website or on the warranty card included with your product. DOOGEE aims to respond to inquiries within 24 hours.


© 2024 DOOGEE. All rights reserved.

Related Documents - T30S



DOOGEE Tablet User Manual

User manual for the DOOGEE tablet, covering setup, messaging, language settings, safety, and maintenance.





DOOGEE Shoot 1 Smartphone Overview and Specifications

A comprehensive overview of the DOOGEE Shoot 1 smartphone, detailing its key specifications, camera features, connectivity options, dimensions, and package contents. Includes essential battery safety warnings.



DOOGEE S61 / S61 PRO Rugged Industrial Smartphone - Technical Specifications

Explore the detailed technical specifications of the DOOGEE S61 and S61 PRO rugged industrial smartphones. Learn about their Helio G35 processor, 6.0" IPS HD+ display, advanced camera systems (including SONY IMX350), 5180mAh battery, and robust IP68/IP69K/MIL-STD-810H durability.



DOOGEE U10 Series Tablet User Manual and Safety Guide

Comprehensive user manual for the DOOGEE U10 Series tablet, covering essential operations, safety guidelines, maintenance tips, and FCC compliance information. Learn how to set up your device, send messages, manage settings, and ensure safe usage.



DOOGEE U10 Series Tablet User Manual and Safety Guide

Comprehensive user manual for the DOOGEE U10 Series tablet, covering device overview, TF card insertion, booting, SMS/MMS, language settings, SAR information, safety guidelines, and maintenance tips to ensure safe and effective use.