Aoxun G23005WF-2

Aoxun Swivel Outdoor Patio Chairs Instruction Manual

Model: G23005WF-2

Introduction

Thank you for purchasing the Aoxun Swivel Outdoor Patio Chairs. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new chairs. Please read these instructions carefully before use and retain them for future reference.



Image: Aoxun Swivel Outdoor Patio Chairs in a patio setting.

Safety Information

To ensure safe use of your Aoxun Swivel Outdoor Patio Chairs, please observe the following guidelines:

- **Weight Capacity:** Do not exceed the maximum weight capacity of 150 pounds (approximately 68 kg) per chair. Exceeding this limit may result in damage to the chair or personal injury.
- **Adult Use:** This product is intended for use by adults only. Children should be supervised when near the chairs.

- **Stable Surface:** Always place the chairs on a flat, stable, and level surface to prevent tipping.
- **Assembly:** Ensure all bolts, screws, and connectors are securely tightened before use. Periodically check and re-tighten as necessary.
- **Movement:** Exercise caution when swiveling or rocking to avoid collisions with other objects or individuals.
- **Outdoor Use:** While designed for outdoor use, prolonged exposure to extreme weather conditions may affect the product's lifespan. Consider covering or storing chairs during harsh weather.

Package Contents

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.
The package for the 2-pack chairs typically includes:

- Chair Backrests (2)
- Chair Seats with Armrests (2)
- Swivel Bases (2)
- Hardware Pack (bolts, washers, nuts, Allen wrench)
- Instruction Manual (this document)

Setup and Assembly

Assembly is required for these chairs. It is recommended to have two people for easier assembly. Approximate assembly time per chair is 30 minutes. All necessary tools are provided.

Tools Required:

- Included Allen Wrench
- *Optional:* Power screwdriver with appropriate socket and hex wrench attachments for faster assembly.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches.
2. **Attach Swivel Base to Seat:** Align the swivel mechanism on the bottom of the chair seat with the top of the swivel base. Secure using the provided bolts and washers. Do not fully tighten yet.
3. **Connect Backrest:** Attach the chair backrest to the seat and armrest frame. Ensure all holes align. Insert bolts and washers. *Note: Some assembly steps may require more washers than initially indicated in diagrams; refer to the total number of washers provided.*
4. **Tighten All Fasteners:** Once all components are loosely assembled, gradually tighten all bolts and screws. Ensure the chair is stable and level before fully tightening. Avoid over-tightening.
5. **Install Adjustable Feet:** Screw the adjustable feet into the bottom of the swivel base. Adjust them as needed to ensure the chair is level on your surface.



Image: Detailed dimensions of the Aoxun Swivel Outdoor Patio Chair. Please note the maximum weight capacity is 150 lbs per chair, as specified in the safety information.

Operating Instructions

Your Aoxun Swivel Outdoor Patio Chairs are designed for comfort and versatility.

- **Swivel Function:** The chairs feature a 360-degree swivel mechanism, allowing you to rotate freely in any direction.
- **Gentle Rocking:** A 15-degree gentle rocking motion is integrated for added relaxation.
- **Ergonomic Design:** The chairs provide neck, shoulder, and lumbar support, along with an extended leg support and a tilting seat for enhanced comfort.



Image: Ergonomic features of the Aoxun Swivel Outdoor Patio Chair.



Image: Illustration of the 360-degree swivel and 15-degree rocking functionality.

Maintenance

Proper care will extend the life and appearance of your patio chairs.

- **Cleaning:** Wipe clean with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Rust Prevention:** The chairs feature a powder-coated, E-coated metal frame designed for anti-rust properties. However, prolonged exposure to rain or moisture can still lead to rust marks. It is recommended to wipe chairs dry after rain and consider covering them when not in use for extended periods.
- **Fabric Care:** The Textilene fabric is waterproof, breathable, and anti-fading. It is also easy to clean.
- **Hardware Check:** Periodically inspect all bolts and screws to ensure they remain tight. Re-tighten as needed.



Image: Detail of the chair's frame coating for durability.




Image: Features of the Textilene all-weather fabric.

Troubleshooting

If you encounter issues during assembly or use, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Difficulty aligning screw holes during assembly.	Manufacturing tolerance or incorrect part orientation.	Loosely assemble all parts before fully tightening any fasteners. Gently adjust components to align holes. If a hole is severely misaligned, contact customer support.
Chair is wobbly or not level after assembly.	Adjustable feet are uneven or not fully extended/retracted.	Adjust the screw-in feet on the bottom of the swivel base until the chair is stable and level. Ensure all four feet are making firm contact with the ground.
Adjustable feet rattle or loosen frequently.	Normal movement or vibration.	Periodically check and re-tighten the adjustable feet. Consider applying thread locker (not included) if loosening persists.
Rust marks appear on patio surface after rain.	Water pooling on metal parts and dripping.	Wipe chairs dry after rain. Consider using patio chair covers or moving chairs to a sheltered area during prolonged wet weather.

Specifications

Brand	Aoxun
Model Number	G23005WF-2
Color	Brown
Material (Frame)	Metal (Powder Coated, E-coated)
Material (Seat)	Textilene Fabric
Product Dimensions (D x W x H)	18.1"D x 18.8"W x 40"H (46cm D x 47.8cm W x 101.6cm H)

Seat Height	18.1 Inches (46cm)
Chair Backrest Width	18.1 Inches (46cm)
Weight Capacity	150 lbs (68 kg) per chair
Features	Arm Rest, 360° Swivel, 15° Gentle Rocking, Ergonomic Design (Neck, Shoulder, Lumbar, Leg Support)
Indoor/Outdoor Usage	Outdoor
Assembly Required	Yes

Warranty and Support

Aoxun stands behind the quality of its products. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.
For product support, missing parts, or any questions regarding your Aoxun Swivel Outdoor Patio Chairs, please contact Aoxun customer service through the retailer where the product was purchased or visit the official Aoxun website for contact information.
Aoxun Store Link: Visit the Aoxun Store on Amazon

© 2024 Aoxun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question