

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI Padded Zero Gravity Chair Instruction Manual

VINGLI VLG56000231

VINGLI Padded Zero Gravity Chair Instruction Manual

Model: VLG56000231

1. SAFETY INFORMATION

IMPORTANT: Please read all safety information before using the VINGLI Padded Zero Gravity Chair.

- **MAXIMUM WEIGHT CAPACITY: 300 lbs. DO NOT EXCEED.**
- Always ensure the chair is placed on a stable and level surface, especially when reclined.
- Keep hands and fingers clear of moving parts during unfolding, folding, and adjustment to prevent pinching.
- Do not allow children to play on or around the chair unsupervised.
- Inspect the chair regularly for any signs of wear or damage. Discontinue use if any damage is found.

2. SETUP

Your VINGLI Padded Zero Gravity Chair comes fully assembled and ready to use. Follow these steps to unfold and prepare your chair for relaxation.

1. Remove the chair from its packaging.
2. Gently pull the armrests apart to begin unfolding the chair.
3. Continue to unfold until the chair is fully extended and stable on all four legs. Ensure all locking mechanisms are disengaged during unfolding.
4. Attach the removable headrest pillow by sliding its elastic straps over the top of the chair's backrest. Adjust its position for optimal comfort.
5. If using the padded cushion, place it onto the chair and secure it using the integrated ties to prevent it from shifting.
6. Attach the side tray by aligning its clips with the designated slots on the armrest and pressing firmly until it clicks into place.



Figure 2.1: The VINGLI Zero Gravity Chair, showing its compact folded state and fully assembled form with cushion and tray.

3. OPERATING INSTRUCTIONS

The VINGLI Zero Gravity Chair offers multiple reclining positions for personalized comfort.

3.1 Adjusting Recline Positions

1. To recline, gently push back on the armrests while applying slight pressure with your feet on the footrest. The chair will smoothly glide into your desired position.
2. To return to an upright position, push forward with your feet and lean slightly forward.

FULL 170° RECLINING POSITIONS



Figure 3.1: The chair offers a full 90° to 170° adjustable recline for optimal comfort.

3.2 Locking Mechanism

Once you have found your preferred reclining position, use the locking mechanisms to secure the chair.

1. Locate the two locking levers, one on each side beneath the armrests.
2. While in your desired position, push the levers upwards to engage the lock. This will prevent the chair from moving.
3. To unlock, simply push the levers downwards.

3.3 Using the Side Tray

The removable side tray provides convenient storage for your personal items.

- The tray features a cup holder and a slot for your phone or tablet.
- Ensure the tray is securely attached before placing items on it.



Figure 3.2: The removable side tray offers convenient storage for beverages and personal devices.

3.4 Headrest Pillow

The headrest pillow is adjustable and removable for customized neck and head support.

- Slide the pillow up or down along the backrest to find your ideal position.
- To remove, simply slide it off the top of the backrest.

3.5 Video Demonstration: Backrest Adjustment

Video 3.1: This video demonstrates the operation of the backrest adjustment and locking mechanism for the VINGLI Zero Gravity Chair.

4. MAINTENANCE

Proper maintenance will extend the life and appearance of your VINGLI Zero Gravity Chair.

4.1 Cushion Care

- The thick padded cushion is removable. It is recommended to spot clean with mild soap and water. Allow to air dry completely.
- For prolonged life, store the cushion indoors when not in use or during inclement weather.

SEASONAL COMFORT CUSTOMIZED



Figure 4.1: The chair can be used with or without the cushion, adapting to different seasons and comfort preferences.

4.2 Frame Cleaning

- Wipe the frame with a damp cloth and mild detergent. Rinse thoroughly and dry completely to prevent rust.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.

4.3 Storage

- The chair features a foldable design for compact storage. Fold the chair completely and store it in a dry, protected area when not in use for extended periods.

5. TROUBLESHOOTING

If you encounter any issues with your VINGLI Zero Gravity Chair, please refer to the following common solutions:

- **Difficulty Reclining/Locking:** Ensure the locking levers are fully disengaged before attempting to recline. If the chair still sticks, check for any obstructions in the mechanism.
- **Instability:** Verify that the chair is fully unfolded and all legs are firmly on a level surface. Avoid placing the

chair on uneven ground.

- **Cushion Shifting:** Ensure the cushion's ties are securely fastened to the chair frame.

If problems persist, please contact VINGLI Customer Support for assistance.

6. SPECIFICATIONS

Feature	Detail
Brand	VINGLI
Model Name	VLG56000231
Color	Grey
Product Dimensions	30"D x 24"W x 44"H
Item Weight	16 pounds
Maximum Weight Recommendation	300 Pounds
Material	Cotton (Cushion), Textilene (Chair Fabric)
Special Features	Armrests, Removable Cushion, Ergonomic, Foldable, Side Tray, Detachable Head Pillow
Reclining Position Count	3 (Adjustable 90°-170°)
Indoor/Outdoor Usage	Indoor, Outdoor

VINGLI Product Size



Max Load



Weight



26"

36"



Figure 6.1: Key product dimensions and weight capacity.

7. CUSTOMER SUPPORT

For any questions, concerns, or warranty inquiries regarding your VINGLI Padded Zero Gravity Chair, please contact VINGLI Customer Support.

- Refer to your product packaging or the retailer's website for the most current contact information.
- Please have your model number (VLG56000231) and purchase date available when contacting support.

© 2025 VINGLI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D2W4JL5G>

More documents and user manuals: <https://manuals.plus/>