

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw 22mm Soft Silicone Magnetic Buckle Sport Wristband Replacement Straps User Manual

Lamshaw 22mm Soft Silicone Magnetic Buckle Sport Wristband

Lamshaw 22mm Soft Silicone Magnetic Buckle Sport Wristband User Manual

Brand: Lamshaw | Model: 22mm Soft Silicone Magnetic Buckle Sport Wristband

1. INTRODUCTION

This user manual provides comprehensive instructions for the Lamshaw 22mm Soft Silicone Magnetic Buckle Sport Wristband. It covers installation, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your replacement strap. This band is designed for comfort, durability, and ease of use with its innovative magnetic buckle.



Figure 1.1: Lamshaw 22mm Soft Silicone Magnetic Buckle Sport Wristband (Gray)

This image displays the gray Lamshaw 22mm Soft Silicone Magnetic Buckle Sport Wristband attached to a compatible smartwatch, highlighting its sleek design and the magnetic buckle mechanism.

2. COMPATIBILITY

The Lamshaw 22mm Soft Silicone Magnetic Buckle Sport Wristband is compatible with a wide range of smartwatches. Please verify your watch model before installation.

Compatible Watch Models:

- EIGIIS KE2 Watch
- EIGIIS KE3 Watch
- EIGIIS KE5 Watch
- EIGIIS KE6 Watch
- K22 Watch

- K27 Watch
- K52 Watch
- K55 Watch
- K56 Watch
- K57 Watch
- DM50 Watch
- HM09 Watch
- I32 Watch
- S35 Watch
- S66 Watch

Compatible with Model



KE3 Watch



KE5 Watch



K56 Watch



K52 Watch



K22 Watch



KE2 Watch



KE6 Watch



K55 Watch



K56 Watch



HM09 Watch



S66 Watch



K57 Watch

Figure 2.1: Compatible Smartwatch Models

This image illustrates several smartwatch models that are compatible with the Lamshaw 22mm replacement band, providing a visual guide for users to confirm their device's compatibility.

3. SETUP AND INSTALLATION

Installing your new Lamshaw wristband is a straightforward process. Ensure your smartwatch is powered off before beginning installation.

1. **Prepare the Watch:** If you have an existing band, carefully remove it from your smartwatch.
2. **Align the Band:** Take one half of the Lamshaw wristband. Locate the quick-release pins on the ends of the band.
3. **Insert the Pin:** Gently slide one end of the quick-release pin into the lug hole on your smartwatch.
4. **Secure the Band:** While holding the first end in place, pull the quick-release lever to retract the pin, then align the other end with the opposite lug hole. Release the lever to secure the pin. You should hear a click or feel it lock into place.
5. **Repeat for Second Half:** Attach the second half of the wristband following the same steps.
6. **Verify Installation:** Gently tug on both ends of the installed band to ensure it is securely attached to the watch and will not detach during wear.



Figure 3.1: Wristband with Quick-Release Pins

This image provides a side view of the Lamshaw wristband, clearly showing the quick-release pins that facilitate easy attachment and removal from your smartwatch.

4. OPERATION AND ADJUSTMENT

The magnetic folding buckle design allows for easy and precise adjustment of the wristband to fit your wrist comfortably.

1. **Open the Buckle:** Locate the magnetic folding buckle. Gently open the buckle to create a loop large enough to slide your hand through.
2. **Position on Wrist:** Place the smartwatch on your wrist.
3. **Adjust for Fit:** Slide the magnetic buckle along the strap until the band fits snugly but comfortably around your wrist. The strong magnets will hold the band in place without the need for traditional holes or clasps.
4. **Secure the Buckle:** Ensure the magnetic buckle is fully closed and secure.

Magnetic Folding Buckle



New Upgrade Magnetic Folding Buckle Design

Pretty, convenient and stable

No need to deal with holes and clasp, adjust the length as you wish

Figure 4.1: Magnetic Folding Buckle Mechanism

This image highlights the innovative magnetic folding buckle, demonstrating how the magnetic forces ensure a secure and easily adjustable fit without traditional clasps.



【How to adjust】

Open the button on the back of the strap,
adjust it to suit your wrist circumference,
press the button,
and the adjustment is complete

Figure 4.2: How to Adjust the Band

This diagram provides a visual step-by-step guide on how to open the buckle, adjust the strap length, and secure it for a perfect fit on your wrist.

Your browser does not support the video tag.

Video 4.1: Lamshaw Magnetic Band Adjustment Demonstration

This video demonstrates the ease of adjusting and securing the Lamshaw magnetic buckle wristband on a smartwatch, showcasing its flexible and convenient design.

The band is designed to fit wrists ranging from 5.51 inches (140mm) to 8.46 inches (215mm).



Figure 4.3: Wrist Size Range

This diagram illustrates the minimum and maximum wrist sizes that the band can accommodate, ensuring a comfortable fit for a wide range of users.

5. MAINTENANCE AND CARE

To maintain the quality and longevity of your Lamshaw silicone wristband, follow these care instructions:

- **Cleaning:** Wipe the band regularly with a soft, damp cloth. For deeper cleaning, use mild soap and water, then rinse thoroughly.
- **Drying:** Allow the band to air dry completely before reattaching it to your smartwatch or wearing it.
- **Avoid Harsh Chemicals:** Do not expose the band to harsh chemicals, solvents, or abrasive cleaners, as these can damage the silicone material.

- **Storage:** When not in use, store the band in a clean, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you encounter any issues with your Lamshaw wristband, refer to the following common solutions:

Problem	Possible Cause	Solution
Band does not attach securely to watch.	Quick-release pins not fully engaged; incorrect band size for watch model.	Ensure pins are fully extended into lug holes. Verify watch model compatibility (refer to Section 2).
Magnetic buckle feels loose or slips.	Debris on magnetic surface; improper adjustment.	Clean magnetic surfaces with a soft cloth. Re-adjust the band to a snug fit, ensuring the magnets fully engage.
Skin irritation.	Band is too tight; allergic reaction to silicone; lack of cleaning.	Loosen the band slightly. Clean the band regularly. If irritation persists, discontinue use and consult a doctor.

7. SPECIFICATIONS

- **Material:** Soft Silicone
- **Buckle Type:** Magnetic Folding Buckle
- **Band Width:** 22mm
- **Wrist Size Compatibility:** 5.51" - 8.46" (140mm - 215mm)
- **Compatibility:** Compatible with KE2, KE3, KE5, KE6, K22, K27, K52, K55, K56, K57, DM50, HM09, I32, S35, S66 Smart Watches.
- **Package Contents:** 1 x Lamshaw Smartwatch Band (Watch NOT included)

8. WARRANTY AND SUPPORT

This product is a replacement wristband and does not include a smartwatch. For any product-related inquiries, support, or concerns, please contact the seller directly through the platform where the purchase was made. Please refer to the seller's return and refund policies for details regarding product guarantees.