

COSTWAY VH33702PQ-ORDE

COSTWAY Record Player Stand with Charging Station Instruction Manual

Model: VH33702PQ-ORDE | Brand: COSTWAY

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your COSTWAY 3-Tier Record Player Stand with an integrated charging station. Designed for audio enthusiasts and home decoration, this stand offers dedicated storage for your turntable, audio accessories, and vinyl records. Please read these instructions carefully before assembly and use to ensure safe and proper operation.

PRODUCT FEATURES

- **Integrated Charging Station:** Features 2 sockets (250V/16A), 1 USB port, and 1 Type-C port (5V/3A) for convenient device charging. The power cable length is 150 cm.
- **Multi-Tier Storage:** A dedicated top layer for your turntable, an open shelf for audio accessories, books, or other items, and four dividers specifically designed for organizing vinyl records, albums, and CDs.
- **Cable Management:** Includes a designated cable hole on the back to help organize and hide power cords, maintaining a tidy appearance.
- **Stable Construction:** Constructed from high-quality chipboard and MDF with metal support legs, ensuring durability and stability.
- **Safety Features:** Equipped with two anti-tip kits to prevent accidental tipping and enhance safety. Protective pads are included to prevent floor scratches.
- **Versatile Design:** Functions as both a record player stand and a general display shelf, suitable for various living spaces.



Figure 1: Product dimensions. Overall: 48 x 40 x 88 cm (L x W x H). Open shelf: 44.5 x 38 x 25 cm (L x W x H). Each divider: 10 x 30 x 33 cm (L x W x H). Height from floor to divider: 25 cm. Power cable: 150 cm.



Versenkte Steckdosenleiste



250V/16A
2 Steckdosen



5V/3,1A
1 USB-Anschluss & 1 Typ-c



150 CM
Netzkabel

Figure 2: Multiple storage options for turntable, accessories, and vinyl records.

SETUP AND ASSEMBLY

Assembly of the COSTWAY Record Player Stand is required. Please follow the detailed, step-by-step instructions provided in the separate assembly manual included with your product packaging. Ensure all components are present before beginning assembly.

Safety Precautions:

- Always assemble on a clean, flat, and soft surface to prevent scratches.
- Ensure all screws and fasteners are tightened securely. Do not overtighten.
- Install the provided anti-tip kits to a wall stud or solid surface to prevent the stand from tipping, especially if children or pets are present.
- Do not exceed the maximum load capacities specified in the 'Specifications' section.

Zuverlässige Struktur für lange Lebensdauer



Figure 3: Structural details including anti-tip kits, metal support legs, and protective pads for stability and safety.

OPERATING INSTRUCTIONS

Using the Charging Station:

1. After assembling the stand, connect the integrated power cable to a standard wall outlet.
2. The charging station, located on the top surface, provides two 250V/16A sockets, one 5V/3A USB port, and one 5V/3A Type-C port.
3. Plug your record player, audio equipment, or mobile devices into the appropriate ports for power or charging.

Cable Management:

Utilize the cable management hole located on the back of the stand to route power cords and audio cables. This helps to keep your setup neat and prevents tangled wires.

Was macht sie einzigartig?



Unserer

- ✓ Mit intimer Ladestation
- ✓ Mit Kabelmanagement-Loch

Andere

- ✗ Keine Steckdosen oder USB-Anschlüsse
- ✗ Kein Kabelmanagementloch



Figure 4: Close-up of the recessed charging station with two power sockets, one USB port, and one Type-C port.

MAINTENANCE

To maintain the appearance and longevity of your record player stand, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the stand with a soft, dry cloth to prevent dust buildup.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the engineered wood.
- **Inspection:** Periodically check all connections and fasteners to ensure they remain tight.

TROUBLESHOOTING

If you encounter any issues with your record player stand, consider the following common solutions:

- **Stability Issues:** Ensure all assembly screws are fully tightened. Verify that the stand is placed on a level surface. Re-check the installation of the anti-tip kits.
- **Charging Station Not Working:** Confirm the power cable is securely plugged into both the stand

and a functional wall outlet. Check if the wall outlet is receiving power.

- **Scratches on Floor:** Ensure the protective pads on the metal legs are properly installed and intact.

For further assistance, please refer to the contact information in the Support section.

SPECIFICATIONS

Brand	COSTWAY
Model Number	VH33702PQ-ORDE
Overall Dimensions (L x W x H)	48 x 40 x 88 cm (18.9 x 15.75 x 34.65 inches)
Item Weight	16 kg (35.27 lbs)
Material	Chipboard, MDF, Metal (Engineered Wood)
Color	Rustic Brown
Top Load Capacity	50 kg (110 lbs)
Open Shelf Load Capacity	30 kg (66 lbs)
Dividers Total Load Capacity	40 kg (88 lbs)
Charging Station Sockets	2 x 250V/16A
Charging Station USB Port	1 x 5V/3A
Charging Station Type-C Port	1 x 5V/3A
Power Cable Length	150 cm (59 inches)
Number of Shelves	4 (dividers) + 1 (open shelf) + 1 (top)
Assembly Required	Yes

WARRANTY AND SUPPORT

This COSTWAY Record Player Stand comes with a limited warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty information provided in your product packaging or contact COSTWAY customer service directly.

For technical support, missing parts, or any questions not covered in this manual, please visit the official COSTWAY website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.

