

NAVIFORCE NF7102

NAVIFORCE Digital Multi-Function Watch NF7102 User Manual

Model: NF7102

1. INTRODUCTION

This manual provides comprehensive instructions for the operation, setup, and maintenance of your NAVIFORCE Digital Multi-Function Watch, model NF7102. Please read this manual carefully to ensure proper use and to maximize the lifespan of your watch.





Figure 1: Front view of the NAVIFORCE Digital Multi-Function Watch NF7102.

2. PRODUCT OVERVIEW

2.1 Key Features

- **Movement:** High-efficiency electronic components for accurate time display and low power consumption.
- **Strap:** Soft and durable silicone strap, designed for comfort and elasticity.
- **Case:** Lightweight PC plastic case, ergonomically designed for comfortable wear.
- **Multi-functional:** Includes 13-digit chronograph, automatic weekly calendar, 12/24-hour system, alarm, snooze, full-time chime, 1/100th second stopwatch, dual time, countdown timer, and white LED backlight.
- **Waterproof:** 30m water resistance for daily use (hand washing, rain, splashes). Not suitable for swimming, diving, or showering.

2.2 Watch Components and Button Functions



Figure 2: Watch button functions. The buttons are labeled LIGHT, MODE, ST/STP, and RESET.

- **LIGHT Button:** Activates the white LED backlight.
- **MODE Button:** Cycles through different watch modes (Time, Alarm, Stopwatch, Dual Time, Countdown).
- **ST/STP Button:** Starts/stops functions in Stopwatch mode, adjusts settings in setting modes.
- **RESET Button:** Resets functions in Stopwatch mode, adjusts settings in setting modes.

3. SETUP AND BASIC OPERATION

3.1 Initial Time and Date Setting

1. In Timekeeping Mode, press and hold the **MODE** button until the seconds begin to flash, indicating setting mode.
2. Press the **RESET** button to cycle through the settings: Seconds → Hour → Minute → Year → Month → Day.
3. Use the **ST/STP** button to adjust the flashing value.
4. Once all settings are correct, press the **MODE** button to exit setting mode.

3.2 12/24-Hour Format Selection

In Timekeeping Mode, press the **ST/STP** button to toggle between 12-hour (with AM/PM indicator) and 24-hour formats.

4. OPERATING INSTRUCTIONS FOR FUNCTIONS

Press the **MODE** button to cycle through the following modes:

- Timekeeping Mode
- Alarm Mode
- Stopwatch Mode
- Dual Time Mode
- Countdown Timer Mode

4.1 Alarm Mode

1. From Timekeeping Mode, press **MODE** once to enter Alarm Mode.
2. Press and hold **RESET** until the alarm hour flashes.
3. Use **ST/STP** to adjust the hour. Press **RESET** to move to minutes.
4. Use **ST/STP** to adjust the minutes.
5. Press **MODE** to exit alarm setting.
6. In Alarm Mode, press **ST/STP** to toggle the alarm ON/OFF. An alarm icon will appear when active.
7. Press **LIGHT** to activate the snooze function when the alarm sounds.

4.2 Stopwatch Mode (1/100th Second)

1. From Timekeeping Mode, press **MODE** twice to enter Stopwatch Mode.
2. Press **ST/STP** to start the stopwatch.
3. Press **ST/STP** again to stop the stopwatch.
4. Press **RESET** to clear the stopwatch to zero.
5. To record split times, press **RESET** while the stopwatch is running. The display will show the split time while the stopwatch continues to run in the background. Press **RESET** again to return to the running stopwatch display.

4.3 Dual Time Mode

This function allows you to keep track of a second time zone.

1. From Timekeeping Mode, press **MODE** three times to enter Dual Time Mode.
2. Press and hold **RESET** until the hour flashes.
3. Use **ST/STP** to adjust the hour. Press **RESET** to move to minutes.
4. Use **ST/STP** to adjust the minutes.
5. Press **MODE** to exit dual time setting.

4.4 Countdown Timer Mode

1. From Timekeeping Mode, press **MODE** four times to enter Countdown Timer Mode.
2. Press and hold **RESET** until the hour flashes.
3. Use **ST/STP** to adjust the hour. Press **RESET** to move to minutes.
4. Use **ST/STP** to adjust the minutes.
5. Press **MODE** to exit countdown setting.

6. Press **ST/STP** to start or pause the countdown.
7. When the countdown reaches zero, an alarm will sound. Press any button to stop the alarm.

4.5 Backlight Function

Press the **LIGHT** button in any mode to illuminate the display with a white LED backlight for a few seconds.



Video 1: An overview of the NAVIFORCE Digital Multi-Function Watch, demonstrating its design and features. This video is provided by the NAVIFORCE Flagship Store.

5. MAINTENANCE AND CARE

5.1 Water Resistance

The watch is rated for 30 meters (3ATM) water resistance. This means it is suitable for daily use such as hand washing, rain, and splashes. It is **not** recommended for swimming, diving, or showering, as prolonged exposure to water pressure or steam can compromise the seals.




Figure 3: The watch demonstrating its 30m water resistance for daily activities.

5.2 Cleaning the Watch

To clean your watch, wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, which can damage the case or strap. For the silicone strap, mild soap and water can be used, followed by thorough rinsing and drying.

5.3 Battery Information

The watch uses 1 Lithium Polymer battery (included). Battery replacement should ideally be performed by a qualified watch technician to ensure water resistance is maintained.

6. TROUBLESHOOTING

- **Display is blank or dim:** Check battery level. If the battery is low, the display may become dim or disappear. Replace the battery.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though this model does not specify a lock function). Try pressing the buttons firmly. If issues persist, a battery reset might be needed by a professional.
- **Time is inaccurate:** Re-set the time according to Section 3.1. If inaccuracy persists after setting, the

battery may be low or the movement may require service.

- **Water inside the watch:** If moisture appears inside the watch, stop using it immediately and take it to a professional for inspection and repair to prevent further damage.

7. SPECIFICATIONS

Feature	Specification
Model Number	NF7102
Product Dimensions	3.5 x 3.5 x 4 inches
Item Weight	5.29 ounces
Case Diameter	35mm
Case Thickness	14mm
Strap Material	Silicone
Clasp Type	Buckle
Water Resistance	30m (3ATM)
Battery Type	1 Lithium Polymer (included)
Manufacturer	NAVIFORCE

