

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Donner](#) /

› [Donner HUSH I PRO Acoustic Electric Travel Guitar Instruction Manual](#)

Donner HUSH I PRO

Donner HUSH I PRO Acoustic Electric Travel Guitar

Instruction Manual

1. SETUP

1.1 Package Contents

Your Donner HUSH I PRO guitar kit includes everything you need to get started:

- Donner HUSH I PRO Acoustic Electric Travel Guitar
- Portable Gig Bag
- Headphones
- USB-C Charging Cable
- 1/8" Audio Cable
- Strap
- Truss Rod Wrench

1.2 Assembly


The HUSH I PRO features an upgraded quick-disconnect zinc alloy bracket for fast and solid assembly of the body rests. Simply attach the body rests to the main guitar body as shown in the image below.

IMMERSIVE ATMOSPHERIC TONE DISCOVERY

8 Acoustic
Guitar Body
Styles



Customize
Your
Tone



18 Presets



20 IIR slots



Image: Donner HUSH I PRO Travel Guitar with detachable body rests, ready for playing.

1.3 Charging

Before first use, ensure your guitar is fully charged. Connect the provided USB-C charging cable to the guitar's USB-C port. The guitar has a battery life of approximately 8 hours on a full charge.



Image: Close-up of the USB-C charging port and internal battery indicator on the HUSH I PRO.

1.4 Initial Tuning

The HUSH I PRO includes a built-in tuner. To access it, rotate the EDIT knob clockwise until the display shows 'Tuner'. Strum each string individually and adjust the corresponding tuning barrels at the bottom of the guitar until the display indicates the correct pitch.

H1 MULTI-EFFECTS PREAMP SYSTEM



Image: The control panel displaying the tuner interface.

2. OPERATING

2.1 Power On/Off

To power on the guitar, press and hold the Power button on the control panel. The display will illuminate. To power off, press and hold the Power button again.

Your browser does not support the video tag.

Video: Demonstration of the Donner HUSH I PRO panel functions and startup display.

2.2 Effect Modes and Tone Adjustment

The HUSH I PRO features 18 built-in effects (5 Modulation, 5 Delay, 5 Reverb, Overdrive, Compressor, Booster) and 8 legendary guitar body tone simulations. Utilize the upgraded H1 preamp system and dynamic 5-band equalization (EQ) adjustment module to fine-tune your sound. Rotate the EDIT knob to select different modules (Presets, Multi, Mod, Delay, Reverb, IR, EQ, Tuner) and use the SELECT and VALUE knobs to adjust parameters within each module.

DONNER HUSH-I PRO GUITAR

UNLEASH YOUR SOUND SPECTRUM



Image: The guitar's display showing various effect presets and tone options.

2.3 Silent Practice

With its resonance-free chamber design and low-decibel strumming sound, the HUSH I PRO allows for quiet practice without disturbing others. Connect headphones to the dedicated jack for an immersive experience. The effect algorithm system also supports wireless BGM accompaniment, allowing you to connect your audio device and play along.

SILENT PRACTICE COMPLETE PACKAGE



Image: A musician enjoying silent practice with the HUSH I PRO and headphones.

2.4 Portability

Building on the distinctive headless design of the HUSH travel guitar series, the I PRO weighs just 2.2kg (approximately 4.85 lbs), making it highly portable. Its compact size is ideal for travel, performances, and practice sessions on the go.

ULTRA-PORTABLE ULTIMATE FLEXIBILITY



Image: The compact size of the Donner HUSH I PRO, highlighting its travel-friendly design.

3. MAINTENANCE

3.1 General Care

Keep your guitar clean by wiping it with a soft, dry cloth after each use. Store it in its gig bag to protect it from dust and environmental changes. Avoid exposing the guitar to extreme temperatures or humidity.

3.2 Battery Care

Please charge promptly when the low battery indicator appears to ensure normal use and prolong battery life. Avoid completely draining the battery frequently.

3.3 Truss Rod Adjustment

The truss rod can be adjusted to optimize neck relief and string action. Use the provided truss rod wrench for adjustments. If you are unfamiliar with truss rod adjustments, it is recommended to seek assistance from a qualified guitar technician.

4. TROUBLESHOOTING

4.1 Common Issues

- Distortion or Noise:** If distortion or noise occurs, especially when using output devices or earphones, it may be due to impedance mismatch. Try replacing with compatible equipment.
- Tuning Instability:** Ensure strings are properly seated and stretched. Utilize the built-in tuner for accurate tuning.
- String Buzz:** String buzz can be caused by improper neck relief or saddle height. Refer to the truss rod adjustment section or consult a technician.
- Bluetooth Buzz:** Some users have reported static buzz when using the Bluetooth function for backing tracks. Try different headphones or streaming devices.

5. SPECIFICATIONS

Feature	Specification
Model Number	HUSH I PRO
Item Weight	8.91 pounds
Package Dimensions	36.22 x 7.28 x 4.92 inches
Country of Origin	China
Batteries	1 Lithium Polymer batteries required (included)
Back Material	Mahogany
Body Material	Mahogany
Color Name	Metallic White
Fretboard Material	Maple/Laurel

Guitar Pickup Configuration	Piezo
String Material	Alloy Steel
Top Material	Mahogany
Neck Material Type	Mahogany/Maple
Number of Strings	6
Guitar Bridge System	Piezo
Hand Orientation	Right

6. WARRANTY AND SUPPORT

6.1 Warranty Information

Specific warranty details are not provided in this manual. Please refer to the product packaging or the official Donner website for comprehensive warranty information.

6.2 Customer Support

For further assistance, technical support, or inquiries regarding your Donner HUSH I PRO guitar, please visit the official Donner website or contact their customer service department.