

[Manuals.plus](#) /

› [Relaxdays](#) /

› Relaxdays Aluminum BBQ Trays (Set of 100) - Instruction Manual

Relaxdays 10049377

Relaxdays Aluminum BBQ Trays (Set of 100) - Instruction Manual

Model: 10049377

1. INTRODUCTION

Thank you for choosing Relaxdays Aluminum BBQ Trays. This set of 100 disposable aluminum trays is designed to simplify your grilling and cooking experience, providing a convenient solution for preparing various foods on the barbecue or in the oven. These trays help to cook food evenly, prevent flare-ups, and minimize cleanup.

2. PRODUCT FEATURES

- **Barbecue Accessory:** A set of 100 trays suitable for barbecues, garden parties, camping, and other outdoor cooking events.
- **Safe Cooking:** Ideal for preparing fish, meat, or vegetables on the barbecue. Also suitable for reheating leftovers.
- **Versatile Use:** Compatible with charcoal, gas, and electric barbecues. Can also be used in conventional ovens up to 260 °C (500 °F).
- **Convenient:** Ensures even heating of dishes and eliminates the need for difficult cleanup after cooking.
- **Dimensions:** Rectangular BBQ drip trays made from recyclable aluminum. Approximate dimensions: Height x Width x Depth: 3 x 34 x 22 cm (1.2 x 13.4 x 8.7 inches).



Image: Stack of aluminum BBQ trays.



Image: Top-down view of a single aluminum BBQ tray, highlighting its design.

3. SETUP AND USAGE

1. **Preparation:** Remove a single aluminum tray from the stack. Ensure the tray is clean and free from any debris.
2. **Placement:** Place the tray directly onto your barbecue grill grates or into a conventional oven. Ensure it is stable.
3. **Food Loading:** Arrange your food (meat, fish, vegetables) evenly within the tray. The perforated bottom allows for heat circulation and drainage of excess fats, preventing flare-ups.
4. **Cooking Temperature:** These trays are designed to withstand temperatures up to 260 °C (500 °F). Monitor cooking to prevent burning.
5. **Serving:** Once cooking is complete, carefully remove the tray from the heat source using heat-resistant gloves or tongs. The tray can be used for serving directly, reducing the need for extra dishes.



Image: Aluminum tray in use at a barbecue, holding grilled food.



Image: Aluminum tray used for cooking while camping.

4. MAINTENANCE

These aluminum trays are designed for single-use convenience. After use, allow the tray to cool completely before disposing of it responsibly. The trays are made from recyclable aluminum, so please check local recycling guidelines for proper disposal.

Do not attempt to wash and reuse the trays as this may compromise their structural integrity and hygiene.

5. TROUBLESHOOTING

- **Food Sticking:** Lightly grease the tray with cooking oil or spray before placing food to prevent sticking, especially for delicate items.
- **Tray Bending/Warping:** Ensure the tray is placed on a flat, stable surface on the grill or in the oven. Avoid overloading the tray with excessively heavy items. The trays are designed for typical barbecue and oven use.
- **Uneven Cooking:** Distribute food evenly within the tray. For barbecues, ensure the heat source is consistent.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions (H x W x D)	Approx. 3 x 34 x 22 cm (1.2 x 13.4 x 8.7 inches)
Item Weight (per 100 trays)	Approx. 1.74 kg
Material	Aluminum (Recyclable)
Maximum Temperature	260 °C (500 °F)
Quantity	100 pieces per set
Model Number	10049377



Image: Dimensions of the aluminum BBQ tray.

7. SAFETY INFORMATION

- **Heat Hazard:** Aluminum trays become very hot during and after use. Always use heat-resistant gloves or appropriate tools when handling hot trays.
- **Sharp Edges:** Handle trays with care as edges may be sharp.
- **Not for Microwave Use:** Do not use aluminum trays in a microwave oven.
- **Food Safety:** Ensure food is cooked to safe internal temperatures.
- **Children and Pets:** Keep used and unused trays out of reach of children and pets.

8. WARRANTY AND SUPPORT

For any questions regarding the Relaxdays Aluminum BBQ Trays, please contact Relaxdays customer support. As these are disposable items, specific warranties typically do not apply beyond initial product defects. Please retain your proof of

purchase for any inquiries.

