

Carlett LETT800M-S6

Carlett Lett800 Comfort Move Shopping Cart with Seat User Manual

Model: LETT800M-S6

1. INTRODUCTION

Thank you for choosing the Carlett Lett800 Comfort Move shopping cart with an integrated seat. This product is designed to assist with shopping and provide a convenient resting spot. It features a lightweight aluminum frame, four wheels for easy maneuverability, an adjustable handle, and a removable, water-resistant bag. This manual provides essential information for the safe and effective use, assembly, and maintenance of your Carlett Lett800 Comfort Move.

Please read this manual thoroughly before using the product and retain it for future reference.

2. SAFETY INFORMATION

Your safety is paramount. Please observe the following guidelines:

- **Weight Limits:** Do not exceed the maximum bag capacity of 15 kg (33 lbs). The integrated seat has a maximum load capacity of 100 kg (220 lbs).
- **Brakes:** Always engage the parking brake when using the seat or when the cart is stationary on an incline. Ensure the adjustable brake system is functioning correctly before each use.
- **Stability:** Ensure all four wheels are in contact with the ground and the cart is stable before sitting on the seat. Avoid leaning excessively to one side.
- **Uneven Surfaces:** Exercise caution on uneven terrain, inclines, or stairs. The cart is not designed for use as a primary mobility aid on highly challenging surfaces.
- **Children:** This product is not a toy. Do not allow children to play with or sit unsupervised on the cart.
- **Assembly:** Ensure all components are correctly assembled and securely fastened before use. Refer to the "Setup" section.
- **Maintenance:** Regularly inspect the wheels, brakes, frame, and bag for any signs of wear or damage. Do not use if damaged.
- **Medical Device:** This product is classified as a Class I Medical Device. Consult a healthcare professional if you have specific mobility concerns.

3. SETUP AND INITIAL ASSEMBLY

The Carlett Lett800 Comfort Move is designed for easy setup. Follow these steps to prepare your cart for use:

1. Unfolding the Frame:

Carefully remove the cart from its packaging. Hold the handle and gently pull the frame outwards until it locks into its open position. Ensure all locking mechanisms are engaged.



Figure 3.1: The Carlett Lett800 Comfort Move shopping cart in its fully unfolded state, viewed from the front-side. The navy blue bag and seat are visible, along with the silver aluminum frame and black handle.

2. Attaching the Bag:

The removable bag should be securely attached to the frame. Locate the attachment points on the frame and fasten the bag using its integrated straps or clips. Ensure the bag is fully seated and stable.

3. Adjusting the Handle:

The ergonomic handle can be adjusted to four different height positions. Locate the adjustment buttons or levers on the side of the handle. Press them and slide the handle to your desired height. Release the buttons/levers to lock the handle in place. Ensure both sides are locked at the same height.



Figure 3.2: A top-down perspective showing the adjustable handle and the integrated seat of the Carlett Lett800 Comfort Move. The handle adjustment mechanism is visible.

4. Checking the Wheels:

Verify that all four wheels are securely attached and rotate freely. The front wheels have a locking mechanism for different maneuverability settings (fixed, 90°, 360° rotation). Ensure they are set to your preferred mode for initial use.

4. OPERATING INSTRUCTIONS

4.1. Using the Shopping Cart

- **Loading the Bag:** Place items evenly inside the removable bag, ensuring not to exceed the 15 kg weight limit. Distribute weight to maintain balance.
- **Maneuvering:** Push the cart using the adjustable handle. Adjust the front wheels to fixed, 90-degree, or 360-degree rotation based on your maneuverability needs. 360-degree rotation offers maximum agility, while fixed provides more directional stability.
- **Braking:** Squeeze the brake levers on the handle to slow down or stop the cart. For parking, engage the parking brake by pushing the levers down until they lock. Release by pulling them up.



Figure 4.1: An individual demonstrating the use of the Carlett Lett800 Comfort Move as a walking aid while pushing it along a paved path.

4.2. Using the Integrated Seat

- **Engage Parking Brake:** Before sitting, always ensure the cart is on a flat, stable surface and the parking brake is fully engaged to prevent movement.
- **Sitting Down:** Carefully turn around and sit on the padded seat. Use the handle for support if needed.
- **Standing Up:** Use the handle for support as you stand up. Disengage the parking brake before moving the cart.
- **Weight Limit:** Do not exceed the seat's maximum weight capacity of 100 kg (220 lbs).



Figure 4.2: Two individuals utilizing the integrated seats of their Carlett Lett800 Comfort Move carts for resting outdoors.

4.3. Folding for Storage

To fold the cart for compact storage or transport:

1. Empty the shopping bag.
2. Locate the folding mechanism (usually a lever or button near the base of the handle or frame).
3. Activate the mechanism and gently push the sides of the frame together until the cart is in its folded position.
4. Ensure it is securely latched to prevent accidental unfolding.



Figure 4.3: An individual demonstrating the portability of the folded Carlett Lett800 Comfort Move cart by pulling it up a set of outdoor stairs.

5. MAINTENANCE

- **Cleaning the Frame:** Wipe the aluminum frame with a damp cloth and mild detergent. Dry thoroughly. Avoid abrasive cleaners.
- **Cleaning the Bag:** The removable bag is washable. Follow the care instructions on the bag's label. For general cleaning, wipe with a damp cloth. The water-resistant fabric helps with easy cleaning.
- **Wheel Maintenance:** Periodically check the wheels for debris (hair, lint, dirt) and remove it. Ensure the wheels rotate smoothly. Lubricate axles if necessary with a silicone-based spray.
- **Brake Inspection:** Regularly check the brake cables and levers for proper function and wear. If brakes feel loose or ineffective, have them inspected by a qualified technician.
- **Storage:** Store the cart in a dry place, away from direct sunlight and extreme temperatures, to prolong its lifespan.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cart does not roll smoothly.	Debris in wheels, loose axle, wheel lock engaged.	Clean wheels, check axle tightness, ensure wheel locks are disengaged for free rotation.
Brakes feel loose or ineffective.	Brake cable stretched, brake pads worn, improper adjustment.	Adjust brake cable tension (refer to a qualified technician if unsure), inspect brake pads for wear.
Handle does not lock at desired height.	Adjustment mechanism not fully engaged, debris.	Ensure adjustment buttons/levers are fully released and locked into a position. Clear any obstructions.

Problem	Possible Cause	Solution
Cart is unstable when sitting.	Parking brake not engaged, uneven surface, weight limit exceeded.	Always engage parking brake. Use on flat, stable surfaces. Do not exceed 100 kg seat capacity.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact Carlett customer support.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Carlett
Model Number	LETT800M-S6
Material	Aluminum (Frame)
Product Dimensions (L x W x H)	55 x 47 x 102 cm (21.65 x 18.5 x 40.16 inches)
Item Weight	5.4 kg (11.9 lbs)
Bag Capacity	29 Liters
Maximum Bag Weight Limit	15 kg (33 lbs)
Maximum Seat Weight Capacity	100 kg (220 lbs)
Number of Wheels	4
Handle Adjustment	4 positions
Wheel Adjustment	3 positions (fixed, 90°, 360°)
Medical Classification	Class I Medical Device

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. Carlett is committed to product quality and customer satisfaction.

If you have any questions, require technical assistance, or need to report a problem with your Carlett Lett800 Comfort Move, please contact Carlett customer support through their official website or the contact information provided with your purchase.

Spare parts availability information is not provided in this manual.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question